



System Management Module User's Guide



Note

Before using this information and the product it supports, be sure to read and understand the safety information and the safety instructions, which are available at:

http://thinksystem.lenovofiles.com/help/topic/safety_documentation/pdf_files.html

In addition, be sure that you are familiar with the terms and conditions of the Lenovo warranty for your solution, which can be found at:

<http://datacentersupport.lenovo.com/warrantylookup>

First Edition (August 2017)

© Copyright Lenovo 2017.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925

Contents

Chapter 1. Introduction 1

Scope of this document 1

Chapter 2. Web interface access 3

Chapter 3. Overview 5

Summary 7

Enclosure Front Overview 7

Enclosure Rear Overview 8

Power 10

Power Overview 10

PSU Configuration 11

Power Cap 12

Voltage Overview 14

Power Restore Policy 14

Cooling 15

Cooling Overview 15

PSU Fan Speed 16

Acoustic Mode 17

System Information 17

Enclosure VPD 18

PDM VPD 18

SMM VPD 19

PSU VPD 19

EIOM VPD 20

PIOR Right/Left VPD 21

Event Log 21

Configuration 22

Firmware Update 23

SMTP/SNMP/PEF 24

Network Configuration 26

Time Setting 28

User Account 29

Account Security 31

Services 31

Web Certificate 32

Network Time Protocol (NTP). 35

Backup and Restore 36

Chapter 4. IPMI Command 39

SMTP Configuration Parameters 58

LAN Configuration Parameters 61

Index 63

Chapter 1. Introduction

The System Management Module (SMM) firmware built-in web pages. It supports the Transport Layer Security 1.2 for data encryption over the network and certificate management.

The SMM performs the following tasks:

1. Node status report
2. Enclosure power and fan status report
3. Enclosure power and fan configuration management
4. Enclosure Vital Product Data (VPD) information report
5. Enclosure event log display, save, and clear
6. SMM management and settings backup/restore

Note:

The SMM web interface supports the following browsers:

- Internet Explorer 11
- Microsoft Edge 25.10586 or later
- Mozilla Firefox 48.0 or later
- Google Chrome 52.0 or later

Scope of this document

This documentation provides the process of operating SMM and detailed WebGUI. The descriptions include how to check the status, component information and show you how to modify the configuration. It offers the detailed explanation and definition for each function tabs of the SMM web pages.

Chapter 2. Web interface access

SMM web interface can be accessed through Ethernet connection (10/100/1000 Mbit) by establishing a session with SMM.

Connecting to the SMM for the first time might require a change of the Internet protocol properties on the client computer. See “Network Configuration” on page 26 section for more information. To log in to the SMM web interface, complete the following steps :

1. Enable SMM network. By default, SMM network is disabled. To enable SMM network, please issue below IPMI command to XClarity Controller. The <XCC's IP> is the XCC's IP address.
 - Query: `ipmitool -I lanplus -H <XCC's IP> -U USERID -P PASSWORD raw 0x3A 0xF1 0x00`
 - Enable: `ipmitool -I lanplus -H <XCC's IP> -U USERID -P PASSWORD raw 0x3A 0xF1 0x01`
 - Disable: `ipmitool -I lanplus -H <XCC's IP> -U USERID -P PASSWORD raw 0x3A 0xF1 0x02`

Net Function = 0x3A			
Code	Command	Request, Response Data	Description
0xF1	SMM network control	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Request type <ul style="list-style-type: none"> – 0x00 = Query SMM network status – 0x01 = Enable – 0x02 = Disable <p>Response:</p> <ul style="list-style-type: none"> • Byte 1 – Completion Code • Byte 2 – SMM network status (for Query request only) 	<p>This setting is used to set SMM network status which value is disabled as default.</p> <p>The XClarity Controller command supports ThinkSystem D2 Enclosure and ThinkSystem SD530 Compute Node. ThinkSystem D2 Enclosure and ThinkSystem SD530 Compute Node only.</p>

2. Point your browser to the SMM web interface URL that your system administrator defined during initial configuration.

Following out-of-factory default network settings is applied at first use of SMM:

- a. SMM use DHCP first. If SMM cannot acquire IP from DHCP server in 2 minutes. It will use static IP.
- b. The default static IP is 192.168.70.100
- c. Using Hyper Text Transfer Protocol Secure (HTTPS). (For example, <https://192.168.70.100>)
- d. IPv4 enabled with static IP = 192.168.70.100
- e. IPv6 enabled with local link address (LLA) IP

Notes: To calculate LLA IP, follow procedures below:

- 1) Split the MAC address of SMM (39-A7-94-07-CB-D0) into two parts and insert FF-FE in the middle. For example, 39-A7-94-FF-FE-07-CB-D0
- 2) Convert the two hexadecimal digits at the left end of the string to binary. For example, 00111001-A7-94-FF-FE-07-CB-D0
- 3) Invert the value for bit 1 of the first byte. For example, 00111011-A7-94-FF-FE-07-CB-D0
- 4) Convert the binary digits at the left end of the string back to hexadecimal
- 5) Combine the hexadecimal digit pairs into 4-digit groups. For example, 3BA7-94FF-FE07-CBD0

- 6) Replace dash (-) separators with colon (:) separators. For example, 3BA7:94FF:FE07:CB00
 - 7) Add FE80:: to the left of the string. For example, FE80::3BA7:94FF:FE07:CB00
3. Type your user ID and password assigned by a system administrator.
 - Default ID: USERID
 - Password: PASSWORD

Note: The sixth character of PASSWORD is number zero.

4. Click **Log in**.
5. Change password for the first login
Default password complexity rules:
 - At least 10 characters in length
 - Must contain at least one number (0 through 9)
 - Must contain at least two of the following three categories:
 - An uppercase letter (A through Z)
 - A lowercase letter (a through z)
 - A non-alphabetic characters such as !@#\$%^*_+() .:|'?"\
6. Use the new password to log in

Chapter 3. Overview

The section introduces detailed functions for SMM web interface.

There are overall six function tabs:

- **Summary**
- **Power**
- **Cooling**
- **System Information**
- **Event Log**
- **Configuration**

Mouse cursor over the function tab buttons reveals the subcategories of the function. Click on the tab or subcategories taking user directly to the function.



Summary



Power and
Cooling



System
Information



Event Log



Configuration

Figure 1. Overview

Notes:

- Please use **Refresh** button on SMM web pages to refresh. If users press F5 on a keyboard or click refresh on a browser, the web page will redirect to login page for security considerations.
- Pages with **Refresh** button does not refresh periodically, except voltage overview and cooling overview. Auto-refresh interval is every 30 seconds on these two pages. For the other pages, click **Refresh** button to get the latest readings and status.

- The session will expire when users do not perform any action on web pages for an interval (default value is 20 minutes), except users stay on an auto-refresh page.

Summary

Summary page displays overall enclosure status and information.



Figure 2. Enclosure

Enclosure Front Overview

Under **Enclosure Front Overview** section, the following illustration indicates the node status:




Figure 3. Enclosure Front Overview

- **Node:** Indicates node numbering.
- **Height:** Node height can be 1 to 2U.
- **Status:**
 - **Not Present:** No node is installed.
 - **No Permission:** The node has not granted power permission and cannot be powered on.
 - **Fault:** The node has power fault and cannot be powered on.
 - **Power On:** The node is powered on.
 - **Power Off:** The node is powered off.
- **Reset/Reseat:** Used to perform virtual reset/virtual reseat.
 - **Reset:** Remotely reset node XClarity Controller (XClarity Controller) through SMM.
 - **Reseat:** Remotely power cycle the entire node.
 - After virtual **Reset/Reseat**, the node XClarity Controller takes at least two minutes to be ready.
- **Launch XClarity Controller:** Using the specified IP address to access XClarity Controller from Web.

Note: Enclosure Front Overview needs to be manually updated 5 minutes after SMM or the node XClarity Controller is reset to maintain latest node status.

Enclosure Rear Overview

Under **Enclosure Rear Overview** section, there are three major sections to show the rear enclosure status:

- **Management Module**
- **Current PSU**
- **Fan**

Management Module

Management Module: Indicates the status of SMM

Management Module	
Name	System Management Module (SMM)
Status	<input checked="" type="checkbox"/> Normal <input type="button" value="SMM Reset"/> <input type="button" value="Reset to Default"/>
Firmware Version	1.0 (TESM04A)
Boot-up Flash	First
ID LED	Off <input checked="" type="radio"/> Turn Off <input type="radio"/> Turn On <input type="radio"/> Blink <input type="button" value="Apply"/>
Error LED	Off
FFDC	<input type="button" value="Capture"/>

Figure 4. Management Module

- **Status:** Indicates the SMM operating status.
 - **SMM Reboot:** Warm reboot the SMM
 - **Reset to Default:** Restored the SMM settings to out-of-factory default
- **Firmware version:** The current firmware version
- **Boot-up Flash:** Indicates SMM current boot up bank. In normal operation, **Boot-up flash** should always be **First**. Only when the first flash has a hardware or firmware failure, SMM will switch to 2nd flash.
- **ID LED:** Identification LED (ID LED) is a blue LED to assist user in locating enclosure in rack. User can choose to turn the blue LED solid on or make the LED blink once every second. Click **Apply** to activate the option.
- **Error LED:** Error LED is on when critical event occurs. It will be turned off after the critical event is deasserted.
- **FFDC:** The Fast Failure Data Collection (FFDC) instantly collects information about events and conditions that might lead up to a failure. Click **Capture**, the file used to analyze the problem can be downloaded from the web.

Current PSU

Current PSU: Indicates the status of power supplies



Current PSU - ZeroOutput Enabled, Total power bank = 2000W

PSU	Status	Ratings	AC-IN	Capability	Zero-Out	EPOW	Throttle	DC-PG
PSU1	Present	2000 W	212 V	2000 W	Wake Up	Normal	Normal	Yes
PSU2	Present	2000 W	0 V	0 W	Disabled	Assert	Normal	No

Figure 5. Current PSU

- **Status**

- **Present:** The power supply is installed.
- **Not Present:** No power supply is installed.
- **Fault:** The power supply is in faulty condition.

- **Ratings:** Displays the power rating such as 1100 W, 1600 W and 2000 W power supplies.

- **AC-IN:** AC input power

- **Capability:** The maximum DC output power that the power supply can provide to the entire system.

- If DC-PG of the PSU is **No**, capability will be 0 W.
- If DC-PG of the PSU is **Yes**, capability is usually equal to its rating.

Notes: The following status are exceptions.

- Rating 1100W PSU supports low line, capability will be 900W (AC-IN < 100V), 1050W (100 V <= AC-IN < 170V) or 1100W (170V <= AC-IN)
- If two PSUs are mismatched, capability will be lower one.

- **Zero-output:** Redundancy mode

- **Disabled:** Zero-output is disabled.
- **Wake-Up:** Zero-output is enabled. The power supply is in working state.
- **Sleep:** Zero-output is enabled. The power supply is in hibernate state and no DC output.

- **EPOW (Early power off warning)**


- **Assert:** The power supply is in AC lost condition.
- **Normal:** The power supply AC is in normal operating condition.

- **DC-PG (Direct current - power good):** The DC power status of the power supply.

- **No:** The power supply is not providing the required DC power.
- **Yes:** The power supply is providing required DC power.

Fan

Fan: Indicates the status of fans.



Fan

Bay	Status	Type	Bay	Status	Type
2	Present	60mm	1	Present	80mm
3	Present	60mm	5	Present	80mm
4	Present	60mm			

Figure 6. Fan

- **Status**
 - **Present:** The fan is in normal operating condition.
 - **Not present:** No fan installed.
 - **Fault:** The fan is in faulty condition.
- **Type:** There are two types of fans, 60mm and 80mm.

Power

There are five major sections under **Power** tab.



Figure 7. Power tab

- **Power Overview:** Displays the enclosure level power consumption, the node level power consumption, and power consumption of subsystems, which includes power subsystem (PSUs), and thermal subsystem (System fans).
- **PSU Configuration:** Allows users to set the redundancy mode for power supplies.
- **Power Cap:** Allows users to set power capping/saving.
- **Voltage Overview:** Monitors the voltage rail on SMM.
- **Power Restore Policy:** Allows user to enable power restore policy.

Power Overview

Power Overview displays the enclosure level power consumption, the node level power consumption, and power consumption of subsystems, which includes power subsystem (PSUs), and thermal subsystem (System fans).

Power Overview

Total Enclosure Power Consumption (W_{ac}) in 30 seconds

Min. (W)	Avg. (W)	Max. (W)
188	188	190

Total PSUs Power Consumption in 30 seconds

Min. (W)	Avg. (W)	Max. (W)
33	37	42

Total Fans Power Consumption

5.11 W

Node Power Consumption (W_{dc})

Node	Min. (W)	Avg. (W)	Max. (W)	Node	Min. (W)	Avg. (W)	Max. (W)
03	Not Present	Not Present	Not Present	04	Not Present	Not Present	Not Present
01	45	45	49	02	91	91	92

Figure 8. Power Overview

The enclosure and PSU power consumption sampled every 1 second over 30 seconds period.

PSU Configuration

PSU Configuration allows users to set the redundancy mode for power supplies.

PSU Configuration

Redundancy Mode

Redundancy Mode	N + 1 ▼
Oversubscription Mode	OVS On ▼

Apply PSU Status

Zero Output

Zero Output	30 minutes (default) ▼
-------------	------------------------

Apply

Figure 9. PSU Configuration

1. **Redundancy Mode:** Offer two modes for user to choose.

- **Redundancy Mode**

- **No Redundancy:** System could be throttled or shut down if one or more power supplies are in faulty condition.
- **N+1:** There is one properly installed PSU as redundant power supply, so there is no impact to system operation or performance if any one of the PSUs is in faulty condition, given that Oversubscription mode is not enabled.

- **Over-subscription Mode: Oversubscription Mode** allows user to take advantage of the extra power from the redundant power supply when the power supplies are in healthy condition. When the redundancy fails, PSU will shut down within 1 second if system power loading is not corrected after the time limit. SMM takes the action of node throttling at such power emergency. Enclosure performance could be impacted even in redundancy mode if oversubscription is also enabled.

- Oversubscription is applied only with N+1 redundancy modes.
- When enabled with N+1, the total power available is equivalent to 1.2 single PSU capability.

- Click on **Apply** after choosing the redundancy and oversubscription mode from drop-down menu to activate.

2. **Zero Output:** Three scanning period are offered: 10/30/60 minutes. The shorter the scanning period, the faster SMM adjusts number of hibernate PSUs to optimize PSU efficiency when system load changes. With shorter scanning period, PSU are also turned on and off more frequently when system loading fluctuates, which could reduce PSU life. Disable zero output will keep all PSU always active. Click on **Apply** after choosing the scanning period from drop-down menu to apply selections.

Power Cap

You can choose the following two cap types through power cap configuration.

1. **Enclosure Power Cap**
2. **Node Power Cap**

Power cap allows user to set a wattage limit on power consumption. When applied on individual node, the node power consumption is capped at assigned level and when applied on enclosure, the whole enclosure

power consumption is capped. When power saving is enabled, individual node or all nodes (enclosure level) runs in throttling mode.

Power Cap Policy

Choose a power cap type : Enclosure Power Cap ▼

Enclosure Power Cap / Power Save

Enclosure	Power Cap	
All	<input checked="" type="checkbox"/> Enable <input style="width: 50px;" type="text" value="480"/> W (Range: 422 W ~ 496 W)	
	Power Save	
	<input type="radio"/> Disable <input type="radio"/> Enable	

APPLY

Figure 10. Enclosure Power Cap

Power Cap Policy

Choose a power cap type : Node Power Cap ▼

Node Power Cap / Power Save

Node	Power Cap		
<div style="border: 1px solid #3498db; padding: 2px; display: inline-block;">3 ▼</div>	Protective Power Cap		
	DISABLE		
	DISABLE		
	User Power Cap	User Define	<input type="checkbox"/> Enable <input style="width: 50px;" type="text" value="0"/> W (Range: 83 W ~ 168 W)
	Thermal	DISABLE	
Power Save			
<input type="radio"/> Disable <input type="radio"/> Enable			

Figure 11. Node Power Cap

1. Select **Enclosure Power Cap** or **Node Power Cap** from the drop-down menu.
2. Enter a power cap value, check the box, and click on **Apply** to enable power cap.
3. Power cap enabled (checked) or disabled (unchecked) can be applied independent of power cap value. However, if power cap is enabled without any input value, the text box will be empty to represents that no user power cap value is specified and no power cap is enforced. If a value is entered and applied without enable ticked, the value will be saved but not enforced.

4. Power cap value is limited in the range from minimum to maximum possible power consumption of the node / enclosure.
5. There are three types of power cap for Node domain. User can set **User Power Capping** value for each node.
6. Select enable in the **Power Save** section and click on **Apply** to activate power save.
7. Power save can be applied with power cap simultaneously.
8. The following table provides details about saving modes.

Table 1. Saving Mode

Mode	Title	Description
Disable	Static maximum performance	The system runs at full speed (no throttling) regardless of the workload
Enable	Static minimum power	The system runs in a throttled state (defined by the implementation) regardless of the workload

Voltage Overview

Voltage Overview table provides the status of SMM board (12V, 5V, 3.3V, 2.5V, 1.2V, 1.15V) and battery voltage. Error log is asserted if critical threshold is reached.

Note: The auto refresh is 30 seconds.

Probe List

Status	Probe Name	Reading	Lower Non-Critical	Upper Non-Critical	Lower Critical	Upper Critical	Lower Non-Recoverable	Upper Non-Recoverable
✔	12V_SENSE	12.155 V	11.700 V	12.675 V	10.595 V	13.195 V	N/A	N/A
✔	5V_SENSE	4.9256 V	4.5028 V	5.4088 V	4.0196 V	5.4994 V	N/A	N/A
✔	3V3_SENSE	3.3582 V	2.9754 V	3.5670 V	2.6448 V	3.5366 V	N/A	N/A
✔	2V5_SENSE	2.5155 V	2.2446 V	2.6961 V	1.9995 V	2.7477 V	N/A	N/A
✔	1V2_SENSE	1.2040 V	1.0850 V	1.2950 V	0.9590 V	1.3230 V	N/A	N/A
✔	1V15_SENSE	1.1550 V	1.0360 V	1.2390 V	0.9170 V	1.2740 V	N/A	N/A
✔	VBAT_SENSE	3.1376 V	N/A	N/A	2.2472 V	N/A	N/A	N/A

Figure 12. Voltage Overview

Power Restore Policy

When **Power Restore Policy** is enabled as **Restore**, SMM remembers the latest node power status and recovers the node to the power status it was before AC is abruptly lost.

Power Restore Policy

<input checked="" type="checkbox"/>	Node	Status	<input type="checkbox"/>	Node	Status
<input checked="" type="checkbox"/>	03	Restore	<input type="checkbox"/>	04	Always OFF
<input checked="" type="checkbox"/>	01	Restore	<input type="checkbox"/>	02	Always OFF

Apply

Power Restore Policy: Determines the mode of operation after loss of power

Always off: Node remains off upon power restore

Restore: Node restores to the state it was before power failed

Figure 13. Power Restore Policy

Power Restore Policy: Determines the mode of operation after loss of power.

- **Always off:** Node remains off upon power restore.
- **Restore:** Node restores to the previous state that was before power failed.

1. Check the boxes of the nodes that needed to enable power restore policy.
2. Click **Apply** to activate the setting.

Note: The change of the setting and node status in power restore policy will take effect in 1 minute later; therefore, the node state might not be recovered on AC loss before it takes effect.

Cooling

There are three major sections under **Cooling** tab.

- **Cooling Overview:** System fan speed
- **PSU Fan Speed:** Power supply fan speed
- **Acoustic Mode:** Allow users to choose acoustic mode

Cooling Overview

Fan speed is displayed in RPM. Error log is asserted when fan speed is below lower critical threshold.

Note: This page will automatically refresh every 30 seconds.

Probe List

Status	Probe Name	Reading	Lower Non-Critical	Upper Non-Critical	Lower Critical	Upper Critical	Lower Non-Recoverable	Upper Non-Recoverable
	FAN_TACH_1A	2304 RPM	1024 RPM	N/A	768 RPM	N/A	N/A	N/A
	FAN_TACH_1B	2304 RPM	1024 RPM	N/A	768 RPM	N/A	N/A	N/A
	FAN_TACH_2A	2816 RPM	1024 RPM	N/A	768 RPM	N/A	N/A	N/A
	FAN_TACH_2B	2944 RPM	1024 RPM	N/A	768 RPM	N/A	N/A	N/A
	FAN_TACH_3A	2816 RPM	1024 RPM	N/A	768 RPM	N/A	N/A	N/A
	FAN_TACH_3B	2944 RPM	1024 RPM	N/A	768 RPM	N/A	N/A	N/A
	FAN_TACH_4A	2816 RPM	1024 RPM	N/A	768 RPM	N/A	N/A	N/A
	FAN_TACH_4B	2944 RPM	1024 RPM	N/A	768 RPM	N/A	N/A	N/A
	FAN_TACH_5A	2304 RPM	1024 RPM	N/A	768 RPM	N/A	N/A	N/A
	FAN_TACH_5B	2304 RPM	1024 RPM	N/A	768 RPM	N/A	N/A	N/A

Figure 14. Cooling Overview

- **Status** (two status):

- Healthy condition: 

- Fault condition: 

- **Fan_Tach_#A(B)**:

- When the number(#) equals to 2, 3 or 4, system fan speed normally operates at 2000 - 18500rpm.

- When the number(#) equals to 1 or 5, system fan speed normally operates at 2000 - 13000rpm.

D2 Enclosure system fan is equipped with dual motor. Tach A displays the primary fan motor speed and tach B displays the redundant fan motor speed.

- **Lower Critical:** 768 rpm is set to be the lower critical fan speed threshold.

PSU Fan Speed

PSU Fan Speed

PSU	Speed (RPM)	Duty (% of Max.)	Status
PSU1	5000	19%	Normal
PSU2	5000	19%	Normal

Figure 15. PSU Fan Speed

- **Speed:** PSU fan speed normally operates at 4000~23000 rpm. PSU fan speed is displayed in RPM.

- **Duty (% of Max.) :** Out of 25300 rpm. (23000*(1+10%))

- **Status:**

- **Normal:** PSU fan is running in healthy condition

- **Not Present:** No power supply is installed

- **Fault:** Fan speed is lower than the threshold (3000rpm)

Acoustic Mode

To reduce the noise level of the enclosure during run-time, you can configure the enclosure to five different acoustic modes.

Acoustic Mode Selection



Figure 16. Acoustic Mode Selection

1. Select the mode from the drop-down menu according to your preference.
 - **None:** Fan speeds change as required for optimal cooling
 - **Mode 1:** Highest acoustics attenuation (lowest cooling)
 - **Mode 2:** Higher acoustics attenuation
 - **Mode 3:** Intermediate acoustics attenuation
 - **Mode 4:** Low acoustics attenuation (higher cooling)
 - **Mode 5:** Aggressive cooling mode
2. Click on **Apply** after choosing the acoustic mode from the drop-down menu to activate the setting.

Notes:

- Acoustic modes can only apply to the entire enclosure as a whole
- When acoustic modes are applied, nodes workload is also capped to avoid over-heating
- If there is power or thermal demanding PCI card installed in the enclosure, acoustic mode is automatically disabled

System Information

There are six sections under **System information** tab and provide the fixed VPD data.

- **Enclosure VPD**
- **Power Distribution Module (PDM) VPD**
- **SMM VPD**
- **PSU VPD**
- **EIOM VPD**
- **PIOR Right/Left VPD**

Note: Information displayed with IPMI standard FRU command is limited to SMM Board VPD data only.

Enclosure VPD

Enclosure VPD

Name	Value
Enclosure Name	Lenovo ThinkSystem SD530 Server
Machine Type/Model	7X20CT01WW
UUID	8230F6F39B504491A4B423D96CD0C1DC
Enclosure Hardware Version	N/A

Backup Restore

Edit

Figure 17. Enclosure VPD

Note: The storage device can be a USB device or microSD card depends on your machine type.

- **Backup:** Save current enclosure name onto USB storage device for future migration
- **Restore:** Load the enclosure name from previously saved data on the USB storage device
- **Edit:** Modify the enclosure name based on following rule
 - Enclosure Name can be up to 64 characters using alphanumeric characters a-z, A-Z and 0-9, - (hyphen), _ (underscore), and space
- **Enclosure Name:** For example, “Lenovo ThinkSystem SR550 Server”
- **Machine Type:** For example, “7X125AJCCN”
- **UUID:** Randomly generated ID number of the enclosure
- **Enclosure Hardware Version:** Hardware version

PDM VPD

PDM VPD

Name	Value
Card UUID	4316EA6EE6B948B7AAF036A735EC8473
Card Hardware Version	Pass3

Backup Restore

Edit

Figure 18. PDM VPD

Note: The storage device can be a USB device or microSD card depends on your machine type.

- **Backup:** Save the current card serial number, card UUID, hardware version, and FRU part number onto the USB storage device for future migration
- **Restore:** Load the previously saved card serial number, card UUID, hardware version, and FRU part number data from the USB storage device
- **Edit:** Modify the card UUID as user preference based on following rule:
 - UUID: Card UUID must be filled in with all 32 alphanumeric characters (A-Z, 0-9). No space and no other characters allowed.

- **Card UUID:** Randomly generated ID number of the enclosure.
- **Card Hardware Version:** Hardware version.

SMM VPD

SMM VPD

Name	Value
Card Serial Number	00006360036
Card UUID	2C3D74E7E945493AAD7BA8B7B0017EBA
Card Hardware Version	Pass3
Card FRU Serial Number	N/A

Figure 19. SMM VPD

- **Card Serial Number:** The last 11 digits of a 8S bar code label on SMM. For example, 8SXXXXXXXXXXAAAABBBCCCC
- **Card UUID:** Randomly generated ID number of the enclosure
- **Card Hardware Version:** hardware version
- **Card FRU Serial Number:** The first 10 digits after “8S” of a 8S bar code label on SMM. For example, 8SXXXXXXXXXXAAAABBBCCCC

PSU VPD

PSU1 VPD

Name	Value
MFR Revision	0B
Type	CFFv3 1100W PT
Part Number	SP50L09207
FRU Number	01GV270
Serial Number	A1DB7111004
Header Code	A1DB
Vendor Name	ACBE
MFR Date	01(week)/17(year)
Primary FW Revision	4.51
Secondary FW Revision	84.51
MFR Model	FSF056
MFR Location	DB
Barcode	8SSP50L09207A1DB7111004

Figure 20. PSU VPD

- **MFR Revision:** Assembly revision
- **Type:** CFFv3 PSU type
- **Part Number:** Lenovo part number
- **FRU Number:** Lenovo FRU number
- **Serial Number:** The last 11 digits of a 8S bar code label on PSU. For example, 8SXXXXXXXXXXAAAABBBCCCC".

- **Header Code:** Lenovo header code
- **Vendor Name:** Vendor name
- **MFR Date:** Manufacturing date code (week/year)
- **Primary FW Revision:** Primary firmware revision
- **Secondary FW Revision:** Secondary firmware revision
- **MFR Model:** Vendor part number
- **MFR Location:** Manufacturer location
- **PSU FRU Number:** For example, "01GV270"
- **Barcode:** Lenovo barcode

EIOM VPD

EIOM VPD

Name	Value
Card Serial Number	00006360036
Card UUID	688471A276B311E68186AD3D4359E997
Card Hardware Version	Pass3
Card FRU Serial Number	N/A

Figure 21. EIOM VPD

- **Card Serial Number:** The last 11 digits of a 8S bar code label on EIOM. For example, 8SXXXXXXXXXXAAAABBBCCCC
- **Card UUID:** Randomly generated ID number of the enclosure
- **Card Hardware Version:** Hardware version
- **Card FRU Serial Number:** The first 10 digits after "8S" of a 8S bar code label on EIOM. For example, 8SXXXXXXXXXXAAAABBBCCCC

PIOR Right/Left VPD

PIOR Right VPD

Name	Value
Card Serial Number	00006360040
Card UUID	44FF6A1378EB11E687B4D1612BBB26D6
Card Hardware Version	Pass3
Card FRU Serial Number	N/A

PIOR Left VPD

Name	Value
Card Serial Number	00006360041
Card UUID	F31E17B57A6A11E6B3FF9E2FA5353282
Card Hardware Version	Pass3
Card FRU Serial Number	N/A

Figure 22. PIOR Right/Left VPD

- **Card Serial Number:** The last 11 digits of a 8S bar code label on PIOR. For example, 8SXXXXXXXXXX**AAAABBBCCCC**
- **Card UUID:** Randomly generated ID number of the enclosure
- **Card Hardware Version:** Hardware version
- **Card FRU Serial Number:** The first 10 digits after “8S” of a 8S bar code label on PIOR. For example, 8SXXXXXXXXXX**AAAABBBCCCC**

Event Log

Event log tab allow users to view SEL (System Event Log).

SEL logs enclosure level info/warning/critical events so that user can get some clues of what is going on in the enclosure. A maximum number of 4090 event entries can be logged.

By default, the latest entry is at the last page as events are sorted by occurring order from earliest in time to the latest. Click on **Date/Time** can reorder the sorting from latest to earliest event.

Note: Currently, new event cannot be written into the log when it is full. User needs to manually clear log before latest event can be logged.

Event Log

To sort system event logs, click the 'Date/Time'.

System Event Count (Current / Maximum) 8 / 4090

Event ID	Severity	Date/Time ↓	Description
0x21070841		2017-04-18 13:30:42 (UTC+0000)	NODE2_PRESENT: Slot Or Connector sensor, Informational was asserted
0x080707a5		2017-04-18 13:30:42 (UTC+0000)	PS2_EPDM: Power Supply sensor, Monitor was asserted
0x080701aa		2017-04-18 13:30:42 (UTC+0000)	PSU_Policy_Lost: Power Supply sensor, transition to Non-Critical from OK was asserted
0x086f03e1		2017-04-18 13:30:42 (UTC+0000)	PS2: Power Supply sensor, Power Supply input lost (AC/DC) was asserted
0x086f00e1		2017-04-18 13:30:42 (UTC+0000)	PS2: Power Supply sensor, Presence detected was asserted
0x086f00e0		2017-04-18 13:30:42 (UTC+0000)	PS1: Power Supply sensor, Presence detected was asserted
0x1d6f0030		2017-04-18 13:30:42 (UTC+0000)	SMM_POWER_ON: System Boot Initiated sensor, Initiated by power up was asserted
0x106f0202		2017-04-18 13:29:41 (UTC+0000)	EvLogDisabled: Event Logging Disabled sensor, Log Area Reset/Cleared was asserted

Figure 23. Event Log

- **Refresh:** SEL does not automatic refresh. User needs to manually click **Refresh** to get the latest entries.
- **Save Log:** Exports SEL data and save as .csv file
- **Clear Log:** Clears SEL data
- **Severity:** From low severity to high severity

-  : Indicates **Information** type of events
-  : Indicates **Warning** type of event
-  : Indicates **Critical** type of events. Critical event lits 'Error' LED.

For detailed event log messages, please see *Messages and Codes Reference* at <http://thinksystem.lenovofiles.com/help/index.jsp>.

Configuration

Configuration tabs settings are used to manage SMM module.




Figure 24. Configuration

There are twelve sections:

- **Firmware Update**
- **SMTP**
- **SNMP**
- **PEF**
- **Network Configuration**
- **Time Setting**
- **User Account**
- **Account Security**
- **Service**
- **Web Certificate**
- **NTP**

- **Backup and Restore**

Note: By pressing hardware reset button for more than 4 seconds, all settings (except **Time Setting**) can be restored to out-of-factory default settings.

Firmware Update

There are two phases to the firmware update process. During firmware upload stage, you can choose path to fetch the firmware image. SMM checks the image header information for validation.

Firmware Update

Upload

Select an image file and click upload. The upload process will terminate all other sessions. After the upload process is started, any attempt to refresh, logout or navigate away from the update page will restart the System.



Figure 25. Firmware Update

Upload

Select an image file and click upload. The upload process will terminate all other sessions. After the upload process is started, any attempt to refresh, logout or navigate away from the update page will restart the system.

Once a valid firmware image is uploaded, a firmware image confirmation table appears with **Preserve Settings** check box. If **Preserve Settings** is checked, SMM configurations are kept and applied after the firmware update. The preserved settings include:

- SMTP
- SNMP
- PEF
- Network Configuration
- Time Setting (Time is always kept no matter **Preserve Settings** is checked or not)
- User Account
- Account Security
- Services
- Web Certificate
- NTP

Notes:

1. A **Recover Primary Bank Firmware** check box is present in the firmware update page, but non-functional when SMM is boot up from the primary bank. If SMM starts on secondary bank, which indicates that the primary bank image might be corrupted and need recovery, this check box is open for selection. Check it to perform the recovery measure and update image onto the primary bank, and uncheck to upgrade firmware onto the secondary bank.
2. SMM will automatically restart if you choose to cancel firmware update process after uploading the firmware image.

Firmware Update

Upload

Select an image file and click upload. The upload process will terminate all other sessions. After the upload process is started, any attempt to refresh, logout or navigate away from the update page will restart the System.

Firmware File Path	<input type="text" value="Choose File"/> <code>firmimg.ast2520</code>	<input type="button" value="Upload"/>
--------------------	---	---------------------------------------

Firmware Image

Current Version	New Version	Preserve Settings	Recover Primary Bank Firmware
1.0 (TESM538)	1.0 (TESM538)	<input checked="" type="checkbox"/>	<input type="checkbox"/>

When primary bank firmware is broken, SMM automatically boot up from backup bank image. To update and recover primary bank image with a new image, check "Recover Primary Bank Firmware" during firmware update process when SMM is booted up from backup bank.

Upload is completed. Please click 'Update' to proceed firmware update or click 'Cancel' to terminate the update. System will be rebooted after Update/Cancel process.

<input type="button" value="Update"/>	<input type="button" value="Cancel"/>
---------------------------------------	---------------------------------------

Figure 26. Firmware Update

During updating, the system will direct you to a loading page where all SMM functions are locked.

Once the progress reaches 100%, SMM automatically restarts and you need to log in again to access SMM Web interface.

SMTP/SNMP/PEF

Configured SMTP and SNMP traps allow user to monitor the enclosure for selected events. SMTP/SNMP trap event types can be set in the PEF (Platform Event Filter) page.

SMTP

Before sending alert, please make sure changes to Sender Information, target Destination Email Address, SMTP (email) Server Settings, and SMTP Authentication have been saved by clicking Apply Changes.

Sender Information

From	<input type="text" value="lenovo-300@lenovo.com"/>
------	--

Destination Email Addresses

	Enable	Destination Email Address	Email Description	Test
Email Alert 1	<input type="checkbox"/>	<input type="text"/>	SNMP email alert	<input type="button" value="Send Alert 1"/>
Email Alert 2	<input type="checkbox"/>	<input type="text"/>	SNMP email alert	<input type="button" value="Send Alert 2"/>
Email Alert 3	<input type="checkbox"/>	<input type="text"/>	SNMP email alert	<input type="button" value="Send Alert 3"/>
Email Alert 4	<input type="checkbox"/>	<input type="text"/>	SNMP email alert	<input type="button" value="Send Alert 4"/>

SMTP (email) Server Settings

SMTP IP Address	<input type="text" value="0.0.0.0"/>
SMTP Port Number	<input type="text" value="25"/>

SMTP Authentication

Enable	<input type="checkbox"/> Anonymous account will be used when authentication is disabled.
Username	<input type="text"/>
Password	<input type="password"/>
STARTTLS Mode	<input type="text" value="AUTO"/>
SASL Mode	<input type="text" value="AUTO"/>

Figure 27. SMTP

- **SMTP:** You can enable, configure and test SMTP email alert at this page.

- Click **Send Alert #** to test the email alert
- Please check **Global Alerting Enable** in PEF page to enable email alerts
- The following information provides the default values:
 - All email alert disabled
 - Email server address = 0.0.0.0
 - Authentication disabled

Notes:

1. Before sending alert, make sure changes to **Sender Information, Destination Email Address, SMTP (email) Server Setting, and SMTP Authentication** have been saved by clicking **Apply**.
2. When SMM SEL is full, no new event entry can be added to SEL. SMTP event email will not be generated until the log is cleared.

SNMP

Before sending test trap, please make sure changes to the target Destination and Community String have been saved by clicking Apply Changes.

IP Destination List

Destination	Enable	IPv4/IPv6	IP Address	Test
IP Destination 1	<input checked="" type="checkbox"/>	* @	0.0.0.0	Send Test Trap
IP Destination 2	<input type="checkbox"/>	* @	0.0.0.0	Send Test Trap
IP Destination 3	<input type="checkbox"/>	* @	0.0.0.0	Send Test Trap
IP Destination 4	<input type="checkbox"/>	* @	0.0.0.0	Send Test Trap
IP Destination 5	<input type="checkbox"/>	* @	0.0.0.0	Send Test Trap
IP Destination 6	<input type="checkbox"/>	* @	0.0.0.0	Send Test Trap
IP Destination 7	<input type="checkbox"/>	* @	0.0.0.0	Send Test Trap
IP Destination 8	<input type="checkbox"/>	* @	0.0.0.0	Send Test Trap

Community String

Community Name: public

Figure 28. SNMP

- **SNMP:** You can enable, configure and test SNMP trap at this page.
 - Click **Send Test Trap** to test the event trap
 - **Community Name** displays/configures the SNMP community name using only alphabet and numerical values. The value must not be empty.
 - All the events would be sent to destination IP address when **Global Alerting Enable** in PEF page is checked.
 - For SNMP trap type, check the **Generate PEF** box for targeted type of events.

Notes:

1. Before sending test trap, make sure changes to the target **Destination** and **Community String** have been saved by clicking **Apply**.
 2. When SMM SEL is full, some PEF alerts might be missing or be sent repeatedly.
- The following information provides the default values:
 - All traps disabled
 - Community Name = public

PEF

Platform Event Filters (PEF) List

Global Alerting Enable Note: This enables/disables both PEF and email alerts.

Filter Name	Generate PET
All Type, Voltage Critical Filter	<input type="checkbox"/>
All Type, Fan Critical Filter	<input type="checkbox"/>
All Type, Power Supply Critical Filter	<input type="checkbox"/>
All Type, Event Logging Disabled Critical Filter	<input type="checkbox"/>
All Type, Module Or Board Critical Filter	<input type="checkbox"/>
All Type, Chassis Critical Filter	<input type="checkbox"/>
All Type, Slot Or Connector Critical Filter	<input type="checkbox"/>
Threshold Type, Fan Informational Filter	<input type="checkbox"/>

Figure 29. PEF

- **PEF:** You can set SMTP/SNMP trap event types at this page.
 - The following information provides the default values:
 - None of the filter selected
 - Global Alerting unchecked

Network Configuration

You can modify networking parameters in **Network configuration**.

You can modify following networking parameters in **Network configuration** section:

- Host Name
- DNS Domain Name
- Auto Negotiation Mode
- Network Speed
- Duplex Mode
- IP Version (IPv4, IPv6) Enable/Disable
- IP Address
- IP Source (Static, DHCP first then Static)
- Gateway
- Subnet Mask
- DNS Server
- VLAN

Network Configuration

General Settings

To change the Network settings may change IP address settings.
Each change to settings may cause a loss in connectivity and the termination of all sessions.
Changes may not take effect immediately.

Host Name	<input type="text" value="S006-00C0A8129977"/>
DNS Domain Name	<input type="text" value="lenovo.com"/>

Advance Settings

Please click on eth0 below to further configure SMM network settings.

Name	IPv4 Enabled	IPv4 Address	IPv6 Enabled	IPv6 Address
eth0	Enabled	10.241.66.187	Disabled	:::0

Figure 30. Network Configuration

General Settings

To change the Network settings may change IP address settings. Each change to settings may cause a loss in connectivity and the termination of all sessions. Changes may not take effect immediately.

Default settings for **Network configuration**:

- Host Name: SMM- $\$$ MAC_ADDR
- DNS Domain Name: lenovo.com

Network Interface Configuration Refresh Back

Network Interface Settings
To change the Network Interface Configuration will require IP address settings.
Each change to settings may cause a loss in connectivity and the termination of all sessions.
Changes may not take effect immediately.

Device Type	Dedicated
MAC Address	00:c0:a8:12:99:77
Auto Negotiation	<input checked="" type="radio"/> On <input type="radio"/> Off
Network Speed	1000 Mb
Duplex Mode	<input checked="" type="radio"/> Full <input type="radio"/> Half

General Settings

Enable Dynamic DNS	<input type="checkbox"/>
Use DHCP for DNS Domain Name	<input type="checkbox"/>
Respond to ARP	<input checked="" type="checkbox"/>

Figure 31. Network Interface Configuration

Click on the item of **Network Interface Configuration** leads to the detail network settings.

Default settings for **Network Interface Configuration**:

- Auto Negotiation: On
- Dynamic DNS: Unchecked
- Use DHCP for DNS Domain Name: Unchecked
- Respond to ARP: Checked

IPv4 Settings

Enabled	<input checked="" type="checkbox"/>
Use DHCP first, then Static	<input checked="" type="checkbox"/>
IP Address	192.168.70.177
Subnet Mask	255.255.255.0
Gateway	192.168.70.1
Use DHCP to obtain DNS server addresses	<input type="checkbox"/>
Preferred DNS Server	0.0.0.0
Alternate DNS Server	0.0.0.0

Figure 32. IPv4 Settings

Default settings for **IPv4 Settings**:

- IPv4: Enabled
- Use DHCP first, then Static: Checked
- IP Address: 192.168.70.100
- Subnet Mask: 255.255.255.0

- Gateway: 192.168.70.1
- Preferred/Alternate DNS Server: Blank

IPv6 Settings

Enabled	<input checked="" type="checkbox"/>
Use DHCP	<input checked="" type="checkbox"/>
Use Stateless	<input checked="" type="checkbox"/>
IP Address 1	<input type="text" value=":::11/64"/>
IP Address 2	<input type="text" value="::/0"/>
Gateway	<input type="text" value="::"/>
Link Local Address	<input type="text" value="fe80::0a94:eff:fe2f:8fd0/64"/>
Use DHCP to obtain DNS server addresses	<input type="checkbox"/>
Preferred DNS Server	<input type="text" value="::"/>
Alternate DNS Server	<input type="text" value="::"/>

Figure 33. IPv6 Settings

Default settings for IPv6 Settings:

- IPv6: Enabled
- Use DHCP: Checked
- Use Stateless Address Auto-configuration: Checked
- IP Address 1: Blank (configured by user)
- IP Address 2: Blank (configured by user)
- Gateway: Blank (configured by user)
- Link Local Address: Converted from MAC address automatically
- Use DHCP to obtain DNS Server address: Unchecked
- Preferred/Alternate DNS Server: Blank (configured by user)

VLAN Settings

Enable VLAN ID	<input type="checkbox"/>
VLAN ID	<input type="text" value="0"/>
Priority	<input type="text" value="0"/>

Figure 34. VLAN Settings

Default settings for VLAN Settings:

- VLAN: Disabled

Time Setting

This page is used to configure system time.

Time Settings

Data and Time Settings

Date and Time:

August 2016							Time									
<<	<	Now			>	>>										
Su	Mo	Tu	We	Th	Fr	Sa	Hour									
31	1	2	3	4	5	6	0	1	2	3	4	5				
7	8	9	10	11	12	13	6	7	8	9	10	11				
14	15	16	17	18	19	20	12	13	14	15	16	17				
21	22	23	24	25	26	27	18	19	20	21	22	23				
28	29	30	31	1	2	3	Minute									
							:00	:05	:10	:15	:20	:25				
							:30	:35	:40	:45	:50	:55				
							Exact minutes:						9			
							Second									
							:00	:05	:10	:15	:20	:25				
							:30	:35	:40	:45	:50	:55				
							Exact seconds:						7			
							Select Date and Time									

Figure 35. Time Settings

Select date and time and apply. Once set, time is always kept even if user restores settings to default or uncheck **Preserve Setting** during the firmware update.

User Account

User Account page allows you to manage user roles.

There are three types of user roles:

- Administrator: Full access to all the web pages and can modify all the settings and configurations
- Operator: Full access to all the web pages except **User Account** page. Operator can only see its own account at the **User Account** page and no modification at the account page is allowed
- User: Full access and modification rights to all the pages except the following pages in **Configuration** tab: **SMTP/SNMP/PEF/Network Configuration/User Account/Web Service**. Only viewing right is allowed on these pages. Any modification is not allowed.

User Account

Refresh

User Account

To configure a particular user, click the User ID. If Password policy check is enabled, password strength checking will be enabled while updating user configuration.

Password Policy Check Enable

User ID	State	User Name	User Role	IPMI LAN Privilege
3	Enabled	USER	User	None

Apply

Figure 36. User Account page for User and Operator

User Account

To configure a particular user, click the **User ID**. If **Password policy check** is enabled, password strength checking will be enabled while updating user configuration.

The image shows **User Account** page for User and Operator:

Note: Password Policy Check Enabled by default. User name= USERID, Password = PASSWORD

Refresh

User Account

To configure a particular user, click the User ID. If Password policy check is enabled, password strength checking will be enabled while updating user configuration.

Password Policy Check Enable

User ID	State	User Name	User Role	IPMI LAN Privilege
1	Disabled		None	None
2	Enabled	USERID	Administrator	Admin
3	Disabled		None	None
4	Disabled		None	None
5	Disabled		None	None
6	Disabled		None	None
7	Disabled		None	None
8	Disabled		None	None
9	Disabled		None	None
10	Disabled		None	None
11	Disabled		None	None
12	Disabled		None	None
13	Disabled		None	None
14	Disabled		None	None
15	Disabled		None	None
16	Disabled		None	None

Figure 37. User Account - Administrator

The image shows **User Account** page for Administrator

Back

Password Policy

Password Policy Check Enabled Yes

General

User ID	2
Enable User	<input checked="" type="checkbox"/>
User Name	<input type="text" value="USERID"/>
Change Password	<input type="checkbox"/>
New Password	<input type="text"/>
Confirm New Password	<input type="text"/>

User Privileges

User Role	Administrator
IPMI LAN Privilege	Administrator

Figure 38. Password Policy

Click on one of the listed account leads to **User Configuration**. User can enable/disable/delete account, set user name, set/change password, and select user privileges here. When **Password Policy Check Enable** box is checked, account password needs to follow the password policy rule (at least 8 characters with numbers, letters, and a character)

Notes:

1. User assigns account user name in **User Name** field with up to 16 characters using alphanumeric characters a-z, A-Z and 0-9, - (hyphen) and _ (underscore). Click the **Apply Changes** button. If validation fails, the GUI displays an error message. Creating new user account with existing user name is not allowed.
2. User can set/change password in **New Password** field using up to 20 printable US-ASCII (Code: 33-126) characters. Password must contains characters from three of the following four categories:
 - English uppercase characters (A through Z)
 - English lowercase characters (a through z)
 - Base 10 digits (0 through 9)
 - Non-alphabetic characters (for example, !, \$, #, %)
 If validation fails, the GUI displays an error message.

Account Security

Advanced account security setting allows you to set different values for the following rules.

Items	Default settings
Minimum password length	10
Force user to change password on first access	Yes
Password expiration period (in days)	90
Password expiration warning period (in days)	5
Minimum password change interval (in hours)	24
Minimum password reuse cycle (0-10)	5
Maximum number of login failures	5
Lockout period after maximum login failures (in minutes)	60
Web inactivity session timeout (in minutes)	20

Services

You can configure different HTTPS ports for connection and enable/disable IPMI service state at **Services** page.

Services

Web Server

HTTPS Port Number	<input type="text" value="443"/>
Max Sessions	32
Active Sessions	2

IPMI

Enabled	<input checked="" type="checkbox"/>
---------	-------------------------------------

Figure 39. Services

Default settings for **Services**:

- HTTPS Port Number = 443.

Note: No default HTTP port 80

Web Certificate

The web certificate page displays current certificate information.

There are three buttons for user to **Generate Certificate Signing Request**, **Import a Signed Certificate** and **Generate Self-signed Certificate**.

Web Certificate

Generate CSR

Import Certificate

Generate Self Signed Certificate

Current Certificate

```
Serial Number          : E342C4FD23C3F21D

Subject Information:
Country Code (CC)     : US
State (S)              : NC
Locality (L)          : RTP
Organization (O)      : ThinkServer
Common Name (CN)      : www.lenovo.com

Issuer Information:
Country Code (CC)     : US
State (S)              : NC
Locality (L)          : RTP
Organization (O)      : ThinkServer
Common Name (CN)      : www.lenovo.com

Valid From             : 01 Jan 2013, 00:06:39 (UTC+0000)
Valid To               : 30 Dec 2022, 00:06:39 (UTC+0000)
```

Figure 40. Web Certificate

Subject Information:

- Country Code (CC) = US
- State (S) = NC
- Locality (L) = RTP
- Organization (O) = ThinkServer
- Common Name (CN) = www.lenovo.com

Issuer Information:

- Country Code (CC) = US
- State (S) = NC
- Locality (L) = RTP
- Organization (O) = ThinkServer
- Common Name (CN) = www.lenovo.com

Web Certificate

Generate Certificate Signing Request (CSR)

Common Name	<input type="text"/>
Organization Name	<input type="text"/>
Organization Unit	<input type="text"/>
Locality	<input type="text"/>
State Name	<input type="text"/>
Country Code	<input type="text" value="Afghanistan"/>
Email	<input type="text"/>

Figure 41. Generate Certificate Signing Request (CSR)

You can press the **Generate CSR** button to fill the certification request information and download the CSR. After that, you can send the CSR to a third-party certificate authority to apply for a digital identity certificate.

Web Certificate

Import a Signed Certificate

Uploading certificate will restart the web service, causing the termination of the current GUI session and temporary unavailability of the web server.

File Path	<input type="button" value="Choose File"/> No file chosen	<input type="button" value="Import Certificate"/>
-----------	---	---

Figure 42. Signed Certificate

Import a Signed Certificate

Uploading certificate will restart the web service, causing the termination of the current GUI session and temporary unavailability of the web server.

You can import the certificate when the CA responds with a signed certificate. Support importing certificate in PEM format. You can convert your DER certificate to PEM format by “openssl x509 -inform der -in certificate.cer -out certificate.pem”. After importing certificate you have to reconnect to the SMM web.

Web Self-signed Certificate

Generate Self-signed Certificate

Generating a self-signed certificate will restart the web service, causing the termination of the current GUI session and temporary unavailability of the web server.

Common Name	<input type="text"/>
Organization Name	<input type="text"/>
Organization Unit	<input type="text"/>
Locality	<input type="text"/>
State Name	<input type="text"/>
Country Code	<input type="text" value="Afghanistan"/>
Email	<input type="text"/>

Figure 43. Web Self-signed Certificate

Generate Self-signed Certificate

Generating a self-signed certificate will restart the web service, causing the termination of the current GUI session and temporary unavailability of the web server.

You can also generate a self-signed certificate by filling the information and pressing generate button at this page.

Network Time Protocol (NTP)

You can configure the network time protocol and time zone settings at NTP page.

NTP Time Settings

Use this page to configure the Network Time Protocol and Time Zone settings.

Network Time Protocol

Operation Mode	<input type="text" value="Disabled"/>
NTP Server 1	<input type="text"/>
NTP Server 2	<input type="text"/>
NTP Server 3	<input type="text"/>
Requested Mode's Update Frequency (minutes)	<input type="text" value="3"/>
Time Synchronization Method	<input checked="" type="radio"/> Step Mode <input type="radio"/> Slew Mode

Time Zone Setting

The Client Time Zone can be changed from modify the time zone of client operating system.

Use Server or Client Time Zone	<input checked="" type="radio"/> Server Time Zone <input type="radio"/> Client Time Zone
Server Time Zone	<input type="text" value="UTC"/> <input type="button" value="Select..."/> <input type="button" value="Set to UTC"/>

Figure 44. NTP Time Settings

In the NTP time settings, you can use the drop-down menu to change operation mode and enter NTP server address into the text boxes. In addition, you can set the update frequency and select the time

synchronization method. After changing the settings, click on the **Apply Changes** to save the configuration. To click **Sync Time Now** button will synchronize with server right now. For the time zone setting, you can select the server or the client time zone. The client time zone can be changed by modifying the time zone of client operation system.

Default settings for **NTP Time Settings**:

- Operation Mode: Disable
- Server Time Zone: UTC

Backup and Restore

Backup and Restore page allows you to backup and restore your data.

SMM Backup and Restore Configuration

Latest Network backup file time: Fri Jun 2 18:33:53 2017

Backup Configuration from Network

Apply

Restore from Network Backup Configuration

Choose File No file chosen

Apply

Latest storage device backup file time: Fri Jun 2 17:25:27 2017

Backup Configuration to storage device

Apply

Restore Configuration from storage device

Apply

Note: The storage device can be a USB device or microSD card depend on machine type.

Figure 45. SMM Recovery

User configurations are automatically saved when they are set or modified. User can backup the configuration from remote to local device or restore the configuration to remote from local device by network. If storage device is inserted and detected, it can be used for SMM to preserve and migrate SEL and user configurations. SMM only keeps the latest configuration file in storage device for backup and restore.

Note: The storage device can be a USB device or microSD card depends on your machine type. The size of the USB/microSD storage device should be larger than 1GB. The support file system is FAT32.

- **Backup:** Backup SEL and below enclosure configurations to local device or USB/microSD storage.
 - Power supply redundancy policy
 - Oversubscription mode
 - Zero Output
 - Enclosure capping/saving or node capping/saving
 - Acoustic Mode setting
 - Power restore policy

- The settings in configuration tabs
- **Restore:** Restore and apply the configurations stored in local device or USB/microSD to SMM.

Chapter 4. IPMI Command

The section provides detailed IPMI commands.

Name	NetFn	CMD	Request data / Response data	Comments
OEMCMD_GET_PSU_COLLECTED_DATA	0x32	0x90	<p>Request:</p> <p>Byte 1: Input type</p> <p>1: AC-IN</p> <p>2: PSU consumption</p> <p>3: System fan power</p> <p>Response:</p> <ul style="list-style-type: none"> • When AC-IN, PSU consumption <ul style="list-style-type: none"> – Byte 1: Completion code 0x00: successful – Byte 2: Sum of MIN AC-IN / (PSU consumption) LSB – Byte 3: Sum of MIN AC-IN / (PSU consumption) MSB – Byte 4: Sum of AVG AC-IN / (PSU consumption) LSB – Byte 5: Sum of AVG AC-IN / (PSU consumption) MSB – Byte 6: Sum of MAX AC-IN / (PSU consumption) LSB – Byte 7: Sum of MAX AC-IN / (PSU consumption) MSB • When FAN power <ul style="list-style-type: none"> – Byte 1: Completion code 0x00: successful – Byte 2: Sum of FAN Power (LSB) – Byte 3: Sum of FAN Power – Byte 4: Sum of FAN Power (MSB) 	<p>This command is used to show regularly collected Data from all PSU and system FAN.</p> <p>1 Unit = 1 W</p> <p>Note: Only FAN power unit using 10 mW = 0.01 W</p> <p>FAN total power = (MSB * 256 * 256) + (Byte2 * 256) + LSB) * (10 mW)</p> <p>AVG: average</p>

OEMCMD_GET_PSU_STATUS	0x32	0x91	<p>Request: None</p> <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful • Byte 2: PSU EPOW <ul style="list-style-type: none"> – Bit: 0-1 = PSU1-2 – 0: Not trigger – 1: Trigger • Byte 3: PSU THROTTLE <ul style="list-style-type: none"> – Bit: 0-1 = PSU1-2 – 0: Not trigger – 1: Trigger • Byte 4: PSU PRESENT <ul style="list-style-type: none"> – Bit: 0-1 = PSU1-2 – 0: Not present – 1: Present • Byte 5: PSU PWR GOOD <ul style="list-style-type: none"> – Bit: 0-1 = PSU1-2 – 0: Not power good – 1: Power good • Byte 6: EPOW OUT • Byte 7: THROTTLE OUT 	This command is used to show the PSU related register or Status (From PSOC) ZERO_WAKE_UP#
OEMCMD_GET_FAN_GPIO	0x32	0x94	<p>Request: None</p> <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Parameter out of range • Byte 2: FAN Present <ul style="list-style-type: none"> – One bit per FAN – LSB: FAN1 • Byte 3: FAN Error LED <ul style="list-style-type: none"> – One bit per FAN – LSB: FAN1 	

OEMCMD_SET_FAN_GPIO	0x32	0x95	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: FAN Error LED number (1-5) • Byte 2: Fan Error Led Function <ul style="list-style-type: none"> – 0: Led off – 1: Led on <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Parameter out of range 	
OEMCMD_GET_SYS_LED	0x32	0x96	<p>Request: None</p> <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful • Byte 2: System Locater LED <ul style="list-style-type: none"> – 0: Off – 1: On – 2: Blink • Byte 3: Check Log LED <ul style="list-style-type: none"> – 0: Off – 1: On 	<p>This command is used to get the SMM LED status.</p> <p>0: Off</p> <p>1: On</p> <p>2: Blink (Locater only)</p>
OEMCMD_SET_SYS_LED	0x32	0x97	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: LED type <ul style="list-style-type: none"> – 1: System Locater LED – 2: Check Log LED • Byte 2: Function <ul style="list-style-type: none"> – 0: Disable – 1: Enable – 2: Blink (System Locater only) <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Parameter out of range 	<p>This command is used to get the SMM LED status.</p> <p>0: Off</p> <p>1: On</p> <p>2: Blink (Locater only)</p>

OEMCMD_GET_NODE_POWER_READING	0x32	0x98	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Node number <ul style="list-style-type: none"> - 1: Node 1 - 2: Node 2 - 3: Node 3 - 4: Node 4 - 5: Enclosure <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> - 0x00: Successful - 0xC9: Parameter out of range - 0xD5: Current not support (Node absent) • Byte 2: Power minimum (LSB) • Byte 3: Power minimum (MSB) • Byte 4: Power average (LSB) • Byte 5: Power average (MSB) • Byte 6: Power maximum (LSB) • Byte 7: Power maximum (MSB) 	Display the node power consumptions update by XCC.(Unit: Watt)
OEMCMD_GET_NODE_SIZE	0x32	0x99	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Node 1 - 4 <ul style="list-style-type: none"> - 1: Node 1 - 2: Node 2 - 3: Node 3 - 4: Node 4 <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> - 0x00: Successful - 0xC9: Parameter out of range - 0xD5: Current not support (Node absent) • Byte 2: Node Physical Width • Byte 3: Node Physical Height • Byte 4: Add-on Valid • Byte 5: Add-on Width 	Displays dimensions of node

			<ul style="list-style-type: none"> • Byte 6: Add-on Height 	
OEMCMD_SET_ACOUSTIC_MODE	0x32	0x9B	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Acoustic mode <ul style="list-style-type: none"> – 0: Disable – 1: Mode 1 Enable – 2: Mode 2 Enable – 3: Mode 3 Enable – 4: Mode 4 Enable – 5: Mode 5 Enable <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0x01: PCIe priority high – 0xC9: Out of range 	<ul style="list-style-type: none"> • 0x0 = Disable • 0x1 = Mode 1 Enable <ul style="list-style-type: none"> – System FAN duty range 5% - 20%. • 0x2 = Mode 2 Enable <ul style="list-style-type: none"> – System FAN duty range 5% - 25%. • 0x3 = Mode 3 Enable <ul style="list-style-type: none"> – System FAN duty range 5% - 30%. • 0x4 = Mode 4 Enable <ul style="list-style-type: none"> – System FAN duty range 5% - 45%. • 0x5 = Mode 5 Enable <ul style="list-style-type: none"> – System FAN duty range 30% - 100%. Add 20% more duty to normal duty.

OEMCMD_GET_CAP_BOUNDARY	0x32	0x9D	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Node number <ul style="list-style-type: none"> – 1: Node 1 – 2: Node 2 – 3: Node 3 – 4: Node 4 – 5: Enclosure <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Parameter out of range – 0xD5: Current not support (Node absent) • Byte 2: Capping Min LSB • Byte 3: Capping Min MSB • Byte 4: Capping Max LSB • Byte 5: Capping Max MSB • Byte 6: Protective Capping LSB • Byte 7: Protective Capping MSB • Byte 8: User Capping LSB • Byte 9: User Capping MSB • Byte 10: Thermal Capping LSB • Byte 11: Thermal Capping MSB 	<p>Node Capping Range:</p> <p>(Node minimum power capacity) < Cap < (Node max power capacity)</p> <p>Enclosure Capping Range:</p> <p>(Sum of Node minimum power capacity) < Cap) The minimum power should consider the permission pass nodes.</p> <p>Note: Capping will only be applied in OS-runtime. The configuration of enclosure level current capping is not the same behavior with sum of node level</p>
OEMCMD_SET_CAP_VALUE	0x32	0x9E	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Node number <ul style="list-style-type: none"> – 1: Node 1 – 2: Node 2 – 3: Node 3 – 4: Node 4 – 5: Enclosure • Byte 2: Capping Value (LSB) • Byte 3: Capping Value (MSB) <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Parameter out of range 	<p>Note: Capping / Saving not support when node with no permission</p> <p>Capping value range: 1 - 32767</p>

			<ul style="list-style-type: none"> - 0xD5: Current not support (Node absent) 	
OEMCMD_SET_CAP_STATE	0x32	0x9F	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Node number <ul style="list-style-type: none"> - 1: Node 1 - 2: Node 2 - 3: Node 3 - 4: Node 4 - 5: Enclosure • Byte 2: Capping mode <ul style="list-style-type: none"> - 0: Disable - 1: Enable • Byte 3: Saving mode <ul style="list-style-type: none"> - 0: Disable - 1: Saving mode 1 <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> - 0x00: Successful - 0xC9: Parameter out of range - 0xD5: Current not support (Node absent) 	<p>Note: Capping / Saving not supported when node with no permission.</p>

OEMCMD_GET_CAP_STATE	0x32	0xA0	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Node number <ul style="list-style-type: none"> – 1: Node 1 – 2: Node 2 – 3: Node 3 – 4: Node 4 – 5: Enclosure <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Parameter out of range – 0xD5: Current not support (Node absent) • Byte 2: Capping mode <ul style="list-style-type: none"> – 0: Disable – 1: Enable • Byte 3: Capping Value LSB • Byte 4: Capping Value MSB • Byte 5: Saving mode <ul style="list-style-type: none"> – 0: Disable – 1: Saving mode 1 	Saving mode does not support 2, 3
OEMCMD_SET_DATE_TIME	0x32	0xA1	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Year MSB(2000~2037) • Byte 2: Year LSB (2000~2037) • Byte 3: Month (0x01~0x12) • Byte 4: Date (0x01~0x31) • Byte 5: Hour (0x00~0x23) • Byte 6: Minute (0x00~0x59) • Byte 7: Second (0x00~0x59) <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Out of range 	<p>Note: Year is from 2000~20xx for user input convenient, the input data is decimal format. Example: Year 2010 Byte 1 : 0x20 Byte 2: 0x10</p>

OEMCMD_GET_PSU_POLICY_OVS	0x32	0xA2	<p>Request: None</p> <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful • Byte 2: PSU Policy <ul style="list-style-type: none"> – 0: No Redundant – 1: N+1 Policy • Byte 3: Oversubscription Mode <ul style="list-style-type: none"> – 0: Disable – 1: Enable 	<p>This command is used to get PSU policy and total power bank. (Unit :1W)</p> <p>AC high line or 240VDC:</p> <ul style="list-style-type: none"> • 1320W for 1100W PSU • 1920W for 1600W PSU • 2400W for 2000W PSU <p>AC low line:</p> <ul style="list-style-type: none"> • 1080W for 1100W PSU (<100VDC) • 1260W for 1100W PSU (<170VDC) • NA for 1600W PSU • NA for 2000W PSU
OEMCMD_SET_PSU_POLICY_OVS	0x32	0xA3	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: PSU Policy <ul style="list-style-type: none"> – 0: No Redundant – 1: N+1 Policy • Byte 2: OVS <ul style="list-style-type: none"> – 0: Disable – 1: Enable <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xD5: PSU configure not allow – 0xC9: Out of range • Byte 2: Completion code <ul style="list-style-type: none"> – 0x00: REDUNDANT_OK – 0x01:REDUNDANT_PRESENT_ERR – 0x02:REDUNDANT_BANK_LACK 	<p>This command is used for set PSU policy.</p> <p>We may not set the PSU policy successful due to configuration invalid.</p>

OEMCMD_SET_NODE_RESET	0x32	0xA4	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Node number <ul style="list-style-type: none"> – 0x1: Node 1 – 0x2: Node 2 – 0x3: Node 3 – 0x4: Node 4 • Byte 2: Reset mode <ul style="list-style-type: none"> – 1: reset (XCC reset) – 2: resear (AC cycling) <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Parameter out of range – 0xD5: Current not support (Node absent) 	<p>This command is used for Reset/ Reseat node by user. If node not present, it would response 0xD5</p>
OEMCMD_GET_PSU_FAN_STATUS	0x32	0xA5	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: PSU FAN number <ul style="list-style-type: none"> – 1: PSU1 FAN – 2: PSU2 FAN <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Out of range • Byte 2: FAN Speed LSB (rpm) • Byte 3: FAN Speed MSB (rpm) • Byte 4: FAN duty (0~100%) • Byte 5: FAN status <ul style="list-style-type: none"> – 0 : Not Present – 1 : Abnormal – 2 : Normal 	<p>This command is used to get PSU FAN status</p> <p>Note: Ab-Normal means PSU rpm is lower than 3000 rpms.</p>

OEMCMD_BACKUP_RESTORE	0x32	0xA6	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Actions <ul style="list-style-type: none"> – 0 : Get Backup or Restore Status – 1 : Backup to storage device – 2 : Restore from storage device <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: <ul style="list-style-type: none"> – 0x00 : BACKUP RESTORE OK – 0x01: BACKUP RESTORE RUNNING – 0x30: SD DEVICE NOT EXIST – 0x31: SD BACKUP FINISHED – 0x32: SD BACKUP FAIL – 0x41: SD RESTORE FINISHED – 0x42: SD RESTORE FAIL – 0xC9: Out of range – 0xCC: Invalid data field in request 	This command is used to backup/restore configuration to/from external storage device such as USB or SD. If the storage device is not inserted, it will return fail.
OEMCMD_GET_NODE_STATUS	0x32	0xA7	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Node number <ul style="list-style-type: none"> – 0x1: Node 1 – 0x2: Node 2 – 0x3: Node 3 – 0x4: Node 4 <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Parameter out of range – 0xD5: Current not support (Node absent) • Byte 2: Node power state <ul style="list-style-type: none"> – 0x00: Power OFF – 0x20: No Permission – 0x40: Power Fault – 0x80: Power ON • Byte 3: Width 	Report current node status.

			<ul style="list-style-type: none"> • Byte 3: Width • Byte 5: Permission state <ul style="list-style-type: none"> – 0x00: First permission fail – 0x01: Permission to standby – 0x02: Second permission fail – 0x03: Permission pass (Secondary boot pass) – 0xFF: Permission not decide 	
OEMCMD_GET_SMM_STATUS	0x32	0xA8	<p>Request: None</p> <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful • Byte 2: SMM version • Byte 3: SMM minor version • Byte 4: PSOC major version • Byte 5: PSOC minor version • Byte 6: Boot Flash number <ul style="list-style-type: none"> – 0x1: flash 1 – 0x2: flash 2 (fail over) • Byte 7: 13: SMM build ID 	The build ID is using ASCII value. For example, 0x41 = 'A'
OEMCMD_SET_NODE_RESTORE_POLICY	0x32	0xA9	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Node policy <ul style="list-style-type: none"> – Bit [7:6]: Node 4 (1: Last state, 0: Off) – Bit [5:4]: Node 3 – Bit [3:2]: Node 2 – Bit [1:0]: Node 1 <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Parameter out of range 	

OEMCMD_GET_NODE_RESTORE_POLICY	0x32	0xAA	<p>Request: None</p> <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful • Byte 2: Node policy <ul style="list-style-type: none"> – Bit [7:6]: node 4 (1:last state, 0:off) – Bit [5:4]: node 3 – Bit [3:2]: node 2 – Bit [1:0]: node 1 	
OEMCMD_SET_PSU_SMART_REDUNDANT	0x32	0xAB	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Mode <ul style="list-style-type: none"> – 0 : disable – 1: per 10 minutes update – 2: per 30 minutes update – 3: per 60 minutes update <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0x01: Not Support – 0xC9: Out of range 	If PSU in “not support” or “mismatch “stage, the PSU smart redundant also not support.
OEMCMD_GET_PSU_SMART_REDUNDANT	0x32	0xAC	<p>Request: None</p> <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful • Byte 2: status <ul style="list-style-type: none"> – 0x00: Normal – 0x01: Not support • Byte 3: mode (When status is normal) <ul style="list-style-type: none"> – 0 : disable – 1: per 10 minutes update – 2: per 30 minutes update – 3: per 60 minutes update 	<p>Status:</p> <ul style="list-style-type: none"> • 0x00: Normal • 0x01: Not support
OEMCMD_SMM_RESET_TO_DEFAULT	0x32	0xAD	<p>Request: None</p> <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful 	This command is used to reset SMM to default value.

OEMCMD_GET_VPD	0x32	0xB0	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: VPD type <ul style="list-style-type: none"> – 0: SMM – 1: PDM – 2: RH Riser – 3: LH Riser – 4: EIOM – 5: Enclosure • Byte 2: Device ID <ul style="list-style-type: none"> – 0: MTM – 1: Machine serial number – 2: Component part number Level – 3: Component FRU number – 4: Component serial number – 5: Manufacture ID – 6: Hardware revision – 7: Manufacture date – 8: UUID – 9: IANA enterprise number – A: Product ID – B: Component name – C: GLID – D: EC level <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful • Byte 2: N VPD Data 	<p>Read Only</p> <p>Device ID:</p> <ul style="list-style-type: none"> • 0x0: MTM (Enclosure), 10 Bytes • 0x1: Machine serial number (Enclosure), 10 Bytes. • 0x2: Component part number (SMM, PDM, PIOR, EIOM), 12 Bytes. • 0x3: Component FRU number (SMM, PDM, PIOR, EIOM), 12 Bytes. • 0x4: Component serial number (SMM, PDM, PIOR, EIOM), 12 Bytes. • 0x5: Manufacture ID (Enclosure, SMM), 4 Bytes. • 0x6: Hardware revision level (SMM, PDM, PIOR, EIOM, Enclosure), 1 Byte. • 0x7: Manufacture date (SMM, PDM, PIOR, EIOM, Enclosure), 4 Bytes. • 0x8: Universal Unique ID (UUID) (SMM, PDM, PIOR, EIOM, Enclosure), 16 Bytes. • 0x9: IANA enterprise number (Enclosure), 4 Bytes. • 0xA: Product ID (Enclosure), 2 Bytes. • 0xB: Component name (SMM, PDM, PIOR, EIOM, Enclosure), 64 Bytes.
----------------	------	------	--	---

				<ul style="list-style-type: none"> • 0xC: Global Identifier (GLID) (Enclosure), 8 Bytes. • 0xD: EC level (SMM, PDM, PIOR, EIOM, Enclosure), 10 Bytes.
OEMCMD_GET_PSU_DATA	0x32	0xC3	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: PSU number <ul style="list-style-type: none"> – 1: PSU 1 – 2: PSU 2 <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Out of range • Byte 2: LSB of fan speed (rpm) • Byte 3: MSB of fan speed (rpm) • Byte 4: LSB of VIN (v) • Byte 5: MSB of VIN (v) • Byte 6: LSB of PSU type (w) • Byte 7: MSB of PSU type (w) 	This command is used to get PSU data.
OEMCMD_SET_SYSTEM_FAN_PWM	0x32	0xC4	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Duty (%) <ul style="list-style-type: none"> – 0 ~ 100 <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Parameter out of range 	Should disable automatic system FAN control first by OEMCMD_SET_SYSTEM_FAN_CONTROL (0x32, 0xC6)

OEMCMD_SET_SYSTEM_FAN_CTRL	0x32	0xC6	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: mode <ul style="list-style-type: none"> – 0: Disable automatic FAN control – 1: Enable automatic FAN control – 2: Put FAN in silent mode and disable automatic FAN control <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful 	
OEMCMD_GET_NODE_COOLING_VALUE	0x32	0xC7	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Node number <ul style="list-style-type: none"> – 1: Node 1 – 2: Node 2 – 3: Node 3 – 4: Node 4 <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful – 0xC9: Parameter out of range – 0xD5: Current not support (Node absent) • Byte 2: Cooling value <ul style="list-style-type: none"> – 0 - 100 	
OEMCMD_GET_WEB_STATE	0x32	0xF0	<p>Request: None</p> <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful • Byte 2: State <ul style="list-style-type: none"> – 0x00: Disabled – 0x01: Enabled 	
OEMCMD_SET_WEB_STATE	0x32	0xF1	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: State <ul style="list-style-type: none"> – 0x00: Disabled – 0x01: Enabled <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful 	

OEMCMD_GET_SECURITY_OPTION	0x32	0xFA	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Configuration type <ul style="list-style-type: none"> – 0x00: Minimum password length – 0x01: Force user to change password on first access – 0x02: Password expiration period (in days) – 0x03: Password expiration warning period (in days) – 0x04: Minimum password change interval (in hours) – 0x05: Minimum password reuse cycle – 0x06: Maximum number of login failures – 0x07: Lockout period after maximum login failures (in minutes) – 0x08: Web inactivity session time-out (in minutes) <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 0x00: Successful • Byte 2: Configuration setting (LSB) • Byte 3: Configuration setting (MSB) 	
OEMCMD_SET_SECURITY_OPTION	0x32	0xFB	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Configuration type <ul style="list-style-type: none"> – 0x00: Minimum password length – 0x01: Force user to change password on first access – 0x02: Password expiration period (in days) – 0x03: Password expiration warning period (in days) – 0x04: Minimum password change interval (in hours) 	

			<ul style="list-style-type: none"> - 0x05: Minimum password reuse cycle - 0x06: Maximum number of login failures - 0x07: Lockout period after maximum login failures (in minutes) - 0x08: Web inactivity session time-out (in minutes) • Byte 2: Configuration value (LSB) • Byte 3: Configuration value (MSB / Optional) <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> - 0x00: Successful - 0xc9: Parameter out of range 	
OEMCMD_SET_SMTP_CONFIG_PARAMETERS	0x32	0xB2	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Parameter selector • Byte 2: N - Configuration parameter data. Per "SMTP Configuration Parameters" on page 58. <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Generic codes plus <ul style="list-style-type: none"> - 0xC7: Request data length invalid - 0xC9: Parameter out of range - 0xCC: Invalid data field in request 	See "SMTP Configuration Parameters" on page 58 for parameter selector and data.

OEMCMD_GET_SMTP_CONFIG_PARAMETERS	0x32	0xB3	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Parameter selector • Byte 2: Set selector. (Selects a given set of parameters under a given Parameter selector value.) <ul style="list-style-type: none"> – 0x00: Parameter does not use a set selector. • Byte 3: Block selector <ul style="list-style-type: none"> – 0x00: Parameter does not require a block selector. <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Generic codes plus <ul style="list-style-type: none"> – 0xC7: Request data length invalid – 0xC9: Parameter out of range – 0xCC: Invalid data field in request • Byte 2: N - Configuration parameter data. See “SMTP Configuration Parameters” on page 58. 	
IPMICMD_SET_LAN_CONFIG_PARAM	0x0C	0x01	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Channel number • Byte 2: Parameter selector • Byte 3: Configuration parameter data. See “LAN Configuration Parameters” on page 61 <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 80h: Parameter not supported – 81h: Attempt to set the ‘set in progress’ value when not in the ‘set complete’ state. – 82h: Attempt to write read-only parameter – 83h: Attempt to read write-only parameter 	<p>The OEM parameters are added into parameter selector and data.</p> <p>(Byte 2: N)</p> <p>See “LAN Configuration Parameters” on page 61 for more details.</p>
IPMICMD_SET_LAN_CONFIG_PARAM	0x0C	0x02	<p>Request:</p> <ul style="list-style-type: none"> • Byte 1: Channel number • Byte 2: Parameter selector • Byte 3: Set Selector 	<p>The OEM parameters are added into parameter selector and data.</p> <p>(Byte 2: N)</p>

			<ul style="list-style-type: none"> – 00h: If parameter does not use a Set Selector • Byte 4: Block Selector <ul style="list-style-type: none"> – 00h: If parameter does not require a block number <p>Response:</p> <ul style="list-style-type: none"> • Byte 1: Completion code <ul style="list-style-type: none"> – 80h: Parameter not supported. • Byte 2: Parameter revision • Byte 3: N Configuration parameter data, see “LAN Configuration Parameters” on page 61 	See “LAN Configuration Parameters” on page 61 for more details.
--	--	--	--	---

SMTP Configuration Parameters

The following table is detail parameters for OEMCMD_SET_SMTP_CONFIG_PARAMETERS and OEMCMD_GET_SMTP_CONFIG_PARAMETERS.

Parameter Selector	Number	Parameter Data (non-volatile)
Sender Information	0	<p>Assigns the send from. The field is default filled with <host name>@<domain name> automatically. If the field is OEM set, it must follow the rules:</p> <ol style="list-style-type: none"> 1. Do not consist of only space characters. 2. It must be the combination of alphanumeric characters a-z, A-Z and 0-9, space characters, non-alphabetic characters. 3. The maximum length of the field is 254 characters. <ul style="list-style-type: none"> • Data 1: String length • Data 2: N – the sting of <host name>@<domain name>

Destination Email Addresses	1	<p>Data 1: Set selector = Field selector, 0 based.</p> <ul style="list-style-type: none"> • [7:2] - Reserved • [1:0] - Field selector <ul style="list-style-type: none"> - 00b: Field 1 - Enable/Disable - 01b: Field 2 - Destination Email Address - 10b: Field 3 - Email Description - 11b: Field 4 - Send Alert (Set only) <p>Data 2: Block selector = Target of Email Alert selector, 0 based.</p> <ul style="list-style-type: none"> • [7:2] - Reserved • [1:0] - <ul style="list-style-type: none"> - 00b: Email Alert 1 - 01b: Email Alert 2 - 10b: Email Alert 3 - 11b: Email Alert 4 <p>For Set selector = 0</p> <p>Data 3:</p> <ul style="list-style-type: none"> • [7:1] - reserved • [0] - <ul style="list-style-type: none"> - 0b: Disable - 1b: Enable <p>For Set selector = 1</p> <p>Data 3: String length, Max = 64.</p> <p>Data 4: N – the sting of Destination Email Address</p> <p>For Set selector = 2</p> <p>Data 3: String length, Max = 254.</p> <p>Data 4: N – the sting of Email Description</p>
SMTP (email) Server Settings	2	<p>Data 1: Set selector = Field selector, 0 based.</p> <ul style="list-style-type: none"> • [7:1] - reserved • [0] - Field selector <ul style="list-style-type: none"> - 0b: Field 1 - SMTP IP Address - 1b: Field 2 - SMTP Port Number <p>For Set selector = 0</p> <p>Data 2: String length, Max = 254.</p> <p>Data 3: N – the sting of IPV4, IPV6 or FQDN</p> <p>For Set selector = 1</p> <p>Data2:3: Port number. LS-byte first.</p>

SMTP Authentication	3	<p>Data 1: Set selector = Field selector, 0 based.</p> <ul style="list-style-type: none"> • [7:3] - reserved • [2:0] - Field selector <ul style="list-style-type: none"> - 000b: Field 1 - Enable/Disable - 001b: Field 2 - User name - 010b: Field 3 - Password (Set only) - 011b: Field 4 - STARTTLS Mode - 100b: Field 5 - SASL Mode - 101b:111b: Reserved <p>For Set selector = 0</p> <p>Data 2:</p> <ul style="list-style-type: none"> • [7:1] - Reserved • [0] <ul style="list-style-type: none"> - 0b: Disable - 1b: Enable <p>For Set selector = 1</p> <p>Data 2: String length, Max = 254.</p> <p>Data 3: N – the sting of user name</p> <p>For Set selector = 2</p> <p>Data 2: String length, Max = 254</p> <p>Data 3: N – the sting of password</p> <p>For Set selector = 3</p> <p>Data 2:</p> <ul style="list-style-type: none"> • [7:2] - Reserved • [1:0] <ul style="list-style-type: none"> - 00b: AUTO - 01b: OFF - 10b: ON - 11b: Reserved <p>For Set selector = 4</p> <p>Data 2:</p> <ul style="list-style-type: none"> • 000b: AUTO • 001b: PLAIN • 010b: LOGIN • 011b: NTLM • 100b: MD5 • 101b:111b: Reserved
---------------------	---	---

LAN Configuration Parameters

The following table is detail parameters for LAN configuration .

Parameter Selector	Number	Parameter Data (non-volatile)
Host Name	0xC3	BMC hostname <ul style="list-style-type: none">• Data 1: String length, Max = 63• Data 2: N – the sting of BMC hostname
DNS Domain Name	0xC4	DNS Domain Name Set operation implicates using static for DNS Domain Name. Note: The setting of Use DHCP for DNS Domain Name will be disabled <ul style="list-style-type: none">• Data 1: String length, Max = 237• Data 2: N – the sting of DNS Domain name

Index

A

- abstract 1
- account
 - security 31
- account security 31
- Acoustic
 - Mode 17
- Acoustic Mode 17

C

- Configuration 22
- Cooling 15
 - Overview 15
- Cooling Overview 15

E

- EIOM
 - VPD 20
- EIOM VPD 20
- enclosure
 - VPD 18
- Enclosure
 - front 7
 - overview 7–8
 - rear 8
- Enclosure Front Overview 7
- Enclosure Rear Overview 8
- enclosure VPD 18
- Event
 - Log 21
- Event Log 21

F

- Firmware 23
- front
 - enclosure 7

I

- Interface
 - Access 3
- Introduction 1
- IPMI Command 39

L

- LAN configuration parameters 61

N

- Network Configuration 26
- NTP 35

O

- Overview 5

P

- PDM
 - VPD 18
- PDM VPD 18
- PIOR
 - VPD 21
- PIOR Right/Left VPD 21
- power
 - capping 12
 - consumption 10
- Power 10
 - Restore
 - policy 14
- Power Capping 12
- Power consumption overview 10
- Power Restore Policy 14
- PSU
 - Configuration 11
 - fan
 - speed 16
 - VPD 19
- PSU Configuration 11
- PSU Fan Speed 16
- PSU VPD 19

R

- rear
 - enclosure 8

S

- server
 - cooling 15
- server power 10
- SMM
 - Recovery 36
- SMM Recovery 36
- SMM VPD 19
- SMMVPD 19
- SMTP Configuration Parameters 58
- SMTP/SNMP/PEF 24
- SMTPSNMP
 - PEF 24
- Summary 7
- system
 - information 17
- System information 17

T

- Time
 - Setting 28
- Time Setting 28

U

Update 23
User
 account 29
User Account 29

V

Voltage
 Overview 14
Voltage Overview 14

W

Web
 Certificate 32
 service 31
Web Certificate 32
Web Interface Access 3
Web Service 31



Part Number: SP47A24237

Printed in China

(1P) P/N: SP47A24237

