

SONY

4-579-661-14(1)



Blu-ray Disc™ / DVD Player

Operating Instructions

The software of this player may be updated in the future. To download any available updates and the Operating Instructions with advanced features, please visit the following website:

http://www.sony.com/bluraysupport/



BDP-S3700/BDP-BX370/BDP-S1700

WARNING


To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not expose batteries or appliances with battery-installed to excessive heat, such as sunshine and fire.

CAUTION

The use of optical instruments with this product will increase eye hazard. As the laser beam used in this Blu-ray Disc/DVD player is harmful to eyes, do not attempt to disassemble the cabinet. Refer servicing to qualified personnel only.



This label is located on the laser protective housing inside the enclosure.



- This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.
• This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Precautions

- The nameplate is located on the bottom of the unit.
• To prevent fire or shock hazard, do not place objects filled with liquids, such as vases, on the apparatus.
• Install this unit so that the AC adaptor can be unplugged from the wall socket immediately in the event of trouble.

For Customers in Canada

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement (BDP-S3700/BX370 only):

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body (excluding extremities: hands, wrists, feet and ankles).

Contains FCC ID : PPQ-WN4636R

Important Safety Instructions

- 1) Read these instructions.
2) Keep these instructions.
3) Heed all warnings.
4) Follow all instructions.
5) Do not use this apparatus near water.
6) Clean only with dry cloth.
7) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11) Only use attachments/accessories specified by the manufacturer.

- "BRAVIA" is a trademark of Sony Corporation.
- MPEG Layer-3 audio coding technology and patents licensed from Fraunhofer IIS and Thomson.
- This product incorporates proprietary technology under license from Verance Corporation and is protected by U.S. Patent 7,369,677 and other U.S. and worldwide patents issued and pending as well as copyright and trade secret protection for certain aspects of such technology. Cinavia is a trademark of Verance Corporation. Copyright 2004-2010 Verance Corporation. All rights reserved by Verance. Reverse engineering or disassembly is prohibited.
- Windows Media is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries. This product is protected by certain intellectual property rights of Microsoft Corporation. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft or an authorized Microsoft subsidiary. Content owners use Microsoft PlayReady™ content access technology to protect their intellectual property, including copyrighted content. This device uses PlayReady technology to access PlayReady-protected content and/or WMDRM-protected content. If the device fails to properly enforce restrictions on content usage, content owners may require Microsoft to revoke the device's ability to consume PlayReady-protected content. Revocation should not affect unprotected content or content protected by other content access technologies. Content owners may require you to upgrade PlayReady to access their content. If you decline an upgrade, you will not be able to access content that requires the upgrade.
- This product meets ENERGY STAR® guidelines for energy efficiency. ENERGY STAR and the ENERGY STAR mark are registered U.S. marks. ENERGY STAR is a registered mark owned by the U.S. government.
- Gracenet, the Gracenet logo and logotype, "Powered by Gracenet", Gracenet MusicID, Gracenet VideoID, and Gracenet Video Explore are either registered trademarks or trademarks of Gracenet, Inc. in the United States and/or other countries.



- Wi-Fi®, Wi-Fi Protected Access® and Wi-Fi Alliance® are registered trademarks of Wi-Fi Alliance.™
- Wi-Fi CERTIFIED™, WPA™, WPA2™, Wi-Fi Protected Setup™, Miracast™ and Wi-Fi CERTIFIED Miracast™ are trademarks of Wi-Fi Alliance.™
- The Wi-Fi CERTIFIED Logo is a certification mark of Wi-Fi Alliance.™
- The Wi-Fi Protected Setup Identifier Mark is a certification mark of Wi-Fi Alliance.™

12)Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



- 13)Unplug this apparatus during lightning storms or when unused for long periods of time.
14)Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Owner's Record

The model and serial numbers are located at the bottom of the unit. Record the serial number in the space provided below. Refer to them whenever you call upon your dealer regarding this product.

Model No. \_\_\_\_\_

Serial No. \_\_\_\_\_

For customers in the USA
If this product is not working properly, please call 1-800-222-SONY(7669).
For Customers in Canada
If this product is not working properly, please contact our Customer Information Service Center at 1-877-899-7669 or write to us at: Customer Information Service 115 Gordon Baker Road, Toronto, Ontario, M2H 3R6

- Copyrights and Trademarks
• Java is a trademark of Oracle and/or its affiliates.
• Manufactured under license from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories.
• For DTS patents, see http://patents.dts.com. Manufactured under license from DTS Licensing Limited. DTS, the Symbol, & DTS and the Symbol together are registered trademarks, and DTS 2.0+Digital Out is a trademark of DTS, Inc. © DTS, Inc. All Rights Reserved.



- The terms HDMI® and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.
- Blu-ray Disc™, Blu-ray™, BD-LIVE™, BONUSVIEW™, and the logos are trademarks of the Blu-ray Disc Association.
- "DVD Logo" is a trademark of DVD Format/Logo Licensing Corporation.
- "DVD+RW","DVD-RW","DVD+R","DVD-R," "DVD VIDEO," and "CD" logos are trademarks.

3

- DLNA™, the DLNA Logo and DLNA CERTIFIED™ are trademarks, service marks, or certification marks of the Digital Living Network Alliance.™



- Opera® Devices SDK from Opera Software ASA. Copyright 1995-2015 Opera Software ASA. All rights reserved.



- All other trademarks are trademarks of their respective owners.
- Other system and product names are generally trademarks or registered trademarks of the manufacturers.™ and ® marks are not indicated in this document.

\* BDP-S3700/BX370 only

Gracenet® End User License Agreement

This application or device contains software from Gracenet, Inc. of Emeryville, California ("Gracenet"). The software from Gracenet (the "Gracenet Software") enables this application or device to perform disc and/or file identification and obtain music- and/or video-related information, including name, artist, track, and title information ("Gracenet Data") from online servers or embedded databases (collectively, "Gracenet Servers"), and to perform other functions. You may use Gracenet Data only by means of the intended End-User functions of this application or device; the reception and display of the Gracenet Data on this application or device are not provided by Gracenet and falls solely within the responsibility and liability of the manufacturer hereof.

This application or device may contain content belonging to Gracenet's providers. If so, all of the restrictions set forth herein with respect to Gracenet Data shall also apply to such content, and said content providers shall be entitled to all of the benefits and protections that are available to Gracenet hereunder. You agree that you will use Gracenet Data, the Gracenet Software, and Gracenet Servers for your own personal, non-commercial use only. You agree not to assign, copy, transfer or transmit the Gracenet Software or any Gracenet Data to any third party. YOU AGREE NOT TO USE OR EXPLOIT GRACENET DATA, THE GRACENET SOFTWARE, OR GRACENET SERVERS EXCEPT AS EXPRESSLY PERMITTED HEREIN.

You agree that your non-exclusive license to use the Gracenet Data, the Gracenet Software, and Gracenet Servers will terminate if you violate these restrictions. If your license terminates, you agree to cease any and all use of the Gracenet Data, the Gracenet Software, and Gracenet Servers. Gracenet reserves all rights in Gracenet Data, the Gracenet Software, and the Gracenet Servers, including all ownership rights. Under no circumstances will Gracenet become liable for any payment to you for any information that you provide. You agree that Gracenet may enforce its rights under this Agreement against you directly in its own name. Gracenet may amend or remove Gracenet Data with or without advance notice and may block or modify access to Gracenet Data; you do not have any claim against Gracenet arising out of such change, removal, blocking or modification.

PLEASE NOTE that in order to use the Gracenet Data, specific technical pre-requisites, such as this application or device, software programs, methods of transfer, telecommunication services and other third party services, usually need to be used, for which additional cost, in particular connection charges, can be incurred, which you will have to pay for separately. Gracenet does not provide such applications or devices, software programs, methods of transfer, telecommunication services or other services, and does not accept any liability for services of third parties. Gracenet is not responsible for the proper setup, connection or (if applicable) equipment of this application or device so that Gracenet Data may be received; this lies within your sole responsibility.


The Gracenet service uses a unique identifier to track queries for statistical purposes. The purpose of a randomly assigned numeric identifier is to allow the Gracenet service to count queries without knowing anything about who you are. For more information, see the web page for the Gracenet Privacy Policy for the Gracenet service. The Gracenet Software and each item of Gracenet Data are licensed to you "AS IS." Gracenet makes no representations or warranties, express or implied, regarding the accuracy of any Gracenet Data from the Gracenet Servers; the download or any other receipt of content, in particular the download of Gracenet Data, is also at your own risk and you are solely responsible for any damage to this application or device or for any other damages, including loss of data, arising out of such actions. Gracenet

5

Getting Started

Remote

The available functions of the remote are different depending on the disc or the situation.



PLAY, TV VOL +, and AUDIO buttons have a tactile dot. Use the tactile dot as a reference when operating the player.

The player automatically returns to standby mode
If any button on the player or remote is not pressed for more than 20 minutes, the player automatically returns to standby mode.

4

reserves the right to delete data from the Gracenet Servers or to change data categories for any cause that Gracenet deems sufficient. No warranty is made that the Gracenet Software or Gracenet Servers are error-free or that functioning of Gracenet Software or Gracenet Servers will be uninterrupted. Gracenet is not obligated to provide you with new, enhanced or additional data types or categories that Gracenet may provide in the future, and is free to discontinue its services at any time.

GRACENET DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NON-INFRINGEMENT. GRACENET DOES NOT WARRANT THE RESULTS THAT WILL BE OBTAINED BY YOUR USE OF THE GRACENET SOFTWARE, GRACENET DATA OR ANY GRACENET SERVER. IN NO CASE WILL GRACENET BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES OR FOR ANY LOST PROFITS OR LOST REVENUES.

© 2000 – present. Gracenet, Inc. All Rights Reserved.

Software License Information

For EULA (End User License Agreement), please refer to [License agreement] in the option menu on each network service icon.

For details of the other software licenses, please select [Setup] and refer to [Software License Information] in [System Settings].

This product contains software that is subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL"). These licenses establish that customers have the right to acquire, modify, and redistribute the source code of said software in accordance with the terms of the GPL or the LGPL. The source code for the software used in this product is subject to the GPL and LGPL, and is available on the Web. To download, please visit the following website: http://oss.sony.net/Products/Linux Please note that Sony cannot respond to any inquiries regarding the content of this source code.

Disclaimer regarding services offered by third parties

Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

6

(Fast reverse/fast forward)

- Fast reverse/fast forward the disc when you press the button during playback. The search speed changes each time you press the button during video playback.
- Plays in slow motion, when pressed for more than one second in pause mode.
- Plays one frame at a time, when you press for a short time in pause mode.

PLAY Starts or re-starts playback.

PREV/NEXT Skips to the previous/next chapter, track, or file.

PAUSE Pauses or re-starts playback.

STOP Stops playback and remembers the stop point (resume point). The resume point for a title/track is the last point you played or the last photo for a photo folder.

SUBTITLE Selects the subtitle language when multi-lingual subtitles are recorded on BD-ROMs/DVD VIDEOS.

TV VOL +/- Adjusts the TV volume.

AUDIO Selects the language track when multi-lingual tracks are recorded on BD-ROMs/DVD VIDEOS. Selects the sound track on CDs.

MUTING Turns off the sound temporarily.

DISPLAY Displays the playback information on the screen.

To lock the disc tray (Child Lock)

You can lock the disc tray to avoid accidental opening of the tray. While the player is turned on, press STOP, HOME, and then TOP MENU button on the remote to lock or unlock the tray.

Code numbers of controllable TVs

Hold down -TV- and the TV manufacturer's code using the remote buttons for 2 seconds.

Table with 2 columns: Manufacturer, Remote Button. Rows include Sony (Default), Hitachi, LG/Goldstar/NEC, Toshiba, RCA, Mitsubishi/MGA, Pioneer, Sharp, Panasonic, Samsung, and Philips.


7

Step 1: Connecting the Player

Do not connect the AC adaptor until you have made all the connections.

Connecting to your TV


Connect the player to your TV with a High Speed HDMI Cable.



\* See "Supplied accessories" (page 15).

Connecting to your AV amplifier (receiver)

Select one of the following connection methods according to the input jacks on your AV amplifier (receiver). When you select A or B, make the appropriate settings in [Audio Settings].



\* See "Supplied accessories" (page 15).

8

2


6



## Step 2: Preparing for Network Connection

### Wired Setup


Use a LAN cable to connect to the LAN (100) terminal on the player.



The use of a shielded and straight interface cable (LAN cable) is recommended.


### Wireless Setup (BDP-S3700/BX370 only)

Use the wireless LAN that is built into the player.



## 5 Perform [Easy Initial Settings].


Follow the on-screen instructions to make the basic settings using  $\leftarrow/\uparrow/\downarrow/\rightarrow$  and ENTER on the remote.



When [Easy Initial Settings] is complete, the player will automatically find the available network.

### Home screen display

The home screen appears when you press HOME. Select an application using  $\leftarrow/\uparrow/\downarrow/\rightarrow$ , and press ENTER.



**[My Apps]:** Manages favorite application. You may add shortcuts for application from [All Apps].

**[Featured Apps]:** Displays recommended application.

**[All Apps]:** Shows all available applications. You can add applications to [My Apps] by pressing OPTIONS, and select [Add to My Apps].

**[Setup]:** Adjusts the player's settings.


Screen mirroring function is only available for BDP-S3700/BX370.

## Step 3: Easy Setup


### When turned on for the first time

Wait for a short while before the player turns on and starts [Easy Initial Settings].


- 1 Insert two Size AAA (R03) batteries by matching the  $\oplus$  and  $\ominus$  ends on the batteries to the markings inside the battery compartment of the remote.



- 2 Connect the supplied AC adaptor in the numeric order shown below. When removing them, do so in reverse order.



- 3 Press  $\text{power}$  to turn on the player.



\* Turns on the player, or sets to standby mode.

- 4 Turn on the TV and set the input selector on your TV by pressing INPUT button on the remote. This will show the signal from the player on your TV screen.

9

### Available options

Various settings and playback operations are available by pressing OPTIONS. The available items differ depending on the situation.

**[Move Application]:** Arranges applications in [My Apps].

**[Remove Application]:** Deletes applications in [My Apps].

**[Register as Favorite]:** Registers 1 application into FAVORITE remote button.

**[Data Contents]:** Displays the contents of the mixed disc.


10

### Playback

## Playing a Disc

For "Playable discs", see page 13.

- 1 Press  $\text{OPEN/CLOSE}$ , and place a disc on the disc tray.



Playing side facing down

- 2 Press  $\text{OPEN/CLOSE}$  to close the disc tray. Playback starts. If playback does not start automatically, select [Video], [Music], or [Photo] category in  $\text{Disc}$ , and press ENTER.

(Mixed disc) contains data contents. Press OPTIONS on the remote and select [Data Contents] to display any available contents.

### Enjoying BONUSVIEW/BD-LIVE

- 1 Connect a USB memory to the USB jack on the player. Use a 1 GB or larger USB memory as your local storage.

- 2 Prepare for BD-LIVE (BD-LIVE only).

- Connect the player to a network (page 9).
- Set [BD Internet Connection] in [BD/DVD Viewing Settings] to [Allow].

- 3 Insert a BD-ROM with BONUSVIEW/BD-LIVE.

The operation method differs depending on the disc. Refer to the instruction manual supplied with the disc.

11

## Playing via a Network

### Using "TV SideView" (BDP-S3700/BX370 only)

"TV SideView" is a free mobile application for remote devices (such as smartphone, etc.). By using "TV SideView" with this player, you can easily enjoy the player by using the operation on your remote device. You can launch a service or application directly from the remote device and view the disc information during disc playback. "TV SideView" also can be used as a remote control and software keyboard. Before you use the "TV SideView" device with this player for the first time, be sure to register the "TV SideView" device. Follow the on-screen instructions on the "TV SideView" device for registration.

The registration can only be performed on the home screen.

### Using Screen mirroring (BDP-S3700/BX370 only)

"Screen mirroring" is a function to display the screen of a mobile device on the TV by Miracast technology. The player can be connected directly with a Screen mirroring compatible device (e.g. smartphone, tablet). You can enjoy the display screen of the device on your large TV screen. No wireless router (or access point) is required to use this feature.

- When using Screen mirroring, the quality of picture and sound may sometimes be deteriorated due to interference from other network. You may improve by adjusting [Screen mirroring RF Setting].
- Some network functions may not be available during Screen mirroring.
- Make sure that the device is compatible with Miracast. Connectivity with all Miracast compatible devices is not guaranteed.

- 1 Select  $\text{Screen mirroring}$  [Screen mirroring] from home screen using  $\leftarrow/\uparrow/\downarrow/\rightarrow$ , and press ENTER.

- 2 Follow the on-screen instructions.

12



To delete data in the USB memory, select [Delete BD Data] in [BD/DVD Viewing Settings], and press ENTER. All data stored in the buda folder will be erased.

## Playing from a USB Device

For "Playable types of files", see page 13.

- 1 Connect the USB device to the USB jack on the player.

- 2 Select  $\text{USB device}$  using  $\leftarrow/\uparrow/\downarrow/\rightarrow$ , and press ENTER.

- 3 Select [Video], [Music], or [Photo] category using  $\uparrow/\downarrow$ , and press ENTER.

13

### Additional Information

## Software Update

- 1 Select  $\text{Setup}$  [Setup] on the home screen using  $\leftarrow/\uparrow/\downarrow/\rightarrow$ .

- 2 Select  $\text{Software Update}$  [Software Update] using  $\uparrow/\downarrow$ , and press ENTER.

### [Update via Internet]

Updates the player's software using available network. Make sure that the network is connected to the Internet. For details, see "Step 2: Preparing for Network Connection" (page 9).

### [Update via USB Memory]

Updates the player's software using USB memory. Make sure that the Software Update Folder is correctly named as "UPDATE" and all the update files must be stored in this folder. The player can recognize up to 500 files/folders in a single layer including the update files/folders.



- We recommend performing the software update every 2 months or so.
- If your network condition is poor, visit <http://www.sony.com/bluraysupport> to download the latest software version and update via USB memory. You can also get information about update functions from the website.

14

## Playable discs

Blu-ray Disc*1	BD-ROM, BD-R*2/BD-RE*2
DVD*3	DVD-ROM, DVD-R/DVD-RW, DVD+R/DVD+RW
CD*3	CD-DA (Music CD), CD-ROM, CD-R/CD-RW


\*1 Since the Blu-ray Disc specifications are new and evolving, some discs may not be playable depending on the disc type and the version. The audio output differs depending on the source, connected output jack, and selected audio settings.

\*2 BD-RE: Ver.2.1, BD-R: Ver.1.1, 1.2, 1.3 including organic pigment type BD-R (LTH type). The BD-Rs recorded on a PC cannot be played if postscripts are recordable.

\*3 A CD or DVD disc will not play if it has not been correctly finalized. For more information, refer to the instruction manual supplied with the recording device.

### Region code (BD-ROM/DVD VIDEO only)

Your player has a region code printed on the bottom of the unit and will only play BD-ROMs/DVD VIDEOS labeled with identical region codes or  $\text{All R}$ .



## Playable types of files

### Video

Codec	Container	Extension	With Audio
MPEG-1 Video*1	PS	.mpg, .mpeg	Dolby Digital, DTS, LPCM, MPEG
	MKV	.mkv	Dolby Digital, LPCM, AAC, MP3, Vorbis
MPEG-2 Video*2	PS*3	.mpg, .mpeg	Dolby Digital, DTS, LPCM, MPEG
	TS*4	.m2ts, .mts	Dolby Digital, DTS, LPCM, MPEG, AAC
Xvid	MKV*1	.mkv	Dolby Digital, LPCM, AAC, MP3, Vorbis
	MKV	.mkv	Dolby Digital, LPCM, AAC, MP3, Vorbis
MPEG4/AVC*5	MP4*1	.mp4, .m4v	AAC
	TS*1	.m2ts, .mts	Dolby Digital, DTS, LPCM, MPEG, AAC
	Quick Time*6	.mov	Dolby Digital, LPCM, AAC, MP3
	FLV*6	.flv, .f4v	LPCM, AAC, MP3
	3gpp/3gpp2*6	.3gp, .3g2, .3gpp, .3gp2	AAC
	VC1*81	TS	.m2ts, .mts
WMV9*1*7	ASF	.wmv, .asf	WMA9, WMA 10 Pro
	MKV	.mkv	Dolby Digital, LPCM, AAC, MP3, Vorbis
Motion JPEG*6	Quick Time	.mov	Dolby Digital, LPCM, AAC, MP3
	AVI	.avi	Dolby Digital, LPCM, AAC, MP3

### Format

AVCHD (Ver.2.0)\*1\*8\*9

### Music

Codec	Extension
MP3 (MPEG-1 Audio Layer III)*10	.mp3
AAC/HE-AAC*1*10	.m4a, .aac*6
WMA9 Standard*1	.wma
WMA 10 Pro*11	.wma
LPCM*10	.wav
FLAC*1	.flac, .fla
Dolby Digital*6*10	.ac3
DSF*1	.dsf
DSDIFF*1*12	.dff
AIFF*1	.aiff, .aif
ALAC*1	.m4a
Vorbis	.ogg
Monkey's Audio	.ape

### Photo

Format	Extension
JPEG	.jpg, .jpeg, .jpe
PNG	.png*13
GIF	.gif*13
BMP	.bmp*6*14

\*1 The player may not play this file format on a DLNA server (BDP-S3700/BX370 only).

\*2 The player can only play standard definition video on a DLNA server (BDP-S3700/BX370 only).

\*3 The player does not play DTS format files on a DLNA server (BDP-S3700/BX370 only).

\*4 The player can only play Dolby Digital format files on a DLNA server (BDP-S3700/BX370 only).

\*5 The player can support AVC up to Level 4.1.

\*6 The player does not play this file format on a DLNA server (BDP-S3700/BX370 only).

\*7 The player can support WMV9 up to Advance Profile.

\*8 The player can support frame rate up to 60 fps.

\*9 The player plays AVCHD format files that are recorded on a digital video camera, etc. The AVCHD format disc will not play if it has not been correctly finalized.

\*10 The player can play ".mka" files.

(This file cannot be played on a DLNA server (BDP-S3700/BX370 only).)

\*11 The player does not play coded file such as Lossless.

15

## Specifications

### System

Laser	Semiconductor laser
<b>Inputs and outputs</b>	
DIGITAL OUT (COAXIAL) (Jack name)	Phono jack /0.5 Vp-p/75 ohms (Jack type/Output level/Load impedance)
HDMI OUT	HDMI 19-pin standard connector
LAN (100)	100BASE-TX Terminal
USB	USB jack Type A (For connecting a USB memory, memory card reader, digital still camera, and digital video camera)*
DC IN	* Do not use for power charging purposes. BDP-S3700/BX370: 12 V DC, 650 mA BDP-S1700: 12 V DC, 600 mA

### Wireless (BDP-S3700/BX370 only)

Wireless LAN standard	Protocol IEEE 802.11 b/g/n
Frequency range	2.4 GHz band: Channels 1-11
Modulation	DSSS and OFDM

### General

Power requirements	12 V DC with AC adaptor Rating: Input 120 V AC, 60 Hz
Power consumption (when using AC adaptor)	BDP-S3700/BX370: 9.2 W BDP-S1700: 8.5 W
Dimensions (approx.)	230 mm x 194 mm x 39 mm (9 1/4 in. x 7 3/4 in. x 1 9/16 in.) (width/depth/height) incl. projecting parts
Mass (approx.)	0.8 kg (1 lb 13 oz)
Operating temperature	5 °C to 35 °C (41 °F to 95 °F)
Operating humidity	25 % to 80 %

### Supplied accessories

- High Speed HDMI Cable (1)\*
- AC adaptor (AC-M1210UC) (1)
- Remote commander (remote) (1)
- Size AAA (R03) batteries (2)

\* Supplied for BDP-BX370

Specifications and design are subject to change without notice.