

Quick Start Guide

For more information about how to use your phone, please visit www.alcatel-mobile.com to download the complete user manual. Moreover, from the website you can also consult FAQ.



www.sar-tick.com


This product meets applicable national SAR limits of 2.0 W/kg. The specific maximum SAR values can be found on page 23 of this user guide.

When carrying the product or using it while worn on your body, either use an approved accessory such as a holster or otherwise maintain a distance of 5 mm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

1 Your mobile



1

1.1 Keys

- Navigation key**
 - Press to confirm an option
 - Press to go left/right/up/down
- Access main menu**
 - Pick up/Send a call
 - Press: Enter Call log
- Access contacts**
 - Press: End a call
 - Return to the Home screen
 - Long press: Power on/off
- Long press: Access your voicemail**
- From Idle screen**
 - Press: enter 0
 - Long press: "0/+ " and "0/+P/W" when in Dial screen.
- In Edit mode**
 - Press: Access symbols table
 - Long press: 0
- From Idle screen**
 - Press: *
 - In Edit mode:
 - Press: Change input methods
- From Idle screen**
 - Press: #
 - Long press: Vibration alert
 - In Edit mode
 - Press: ↵ (space)

2

1.2 Status bar icons ⁽¹⁾

- In 2051X:
- Battery charge level.**
 - Level of network reception.**
 - Bluetooth status (Activated).**
 - Missed calls.**
 - Call forwarding activated:** your calls are forwarded.
 - SD card scanning completed.**
 - Roaming.**
 - Flight mode.**
 - GPRS connection status (Activated).**
 - Music activated.**
 - Radio is on.**
 - Headset connected.**
 - Alarm or appointments programmed.**
 - Receiving an MMS.**
 - Sending an MMS.**
 - SMS unread.**
- In 2051D:
- Level of network reception.**
 - Call forwarding activated:** your calls are forwarded.
 - GPRS connection status (Activated).**
 - Roaming.**

⁽¹⁾ The icons and illustrations in this guide are provided for information purposes only.

3

1.3 Home screen

- #### 1.3.1 Widget bar
- Widgets are convenient shortcuts for quick access from the Home screen.
- You can customize widget bar by "Settings/Phone settings/Widget bar".
- #### 1.3.2 Change wallpaper
- You can select a folder to choose one image as favourite wallpaper by selecting "Options/Set as /Wallpaper" in My files or open the picture in Image and press to choose Set as wallpaper.


- In 2051D:
- Call forwarding activated:** your calls are forwarded.
 - GPRS connection status (Activated).**
 - Roaming.**

4

11 My files.....

You will have access to all audio and visual files stored in phone or memory card in My files. You can access a number of items in Phone or Memory card with this option: Alarm, Audio, Photos, Others, Video, etc.

Inserting and removing the memory card:



Place the microSD card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press and slide it out.

12 Alarm

Your mobile phone has a built-in alarm clock with snooze feature.

5

13 Calculator.....

Press the up, down, left, right and OK key to select +, -, x, ÷ and = respectively. Press to delete the figure.

14 Calendar

Once you enter this menu from the main menu, there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked.

15 Notes

You can create a note in text format by accessing "Notes" from the main menu.

16 Bluetooth.....

You can transfer data, such as music to other device using Bluetooth. Search the device and accept/transfer data. The received data is automatically stored in the directory.

14

2 Getting started.....

2.1 Set up


Removing and installing the back cover



Removing and installing the battery



Inserting and removing the SIM card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out.

6

17 Convertor.....

When select **weight**. You can have a quick check the difference between kg, pound and kg, ounce. Under **length**, you can convert among km and mile, m-yard, m-foot, etc.

18 Fake call

This program enables you to call yourself by simulating a caller number/name, ringtone at a scheduled time. It helps you to politely escape from social situations at any time you wish. This call can be rejected by key.

19 Call filter.....

Enable blacklist, all callers in the list will be automatically blocked. Enable whitelist, only callers in the list can be connected.

20 Wap.....

Access WAP options: Input URL, Bookmarks, History, Offline pages.

15

3 Making a call.....

Charging the battery



Connect battery charger to your phone and plug into the socket.

- Charging may take about 20 minutes to start if the battery is out of power.
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- You are advised to charge the battery to its maximum when using the phone for the first time (approximately 3 hours) ().
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; switch off Bluetooth when not in use; reduce the backlight time, etc.

The charge is complete when the animation stops.

2.2 Power on your phone

Hold down the key until the phone powers on.

2.3 Power off your phone

Hold down the key from the Home screen.

⁽¹⁾ 2051D only.
⁽²⁾ 2051X

7

24 Input mode.....

This mode allows you to type a text by choosing a letter or a sequence of characters associated with a key. Press the key several times until the desired letter is highlighted. When you release the key the highlight character is inserted into the text.

21 Profiles.....

With this menu, you may personalise ringtones for different events and environments.

22 Settings

From the main menu, select the menu icon and select the function of your choice in order to customise your telephone: Phone settings, Call settings, Connections, Security, Restore factory settings ⁽¹⁾, Main SIM settings ⁽²⁾.

23 Services

STK service is the tool kit of SIM card. This phone supports the service function. The specific items depend on SIM card and network. Service menu will be automatically added to the phone menu when supported by network and SIM card. Contact your network operator first to check service availability.

⁽¹⁾ Make the phone's settings recover to its default value. End-user data will not be erased. Enter its default password 1234 to confirm to restore and reboot.
⁽²⁾ 2051D only.

16

⁽¹⁾ 2051D only.

10

⁽¹⁾ 2051D only.

11

12

⁽¹⁾ The quality of the radio depends on the coverage of the radio station in that particular area.
⁽²⁾ Depending on your network operator and market.

13

17

