

1-, 2-, and 4-Port Hardened Serial Servers

Connect serial RS-232/422/485 devices to Ethernet networks, allowing the serial device to become a node on the network.

Access the serial ports over a LAN/WAN using direct IP mode, virtual COM port, or paired mode connections.



Customer Support Information

Order toll-free in the U.S.: Call 877-877-BBOX (outside U.S. call 724-746-5500)
FREE technical support 24 hours a day, 7 days a week: Call 724-746-5500 or fax 724-746-0746
Mailing address: Black Box Corporation, 1000 Park Drive, Lawrence, PA 15055-1018
Web site: www.blackbox.com • E-mail: info@blackbox.com

Trademarks Used in this Manual

Trademarks Used in this Manual

Black Box and the Double Diamond logo are registered trademarks of BB Technologies, Inc.

Firefox is a registered trademark of Mozilla Foundation.

Internet Explorer, Windows, and Windows Vista are registered trademarks of Microsoft Corporation.

UL Is a registered trademark of Underwriters Laboratories.

Any other trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.

We're here to help! If you have any questions about your application or our products, contact Black Box Tech Support at **724-746-5500** or go to **blackbox.com** and click on "Talk to Black Box." You'll be live with one of our technical experts in less than 30 seconds.

Federal Communications Commission and Industry Canada Radio Frequency Interference Statements

This equipment generates, uses, and can radiate radio-frequency energy, and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio communication. It has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart B of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when the equipment is operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be necessary to correct the interference.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This digital apparatus does not exceed the Class A limits for radio noise emission from digital apparatus set out in the Radio Interference Regulation of Industry Canada.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescrites dans le Règlement sur le brouillage radioélectrique publié par Industrie Canada.

WARNING: EXPLOSION HAZARD—DO NOT DISCONNECT EQUIPMENT WHILE THE CIRCUIT IS LIVE OR UNLESS THE AREA IS KNOWN TO BE FREE OF IGNITABLE CONCENTRATIONS.

SUITABLE FOR USE IN CLASS I, DIVISION 2, GROUPS A, B, C AND D HAZARDOUS LOCATIONS, OR NONHAZARDOUS LOCATIONS ONLY.

WARNING: EXPLOSION HAZARD—SUBSTITUTION OF ANY COMPONENT MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2.

Instrucciones de Seguridad (Normas Oficiales Mexicanas Electrical Safety Statement)

1. Todas las instrucciones de seguridad y operación deberán ser leídas antes de que el aparato eléctrico sea operado.
2. Las instrucciones de seguridad y operación deberán ser guardadas para referencia futura.
3. Todas las advertencias en el aparato eléctrico y en sus instrucciones de operación deben ser respetadas.
4. Todas las instrucciones de operación y uso deben ser seguidas.
5. El aparato eléctrico no deberá ser usado cerca del agua—por ejemplo, cerca de la tina de baño, lavabo, sótano mojado o cerca de una alberca, etc.
6. El aparato eléctrico debe ser usado únicamente con carritos o pedestales que sean recomendados por el fabricante.
7. El aparato eléctrico debe ser montado a la pared o al techo sólo como sea recomendado por el fabricante.
8. Servicio—El usuario no debe intentar dar servicio al equipo eléctrico más allá a lo descrito en las instrucciones de operación. Todo otro servicio deberá ser referido a personal de servicio calificado.
9. El aparato eléctrico debe ser situado de tal manera que su posición no interfiera su uso. La colocación del aparato eléctrico sobre una cama, sofá, alfombra o superficie similar puede bloquea la ventilación, no se debe colocar en libreros o gabinetes que impidan el flujo de aire por los orificios de ventilación.
10. El equipo eléctrico debe ser situado fuera del alcance de fuentes de calor como radiadores, registros de calor, estufas u otros aparatos (incluyendo amplificadores) que producen calor.
11. El aparato eléctrico deberá ser conectado a una fuente de poder sólo del tipo descrito en el instructivo de operación, o como se indique en el aparato.
12. Precaución debe ser tomada de tal manera que la tierra física y la polarización del equipo no sea eliminada.
13. Los cables de la fuente de poder deben ser guiados de tal manera que no sean pisados ni pellizcados por objetos colocados sobre o contra ellos, poniendo particular atención a los contactos y receptáculos donde salen del aparato.
14. El equipo eléctrico debe ser limpiado únicamente de acuerdo a las recomendaciones del fabricante.
15. En caso de existir, una antena externa deberá ser localizada lejos de las líneas de energía.
16. El cable de corriente deberá ser desconectado del cuando el equipo no sea usado por un largo periodo de tiempo.
17. Cuidado debe ser tomado de tal manera que objetos líquidos no sean derramados sobre la cubierta u orificios de ventilación.
18. Servicio por personal calificado deberá ser provisto cuando:
 - A: El cable de poder o el contacto ha sido dañado; u
 - B: Objetos han caído o líquido ha sido derramado dentro del aparato; o
 - C: El aparato ha sido expuesto a la lluvia; o
 - D: El aparato parece no operar normalmente o muestra un cambio en su desempeño; o
 - E: El aparato ha sido tirado o su cubierta ha sido dañada.

Table of Contents

1. Specifications.....	7
1.1 General.....	7
1.2 Serial Interface.....	7
1.3 Network.....	8
1.4 TCP/UDP Ports.....	9
1.5 Dimensional Diagrams.....	10
2. Overview.....	12
2.1 Introduction.....	12
2.2 Features.....	12
2.3 What's Included.....	13
2.4 Hardware Description.....	13
2.4.1 1-Port Hardened Serial Server.....	13
2.4.2 2-Port Hardened Serial Server.....	14
2.4.3 4-Port Hardened Serial Server.....	15
2.5 Configuration Software.....	16
3. Installation and Initial Setup.....	17
3.1 Connecting the Power Supply.....	17
3.2 Connecting Hardened Serial Servers to Serial Devices.....	17
3.2.1 RS-232.....	17
3.2.2 RS-422.....	18
3.2.3 RS-485.....	18
3.3 Connecting Hardened Serial Servers to the Network.....	18
3.4 Ethernet Passthrough Port.....	18
3.5 Hardened Serial Server Configuration.....	19
3.5.1 Configuring via the Network using Hardened Serial Server Software.....	19
3.5.2 Configuring via the Network using a Browser.....	19
3.5.3 Configuring via a Serial Port Using Hardened Serial Server Software (Console Mode).....	20
3.6 Hardened Serial Server Operational Connections.....	20
3.7 Installing and Starting Hardened Serial Server Software.....	21
3.8 Discovering Hardened Serial Servers.....	22
4. Configuring the Hardened Serial Server.....	23
4.1 Overview of the Hardened Serial Server Software.....	23
4.1.1 Icons.....	23
4.1.2 Hardened Serial Server Information Table.....	24
4.1.3 Configuration Pane.....	24
4.2 Logging In.....	25
4.3 Navigating the Configuration Pages.....	25
4.4 Setting Up the Hardened Serial Server Name and Password.....	26
4.4.1 Changing the Hardened Serial Server's Name.....	26
4.4.2 Changing the Password.....	26
4.5 Setting Up IP Addressing.....	26
4.5.1 Setting Up Dynamic IP Addressing.....	27
4.5.2 Setting Up Static IP Addressing.....	27
4.6 Setting Up Serial Ports.....	28
4.7 Setting Up Port Network Parameters.....	28
4.7.1 TCP Configuration.....	28
4.7.2 UDP Configuration.....	30

Table of Contents

4.7.3 Setting Up Virtual COM (VCOM) Operation	32
4.7.4 Setting Up Paired Mode Operation	32
4.8 Setting Up Advanced Network Settings	34
4.8.1 Configuring When Network Connections Will Be Forced Closed	34
4.8.2 Configuring When Data Packets Are Sent	35
4.9 Saving/Restoring the Configuration Settings	37
4.10 Adding Virtual COM Ports.....	38
4.11 Removing Virtual COM Ports.....	39
5. Upgrading the Hardened Serial Server Firmware.....	40
5.1 Downloading Firmware Files.....	40
5.2 Uploading the Firmware to the Hardened Serial Server.....	41
6. Operation	42
6.1 LED Indicators.....	42
6.2 Reset Switch	45
6.2.1 Using the Reset Switch to Initiate a Hardware Reset	45
6.2.2 Using the Reset Switch to Enter Console Mode	45
6.2.3 Using the Reset Switch to Exit Console Mode.....	45
6.2.4 Using the Reset Switch to Reload Factory Default Settings	45
7. Diagnostics	46
7.1 Testing a Hardened Serial Server Connection	46
7.2 Testing a Virtual COM Port.....	47
8. Listing/Descriptions of Hardened Serial Server Settings	48
Appendix A. Default Server Settings	54
Appendix B. Connector Pinouts	55
B.1 DB9 M Connector	55
B.2 Terminal Block	55
B.3 Standard Ethernet Cable RJ-45 Pinout	56

1. Specifications

1.1 General

General Specifications

Certifications	FCC Part 15, Class A, CE, NEMA TS2, UL® Class 1, Division 2, Groups A, B, C, and D
Compatible Operating Systems	Windows® XP (32/64 bit), 2003 Server (32/64 bit), Windows Vista® (32/64 bit), 2008 Server (32/64 bit), Windows 7 (32/64 bit)
Configuration Options	Via serial port using Hardened Serial Server Software, via network using Hardened Serial Server Software with an Ethernet connection or a standard Web browser such as Internet Explorer® 7, 8, or 9, or Firefox® 3 or 4
Enclosure	Rating: IP30; Mounting: DIN rail mount (35 mm)
User Controls	(1) Reset button
Connectors	LES421A: (1) DB9 M, (1) 5-pin terminal block, (1) RJ-45, (1) 2-position pluggable terminal block for power; LES422A: (2) DB9 M, (1) RJ-45, (1) 2-position pluggable terminal block for power; LES424A: (4) DB9 M, (1) RJ-45, (1) 3-position pluggable terminal block and (1) locking barrel connector for power
Indicators	LES421A: (4) LEDs: (1) Ready, (1) Serial, (1) Ethernet Link, (1) Ethernet Speed; LES422A: (7) LEDs: (1) Ready, (2) Serial, (2) Ethernet Link, (2) Ethernet Speed; LES424A: (9) LEDs: (1) Ready, (4) Serial, (2) Ethernet Link, (2) Ethernet Speed
Temperature Tolerance	Operating: -40 to +176° F (-40 to +80° C); Storage: -40 to +185° F (-40 to +85° C); Maximum Ambient Surrounding Air Temperature: 176° F (80° C)
Operating Humidity	10 to 95%, noncondensing
Power	LES421A, LES422A: 10 to 48 VDC (58 VDC max.), 4.0 watts max.; LES424A: Locking barrel connector input: Voltage requirements: 10 to 30 VDC maximum, Class 2 grounded type supply only <i>NOTE: Coaxial power cable must be in accordance with Class 2 requirements in Article 725 of the NEC. The locking barrel connector must not be used in a hazardous environment.</i> LES424A (continued): Consumption: 6.0 watts maximum; Terminal blocks: Wire size: 28 to 16 AWG, Wire Type: Copper wire only, Tightening Torque: 5 kg-cm, Wire Temperature Rating: 105° C minimum, sized for 60° C ampacity <i>NOTE: One conductor per terminal.</i>
Size	LES421A, LES422A: 1.2"H x 3.2"W x 4.7"D (3 x 8.1 x 11.9 cm); LES424A: 1.8"H x 4.4"W x 6.8"D (4.6 x 12.2 x 17.1 cm)

1.2 Serial Interface

Serial Interface Specifications

Baud Rates	75, 150, 300, 600, 1200, 2400, 4800, 7200, 9600, 14400, 19200, 28800, 38400, 57600, 115200, 230400
Data Bits	5, 6, 7, 8
Flow Control	None, RTS/CTS, X-ON, X-OFF
Mode Selection	RS-232/422/485 software-selectable
Parity	None, even, odd, mark, space
RS-232 Lines	TXD, RXD, RTS, CTS, DTR, DSR, DCD, GND
RS-422 Lines	TXDA(-), TXDB(+), RXDA(-), RXDB (+), GND
RS-485 (2-Wire)	Data(-), Data(+), GND
RS-485 (4-Wire)	TXDA(-), TXDB(+), RXDA(-), RXDB (+), GND
RS-422/485 Biasing	Auto 1 K-ohm pullups and pulldowns
RS-422/485 Termination	Termination with through hole (user supplied)
RS-485 Data Control	Auto control via Data Multipoint Control Unit (MCU)
Stop Bits	1, 1.5, 2

Chapter 1: Specifications

1.3 Network

Network Specifications

Character Count	0 to 65535
Client Connection	At power-up or upon data arrival
Connection Modes	Server, Client, VCOM, Paired
Delimiters	Hex 1 : 01 to FF (begin buffering when hex 1 received); Hex 2: 01 to FF (send serial data if delimiter hex 2 is set and received)
Diagnostics	Display PC IP, ping, text VCOM, save test config (text readable)
Memory	Serial: 8 KB per port; Network memory: 4 KB
Firmware Upgrade	Via serial, Ethernet, or auto web search
IP Port Addresses	5300: heartbeat and configuration setting in TCP mode (i.e., Pair mode); 8888: LES424A update
Network Communications	LAN: 10-/100-Mbps auto-detecting 10BASE-T and 100BASE-TX
Network Physical Layer Standards	Ethernet: IEEE 802.3 autodetecting and auto MDI/MDI-X 10BASE-T and 100BASE-TX
Protocols Supported	TCP, IPv4, UDP, ARP, HTTP 1.0, ICMP/PING, DHCP/BOOTP; IP mode: Static, DHCP; TCP/UDP: User-definable; UDP: Unicast or multicast
Search	Serial direct COM and Ethernet autosearch or specific IP
Timeouts	Inter-character: 0 to 65535 ms; Serial: 0 to 65535 ms; Network: 0 to 65535 min; Force transmit: 0 to 65535 ms; Max. character count: 0 to 8192 bytes

1.4 TCP/UDP Ports

Table 1-1. TCP/UDP ports.

Port	Description	Comments
80/tcp	Always open for the Web server.	This port is used for configuration of the device using a web browser. This port is always open no matter how you configure the device. If you want to use this method to configure the device from outside of a firewall, then a firewall must allow incoming connections to this port. If you want to use this method to configure the device from the outside of a NAT, the NAT must be configured to forward to this port.
771/tcp	This port is open when any serial port is configured for VCOM mode.	This port is used for communications with the VCOM device driver installed on the computer. This port is open only if you configure any serial port for VCOM mode. If you want to use VCOM from outside of a firewall, then you must allow incoming connections on this port. If you want to use VCOM from outside of a NAT, then you must forward to this port.
7000/tcp	Always open for serial server configuration over TCP.	This port is used for configuration and firmware upgrade of the device using the serial server manager. This port is always open no matter how you configure the device. If you want to configure the serial server from outside of a firewall using the serial server manager, then the firewall must be configured to allow incoming connections on 7000/tcp and allow packets addressed to 7000/udp to be received. <i>NOTE: Configuring over 7000/udp is not supported.</i>
60000/tcp	This port is open when serial port 1 is configured for paired-mode server.	These ports are used to transfer handshake line state and break state in paired mode configuration. These ports are open only if you configure the port for paired-mode server. Note that serial port 1 uses 60000/tcp, serial port 2 uses 60001/tcp, serial port 3 uses 60002/tcp, and serial port 4 uses 60003/tcp. If a port is not configured for paired-mode server, then the corresponding port is not open. If you want to connect to a paired-mode server from outside of a firewall, then you must allow incoming connections on these ports. If you want to connect to a paired-mode server from outside of a NAT, then you must forward to these ports.
60001/tcp	This port is open when serial port 2 is configured for paired-mode server. Applies to LES422A and LES424A only.	As above
60002/tcp	This port is open when serial port 3 is configured for paired-mode server. Applies to LES424A only.	As above
60003/tcp	This port is open when serial port 4 is configured for paired-mode server. Applies to LES424A only.	As above
68/udp	This port is open when the network mode is DHCP.	This port is used if you configure the device for DHCP mode (as opposed to Static IP). It is used to communicate with the DHCP server. This should only be used inside of a firewall or NAT.
7000/udp	Always open for serial server configuration over UDP.	These ports are used for configuration and firmware upgrade of the device using the serial server manager. These ports are always open no matter how you configure the device. If you want to configure the serial server from outside of a firewall using the serial server manager, then the firewall must be configured to allow incoming connections on 7000/tcp and allow packets addressed to 7000/udp to be received
8899/udp	Always open for serial server discovery.	This port is used for discovering serial servers. This port is always open no matter how you configure the device. <i>NOTE: The device discovery only works on a local subnet. The port may not need to be configured in a firewall or NAT.</i>
Other	User-specified ports.	Other TCP and UDP ports may be open, depending on what you specified for the device configuration. THESE ARE THE PORTS SPECIFIED IN THE CONFIGURATION FILE. If you want to use these other ports from outside of a firewall, then you must allow these ports. If you want to use these other ports from outside of a NAT, then you must forward to these ports.

1.5 Dimensional Diagrams




Figure 1-1. Dimensional diagram of a LES421A or LES422A Hardened Serial Server (dimensions in inches).




Figure 1-2. Dimensional diagram of a LES424A Hardened Serial Server (dimensions in inches and millimeters).

2. Overview

2.1 Introduction

The 1-, 2-, and 4-Port Hardened Serial Servers connect serial devices (RS-232, RS-422, or RS-485) to Ethernet networks, allowing the serial device to become a node on the network. The serial ports can be accessed over a LAN/WAN using Direct IP Mode, Virtual COM Port, or Paired Mode connections. Hardened Serial Servers use 10BASE-T or 100BASE-TX copper network media. All models also have an additional copper Ethernet pass-through port. Hardened Serial Servers are built for use in industrial environments and feature heavy duty metal enclosures that are panel- and DIN-rail mountable. The product operates from a range of DC power supply voltages and features pluggable terminal block power connectors. The LES424A also has a locking barrel connector that facilitates redundant power sources.

Table 2-1. Available models.

Part Number	Serial Ports	Serial Connectors	Ethernet Media	Ethernet Connector 1	Ethernet Connector 2	Power
LES421A	1	(1) DB9M and (1) 5-pin terminal block <i>NOTE: Use either the DB9 or the terminal block connector, but not both at the same time.</i>	RJ-45	RJ-45	—	(1) 2-wire terminal block
LES422A	2	(2) DB9M	RJ-45	RJ-45	—	(1) 2-wire terminal block
LES424A	4	(4) DB9M	RJ-45	RJ-45	RJ-45	(1) 3-wire terminal block and (1) locking barrel connector for redundant power

2.2 Features

- LES421A, LES422A: single Ethernet connector.
- LES424A: (2) Ethernet connectors (Ethernet passthrough ports).
- Multi-interface serial ports (RS-232, RS-422, RS-485).
- LES421A has DB9M and pluggable terminal block serial port connector options.
- LES422A and LES424A have DB9M serial port connectors.
- All serial ports are software selectable for RS-232, RS-422, or RS-485 2- and 4-wire communication.
- Configuration can be done via network or direct serial connection.
- Rugged metal case; DIN rail or panel mountable.
- Accepts DC power over a wide voltage range.
- LES424A has two power connections (pluggable terminal strip and locking barrel connector), which can be used for a redundant power supply.
- Supports 10-/100-Mbps Ethernet with auto-selection.
- Configurable for TCP Client or Server, or UDP operation.
- Virtual COM port and Paired Mode capabilities.
- Upload firmware over the Ethernet port for future revisions/upgrades.
- Supports Windows XP (32/64 bit), 2003 Server (32/64 bit), Vista (32/64 bit), 2008 Server (32/64 bit), Windows 7 (32/64 bit).
- Configure Ethernet and serial port settings using Hardened Serial Server Software or built-in Web server.

2.3 What's Included

Your package should include the following items. If anything is missing or damaged, contact Black Box Technical Support at 724-746-5500 or info@blackbox.com.

LES421A or LES422A:

- 1- or 2-port Hardened Serial Server module.
- A printed quick start guide.
- This user manual in PDF format on CD-ROM

LES424A:


- 4-port Hardened Serial Server module.
- A printed quick start guide.
- This user manual in PDF format on CD-ROM
- (1) 3-position terminal block Phoenix connector
- (1) Panel mount kit: (2) brackets, (4) screws
- (1) DIN rail mounting kit: (1) DIN rail bracket, (3) screws

NOTE: To download this user manual, go to ftp://ftp.blackbox.com/anonymous/manuals/L/LES421A_2A_4A_USER_rev1.pdf or visit the Black Box Web site (www.blackbox.com) and enter LES421A, LES422A, or LES424A in the search bar.

2.4 Hardware Description

2.4.1 1-Port Hardened Serial Server (LES421A)

Figures 2-1 and 2-2 show the front and top panels of the LES421A. Table 2-2 describes its components.




Figures 2-1 and 2-2. LES421A front and top panels.

Table 2-2. LES421A components.

Number in Figure 2-1 or 2-2	Component	Description
1	(1) RJ-45 connector	Connects a standard Ethernet network drop using a straight-through RJ-45 male Ethernet cable.
2	(1) 5-position terminal block connector	Connects to an RS-422 or RS-485 serial device when the DB9 M (RS-232) connector is disabled.
3	(1) DB9 male connector	Connects to an RS-232 serial device when the 5-position terminal block (RS-422/RS-485) is disabled.
4	(1) 2-wire terminal block connector	Removable 2-position terminal block with +, -, and chassis ground connections.
5	(1) Serial Port LED	Flashes green when data is being transmitted or received on the serial port. Lights steady green when the serial port is open.
6	(1) Ethernet Link LED	Lights when a connection is made. Flashes when there is data traffic on the Ethernet link.
7	(1) Ready LED	Lights green continuously when the unit is initializing. Flashes once per second when the system is operating correctly. Off when something is wrong, for example, another device uses the same IP address.
8	(1) Reset button	Used to initiate a hardware reset, enter console mode, or reload factory defaults.

2.4.2 2-Port Hardened Serial Server (LES422A)

Figures 2-3 and 2-4 show the front and top panels of the LES422A. Table 2-3 describes its components.



Figures 2-3 and 2-4. LES422A front and top panels.

Table 2-3. LES422A components.

Number in Figure 2-3 or 2-4	Component	Description
1	(1) RJ-45 connector	Connects a standard Ethernet network drop using a straight-through RJ-45 male Ethernet cable.
2	(2) DB9 male connectors	Connects to RS-232, RS-422, or RS-485 serial devices.
3	(1) 2-wire terminal block connector	Removable 2-position terminal block with +, -, and chassis ground connections.
4	(2) Serial Port LEDs	Flashes green when data is being transmitted or received on the serial port. Lights steady green when the serial port is open.
5	(1) Ethernet Link LED	Lights when a connection is made. Flashes when there is data traffic on the Ethernet link.
6	(1) Ready LED	Lights green continuously when the unit is initializing. Flashes once per second when the system is operating correctly. Off when something is wrong, for example, another device uses the same IP address.
7	(1) Reset button	Used to initiate a hardware reset, enter console mode, or reload factory defaults.

2.4.3 4-Port Hardened Serial Server (LES424A)

Figures 2-5 and 2-6 show the front and side panels of the LES424A. Table 2-4 describes its components.




Figure 2-5. LES424A front panel.



Figure 2-6. LES424A back panel.

Table 2-4. LES424A components.

Number in Figure 2-5 or 2-6	Component	Description
1	(1) Power LED	Lights when power to the unit is on.
2	(1) Ready LED	Lights green continuously when the unit is initializing. Flashes once per second when the system is operating correctly. Off when something is wrong, for example, another device uses the same IP address.
3	(2) Ethernet Speed LEDs	Lights green when the Ethernet connection is operating at 100 Mbps. Off when the connection is operating at 10 Mbps.
4	(2) Ethernet Link LEDs	Lights when a connection is made. Flashes when there is data traffic on the Ethernet link.
5	(4) Serial Port LEDs	Flashes green when data is being transmitted or received on the serial port. Lights steady green when the serial port is open.
6	(4) DB9 male connectors	Connects to RS-232, RS-422, or RS-485 serial devices.
7	(2) RJ-45 connectors	Enable the server to act as an Ethernet switch.
8	(1) 3-wire terminal block connector	Removable 3-position terminal block with +, -, and chassis ground connections.
9	(1) Reset button	Used to initiate a hardware reset, enter console mode, or reload factory defaults.

2.5 Configuration Software

Manager configuration software enables you to find connected Hardened Serial Servers, configure them, upgrade Hardened Serial Server firmware, and save/load configuration files. It features a graphical user interface (GUI) that is convenient and easy to use. The software also makes it easy to add and remove virtual COM ports on your computer.

3. Installation and Initial Setup

This section describes how to install the Hardened Serial Server and configure the device.

NOTE: In this section, devices to be connected to the Hardened Serial Server's serial connections are simply referred to as the "serial device."

3.1 Connecting the Power Supply

Connect a DC power supply to the power terminals on the side of the Hardened Serial Server. Polarity of the wires is indicated underneath each connector. Acceptable voltages are between 10 VDC and 58 VDC. The power supply must be capable of supplying 4 watts for the LES421A or LES422A or 6 watts for the LES424A.




Figure 3-1. LES421A, LES422A, and LES424A power supply connections.

3.2 Connecting Hardened Serial Servers to Serial Devices

The Hardened Serial Servers can be connected to serial devices using RS-232, RS-422, RS-485 2-wire, or RS-485 4-wire communication. LES422A and LES424A models use (2) or (4) DB9 M connectors. LES421A models use either (1) DB9 M connector or (1) 5-position terminal strip.

3.2.1 RS-232

The 2- and 4-port models, along with the 1-port model when using its DB9M connector, support seven RS-232 signal lines (TD, RD, DTR, DSR, RTS, CTS, DCD) plus Signal Ground.

The 1-port model, when using its 5-position pluggable terminal block, supports four signal lines (TD, RD, RTS, CTS) plus Signal Ground.

NOTE: Only one connector (DB9M or 5-position terminal block) can be used on the LES421A.

Signals are single-ended and referenced to Signal Ground. Default communications parameters are 9600, 8, N, 1 (9600 baud, 8 data bits, no parity, 1 stop bit), and no flow control.

NOTE: The LES421A, LES422A, and LES424A are configured as DTEs. If they are connected to a computer or other DTE device, use a null-modem (crossover) cable. If the serial device is configured as a DCE, use a straight-through cable.

Chapter 3: Installation and Setup

3.2.2 RS-422

RS-422 connections support two signal pairs: TDA (-), TDB (+), RDA (-), RDB (+), and GND. The data lines are differential pairs (A and B) in which the B line is positive relative to the A line in the idle (mark) state. In RS-422, the transmitter is always enabled. Signal Ground provides a common mode reference for the signal lines.

3.2.3 RS-485

RS-485 connections support 2-wire or 4-wire operation. In RS-485 mode, the transmitter is only enabled when the Hardened Serial Server is transmitting data on the line. This allows other devices to share the bus.

When configured for 4-wire operation, the connection supports two signal pairs: TDA (-), TDB (+), RDA (-), RDB (+), and GND. This makes full-duplex operation possible. The data lines are differential pairs (A and B) in which the B line is positive relative to the A line in the idle (mark) state. Signal Ground provides a common mode reference for the signal lines.

When configured for 2-wire operation, the connection supports one signal pair: Data A (-) and Data B (+). These lines transmit and receive signals using half-duplex operation. The data lines are differential with the Data B line positive relative to Data A in the idle (mark) state. Signal Ground provides a common mode reference for the signal lines.

NOTE: Refer to Appendix B for connector pinout information.




Figure 3-2. LES424A connections.

3.3 Connecting RS-232/422/485 Hardened Serial Servers to a Network

Ethernet Connection (10BASE-T/100BASE-TX)

When connecting a Hardened Serial Server equipped with a 10BASE-T/100BASE-TX network connection (RJ-45 connector) to an Ethernet network, use a standard unshielded twisted-pair cable. When installing this equipment in industrial or other electrically noisy environments, we strongly recommend that you use STP (shielded twisted pair) cable. The Hardened Serial Server has an automatic MDI-X interface that will sense the pinout of the network interface and provide a crossover connection if required.

3.4 Ethernet Passthrough Port

4-Port Hardened Serial Servers (LES424A) are equipped with an additional RJ-45 network port, also known as a passthrough port. This port can be used to connect additional Ethernet devices, such as a local workstation or second serial server, to the network.




Figure 3-3. Ethernet passthrough port (on LES424A only).

3.5 Hardened Serial Server Configuration

The Hardened Serial Servers can be configured using three methods:

- Via the network using Hardened Serial Server Software.
- Via the network using a Web browser.
- Via a serial port using Hardened Serial Server Software (Console Mode).

3.5.1 Configuring via the Network using Hardened Serial Server Software

Hardened Serial Servers can be configured over the network using Hardened Serial Server Software running on a networked PC. Hardened Serial Server Software includes a discovery function that makes it possible to detect the Hardened Serial Server on the network if you do not know its IP address. Once the Hardened Serial Server has been detected, you can use the Hardened Serial Server Software to change its settings.

NOTE: For more information on how to use Hardened Serial Server Software to configure your Hardened Serial Server, refer to Chapter 4: Configuring the Hardened Serial Server.




Figure 3-4. Network setup.

3.5.2 Configuring via the Network using a Browser

Hardened Serial Servers can also be configured over the network using a standard internet browser, such as Internet Explorer® or Firefox® running on a networked PC. To do so, you must know the IP address of the Hardened Serial Server. Your Hardened Serial Server comes from the factory pre-configured to receive an IP address from a DHCP Server. If a DHCP server is not available, it will default to 169.254.102.39.

NOTE: For more information on how to use Hardened Serial Server Software to configure your Hardened Serial Server, refer to Chapter 4: Configuring the Hardened Serial Server.

3.5.3 Configuring via a Serial Port using Hardened Serial Server Software (Console Mode)

Your Hardened Serial Server can be configured via any serial port, using Hardened Serial Server Software. To use this feature, a serial port on the serial server must be connected to the serial port of a PC (using a null modem cable).




Figure 3-5. Console mode setup.

To configure the serial server, it must be put into Console Mode, using the Reset switch.

NOTE: Refer to Section 6.2 for information on how to use the Reset switch to enter Console Mode.

3.6 Hardened Serial Server Operational Connections

Hardened Serial Servers can operate in Direct IP, Virtual COM Port, and Paired Modes.

In Direct IP Mode, applications can use TCP/IP socket connections or UDP/IP datagrams to communicate with the COM ports on the serial server. In this type of application, the serial server is configured as a TCP or UDP server. The socket program running on the PC establishes a communication connection with the serial server. The data is sent directly to and from the serial port on the server.




Figure 3-6. Direct IP and Virtual COM port connection.

In Virtual COM Port Mode, the serial ports on the serial server appear to applications running on the host PC as if the serial ports were physically located on the host PC. When a virtual COM port is configured on the PC (using Serial Server Software), a new COM port appears in the Device Manager. Windows programs are able to interface to the virtual COM port using standard Windows API calls. When a program on the PC opens the new COM port, it communicates directly with the remote serial device connected to the serial server.

In Paired Mode, two Hardened Serial Servers are used to provide a virtual cable connection between two remote serial devices using the Ethernet network. The end serial devices communicate data and handshake information directly, as if they were physically connected in a point-to-point serial connection. Paired Mode devices are set up as shown in the following diagram and configured using Hardened Serial Server Software or a web interface.




Figure 3-7. Paired mode setup.

3.7 Installing and Starting Hardened Serial Server Software

Hardened Serial Server Software is a Windows-based application used to configure Hardened Serial Servers. Install it on your PC from the included CD. Installation should launch automatically when the CD is placed in the CD-ROM drive.

Follow the prompts to install the software.

Once the program is installed, go to the "Start > Programs" menu and run the program.

The Hardened Serial Server Software Discovery window appears.




Figure 3-8. Discovery window.

3.8 Discovering Hardened Serial Servers

If you are configuring the Hardened Serial Server via the network, select “Network”; if you are configuring it via the serial port, select “Serial Port.”

If you already know the IP address of the Hardened Serial Server, click “The device is at this IP address”; if not, leave “I don’t know the IP address of the device” selected.

Click “Connect.” The Progress text box and bar graph provide information to indicate whether serial servers are detected and how far along the process is.

The text in the Progress box appears in various colors, depending on the message type.

Table 3-1. Progress box text colors.

Color	Description
Black	A step in the discovery process.
Dark Blue	A device was not found.
Dark Green	A device was found.
Dark Red	An error occurred.

If one or more devices are found, the discovery window closes automatically and the Configuration window appears.

4. Configuring the Hardened Serial Server

4.1 Overview of the Hardened Serial Server Software

The Hardened Serial Server Software configuration window includes three areas:

- Icons
- Hardened Serial Server information table
- Configuration pane




Figure 4-1. Hardened Serial Server Software Configuration window.

NOTE: The screen shots shown in this manual refer to the LES421A. Your screen will display the model name/number and serial number of your device (LES421A, LES422A, or LES424A). All menus, functions and options shown on the screen shots in this manual apply to your LES421A, LES422A, or LES424A device.

4.1.1 Icons



Figure 4-2. Configuration Window Icons.

- Open—Open a Hardened Serial Server configuration file.
- Save—Save the current Hardened Serial Server configuration to a file.
- Search—Initiate a search for Hardened Serial Servers.

Chapter 4: Configuring the Hardened Serial Server

- Upgrade—Upgrade the firmware in a Hardened Serial Server (see Chapter 5).
- Add—Add a Virtual COM Port to the host PC (see Section 4.10).
- Remove—Remove a Virtual COM Port from the host PC (see Section 4.11).
- Diagnostic—Perform Hardened Serial Server diagnostics (see Chapter 7).

4.1.2 Hardened Serial Server Information Table

The Hardened Serial Server information table contains information about all Hardened Serial Servers that have been discovered on the network or serial ports.

Table 4-1. Serial server information table.

Server Name	Connection	Port 1	Port 2	Port 3	Port 4
LES421A	169.254.0.41	TCP:S:4000=COM5, in use	—	—	—
LES422A	169.254.0.42	TCP: 5000 = COM6	TCP: 5001 = COM7	—	—
LES424A	169.254.0.43	TCP: 6000 = COM8	TCP: 6001 = COM9	TCP: 6002 = COM10	TCP: 6003 = COM11

The table displays the following information for each Hardened Serial Server:

- Server Name—the name reported by the Hardened Serial Server.
- Connection—the IP address of the Hardened Serial Server.
- Port 1, Port 2, Port 3, and Port 4.
 - Communications protocol assigned to the serial port (TCP, UDP, or Paired mode).
 - Whether the port initiates connections (Client mode) or accepts connections (Server mode).
 - TCP port number or UDP port number.
 - The virtual COM port assignment on the local PC (if assigned).
 - Whether the Hardened Serial Server's serial port is being used by anyone on the network.

The status of whether the Hardened Serial Server in use is updated periodically.

When a Hardened Serial Server's IP address is configured for a network that is not within the local network's range, the Hardened Serial Server's information is displayed in a different color (yellow).

4.1.3 Configuration Pane

The configuration pane is essentially a Web browser.




Figure 4-3. Configuration Pane.

It includes the following:

- Masthead with the name and IP address of the currently selected Hardened Serial Server.
- Contents sidebar (on the left side) containing hyperlinks to the following configuration pages:
 - General
 - Network
 - Port x Serial (x = port number; each serial port connection is represented by a hyperlink)
 - Port x Network (x = port number; each serial port connection is represented by a hyperlink)
 - Save
 - Login/Logout
- Configuration settings area in the middle of the pane where you can select the settings desired for operation of the Hardened Serial Server.
- Help sidebar (on the right side) containing helpful descriptions, explanation, and suggestions for configuring the serial server.

4.2 Logging In

You can log in to any Hardened Serial Server listed in the Server Information Table.

To log in:

1. Select the row associated with the desired Hardened Serial Server. The Login page appears.
2. Type the password into the Password box. The default password is blank.




Figure 4-4. Login page.

3. Click "Login."

The "General Configuration" page appears.

Chapter 4: Configuring the Hardened Serial Server

4.3 Navigating the Configuration Pages

There are two ways to move from page to page in the Hardened Serial Server Software: by clicking a specific link, or by clicking “Next” or “Back” to move through the pages sequentially.

NOTE: Always remember to click “Save” before leaving a page to ensure your settings are saved.

4.4 Setting Up the Hardened Serial Server Name and Password

On the General Configuration page you can do the following:

- Change the name of the Hardened Serial Server.
- Initiate a login password change.




Figure 4-5. General Configuration page.

4.4.1 Changing the Hardened Serial Server's Name

1. Type the new name into the “Hardened Serial Server Name” text box.
2. Click “Save.”

4.4.2 Changing the Password

1. Select the “I want to change the password” check box.

Two text boxes appear.

Type the new password:

Type the new password again to confirm it:

Figure 4-6. Changing the password.

2. Type the new password into both boxes.
3. Click “Save.”

4.5 Setting Up IP Addressing

On the Network Configuration page, you can configure the Hardened Serial Server to use dynamic (DHCP) or static IP addressing on the network.




Figure 4-7. Network Configuration page.

4.5.1 Setting Up Dynamic IP Addressing

1. Select the “I want to use DHCP to setup the network” check box.

4.5.2 Setting Up Static IP Addressing

1. Ensure the “I want to use DHCP to setup the network” box is unchecked.

Network

I want DHCP to setup the network.

IP Address:

Subnet Mask:

Default Gateway:

Figure 4-8. IP Address settings.

2. Type the IP Address, Subnet Mask, and Default Gateway addresses in the appropriate boxes.

Chapter 4: Configuring the Hardened Serial Server

4.6 Setting Up Serial Ports

On the Serial Port Configuration page, you can configure the communications parameters of the current serial port. Parameters include the port mode, baud rate, data bits, parity, stop bits, and type of flow control.




Figure 4-9. Serial Port Configuration page.

1. Mode—select the type of serial connection (RS-232, RS-422, RS-485 2-wire, or RS-485 4-wire) required by the serial device.
2. Baud Rate—select the Baud Rate (between 75 baud and 230,400 baud) required to communicate with the serial device.
3. Data Bits—select the number of Data Bits (5, 6, 7, or 8) required to communicate with the serial device.
4. Stop Bits—select the number of Stop Bits (1, 1.5, or 2) required to communicate with the serial device.
5. Parity—select the Parity setting (None, Even, Odd, Mark, or Space) required to communicate with the serial device.
6. Flow Control—select the Flow Control setting (None, RTS/CTS, or X-ON/X-OFF) required to communicate with the serial device.

4.7 Setting Up Port Network Parameters

On the Port Network Parameters Configuration page, you can configure the port to use UDP, TCP, VCOM, or Paired protocols in several different modes.

4.7.1 TCP Configuration

Transmission Control Protocol (TCP) provides reliable connection-oriented network communication with error checking. In TCP mode, the Hardened Serial Server can be configured as a client or a server.

When you configure the Hardened Serial Server as a TCP client, it initiates a connection with a remote server on the network. You must set up the IP address and port number of the remote server that you want the client (Hardened Serial Server) to communicate with. You also select whether you want the Hardened Serial Server to connect at power up or only when it receives data from the device connected to its serial port.

When the Hardened Serial Server is configured as a TCP server, it waits for an incoming connection request from another network device. You must set up the TCP port number that the Hardened Serial Server will listen for incoming connections and set the maximum number of simultaneous connections it will support (one for the LES421A, up to two for the LES422A, and up to four for the LES424A). You can also set up the Hardened Serial Server to accept incoming connection requests only from certain IP addresses or ranges of IP addresses.

The screenshot shows the configuration page for the Hardened Serial Server, titled "BLACK BOX Hardened Serial Server" with the IP address (192.168.1.104) in the top right. The page is divided into three main sections: "Contents", "Port 1 - Network", and "Help".

- Contents:** A sidebar menu with links for General, Network, Port 1 Serial, Port 1 Network (highlighted), Save, and Logout.
- Port 1 - Network:** The main configuration area. It starts with "I want to use this network protocol:" and has radio buttons for TCP (selected), UDP, VCOM, and Paired. Below this, it asks "I want to connect to IP address:" with a text box containing "169.254.0.42". Underneath, it asks "on TCP port number:" with a text box containing "4000". At the bottom, there are two radio buttons: "at power up" (selected) and "when the serial port receives data". At the very bottom of this section are buttons for "Save", "Back", "Next", and "Advanced".
- Help:** A sidebar with text explaining the "Network Protocol", "TCP Mode", "Connect to Address", "Connect to Port", and "Connect on controls" options.

Figure 4-10. TCP configuration.

Setting the Hardened Serial Server to operate as a TCP Client


1. Select "TCP" protocol.
2. Select "to initiate connections (client)."
3. Type the IP address into the "I want to connect to IP address:" box.
4. Type the TCP port number of the server into the "on TCP port number:" box.
5. Select:
 - "at power up"—if you want the Hardened Serial Server to always be connected.
 - "when the serial port receives data"—if you only want to establish a connection when there is data to be sent.

Setting the Hardened Serial Server to operate as a TCP Server

1. Select TCP protocol.
2. Select "to wait for connections (server)."

The configuration options change. The server IP address box disappears and the "number of connections" box appears.

3. Type the port number in the "I want to wait for connection on TCP port number:" box.
4. Select the maximum number of connections desired in the "and limit the number of connections to:" drop down box.



I want to wait for connections on TCP port number:

and limit the number of connections to:

and allow everyone to connect
 and allow a specific IP address to connect
 and allow a specific range of IP addresses to connect

Figure 4-11. TCP server settings.


4.7.2 UDP Configuration

UDP (User Datagram Protocol) enables applications using UDP socket programs to communicate with the serial ports on the Hardened Serial Server. UDP protocol provides connectionless communications, which allows data to be broadcast to and received from multiple nodes on a network.

In UDP mode, if you want to control which network node receives data, you must specify the IP address and UDP port the data will be sent to. You can choose to send to:

- Nobody (Port only in receive mode)
- All nodes at a specific UDP port number. (This is a broadcast message.)
- Specific IP addresses and UDP port numbers. (This is a unicast message.)
- A range of IP addresses and UDP port numbers. (This is a unicast range.)

You can also configure the Hardened Serial Server to receive from nodes on the network using a similar list of configuration options.



BLACK BOX (192.168.1.104)
Hardened Serial Server

Contents
[General](#)
[Network](#)
[Port 1 Serial](#)
[Port 1 Network](#)
[Save](#)
[Logout](#)

Port 1 - Network

I want to use this network protocol:
 TCP UDP VCOM Paired

I want to send data to:
 nobody
 everyone on a specific UDP port (send broadcast)
 only specific IP addresses (send unicast)
 only a range of IP addresses (send unicast range)

I want to receive data from:
 nobody
 everyone on a specific UDP port (receive broadcast)
 only specific IP addresses (receive unicast)
 only a range of IP addresses (receive unicast range)

Help
Network Protocol controls the protocol used to communicate with the serial server. This can be TCP for a TCP server or TCP client connection, or UDP for connectionless data, VCOM for virtual communications port, or Paired using two serial servers together.
[Send to Mode controls ...](#)
[Receive from Mode controls ...](#)

Figure 4-12. UDP configuration.

Setting the Hardened Serial Server to use UDP

1. Select UDP protocol.

Options are provided for sending and receiving data to and from:

- Nobody (one-way communication only).
- Everyone on a specific UDP port.
- Only specific IP addresses.
- Only a range of IP addresses.

Additional configuration fields appear depending on the options chosen.

2. Select the required “Send” options:

- a. “nobody”—sends to nobody.
- b. “everyone on a specific UDP port (send broadcast)”—sends to all UDP ports on the network (specified later).
- c. “only specific IP addresses (send unicast)”—sends to specific network IP addresses (specified later).
- d. “only a range of IP addresses (send unicast range)”—sends to all IP addresses within a specified range (specified later).

3. Configure the “Send IP addresses and port numbers:”

- If you selected: “everyone on a specific UDP port (send broadcast),” type the UDP port number into the “This is the UDP port I want to send data to:” box.
- If you selected: “only specific IP addresses (send unicast),” type the IP addresses and port numbers into the “These are the IP addresses I want to send data to:” text boxes.
- If you selected: “only a range of IP addresses (send unicast range),” type the ranges of IP addresses and port numbers into the “These are the IP addresses I want to send data to:” text boxes.

4. Select the required “Receive” options:

- a. “nobody”—receives from nobody
- b. “everyone on a specific UDP port (receive broadcast)”—receives from all UDP ports on the network (specified later).
- c. “only specific IP addresses (receive unicast)”—receives from specific network IP addresses (specified later).
- d. “only a range of IP addresses (receive unicast range)”—receives from all IP addresses within a specified range (specified later).

5. Configure the “Receive IP addresses and port numbers:”

- If you selected: “everyone on a specific UDP port (receive broadcast),” type the UDP port number into the “This is the UDP port I want to receive data from:” box.
- If you selected: “only specific IP addresses (receive unicast),” type the IP addresses and port numbers into the “These are the IP addresses I want to receive data from:” text boxes.
- If you selected: “only a range of IP addresses (receive unicast range),” type the ranges of IP addresses and port numbers into the “These are the IP addresses I want to receive data from:” text boxes.

6. Click “Save.”

4.7.3 Setting Up Virtual COM (VCOM) Operation

When the Network Protocol is set to VCOM (Virtual COM Port), the Hardened Serial Server communicates over the network with a PC, acting as a remote COM port for the computer.




Figure 4-13. VCOM configuration.

NOTE: Both the Hardened Serial Server and the computer must be configured for VCOM operation. To set up a virtual COM port on the computer, refer to "Adding Virtual COM Ports" (Section 4.10).

1. To enable VCOM operation, select "VCOM" protocol.
2. Click "Save."

4.7.4 Setting Up Paired Mode Operation

Paired Mode enables two Hardened Serial Servers to operate across the network like a "wire replacement" between two serial devices. (Paired Mode is also called serial tunneling.) Serial devices connected to serial servers on each end of the link can communicate as if they were connected by a serial cable.

For Paired Mode to work one Hardened Serial Server must be configured "to initiate connections (client)" and the other must be configured "to wait for connections (server)."

The Hardened Serial Server configured as the client initiates the connection. You must set up the IP address and port number of the server that you want the client (Hardened Serial Server) to communicate with. You also select whether you want the Hardened Serial Server to connect at power up or only when it receives data from the device connected to its serial port.

The Hardened Serial Server configured as a server waits for a connection to be initiated by the remote client. You must set up the TCP port number on which it will listen for connections and set the maximum (up to four) number of simultaneous connections it will accept. The maximum number of connections should be set to at least two (2) to allow the unit to recover if the connection is terminated abnormally. You can filter the connections it will accept based on specific IP addresses or ranges of IP addresses that you specify.





Figure 4-14. Paired Mode configuration.

Setting the Hardened Serial Server to operate in Paired Mode as a client

1. Select “Paired” protocol.
2. Select “to initiate connections (client).”
3. Type the IP address and TCP port numbers of the server in the appropriate text boxes.
4. Select:
 - “at power up”—if you want the Hardened Serial Server to always be connected.
 - “when the serial port receives data”—if you only want to establish a connection when there is data to be sent.

Setting the Hardened Serial Server to operate in Paired Mode as a server


1. Select “Paired” protocol.
2. Select “to wait for connections (server).”



The screenshot shows the configuration window for Paired Mode as a server. At the top, there are two radio button options: "to initiate connections (client)" and "to wait for connections (server)". The "to wait for connections (server)" option is selected. Below this, there is a text input field for the TCP port number, which contains the value "4000". Underneath, there is a label "and limit the number of connections to:" followed by a dropdown menu currently set to "1 connection". At the bottom, there are three radio button options: "and allow everyone to connect" (which is selected), "and allow a specific IP address to connect", and "and allow a specific range of IP addresses to connect".

Figure 4-15. Paired Mode settings.

3. Type the TCP port number to be used in the “I want to wait for connections on TCP port number” box.
4. Select the number of connections in the “and limit the number of connections to” drop down box.
5. Select:
 - “and allow everyone to connect”—if you want any server to connect.
 - “and allow a specific IP address to connect”—if you want to specify up to four IP addresses to be able to connect.
 - “and allow a specific range of IP addresses to connect”—if you want to specify a range of IP addresses that can connect.
6. If you selected:
 - “and allow a specific IP address to connect,” in the area of the window that appears, select one or more IP address boxes and type in the desired IP address.




The screenshot shows a window titled "These are the IP addresses I want to allow to connect:". It contains four rows, each with a checkbox and a text input field for an IP address. The IP addresses listed are 169.254.0.51, 169.254.0.52, 169.254.0.53, and 169.254.0.54. All checkboxes are currently unchecked.

Figure 4-16. IP addresses.

Chapter 4: Configuring the Serial Server

- “and allow a specific range of IP addresses to connect,” in the area of the window that appears, select an IP address box and type in the IP addresses that specify the desired range.



These are the IP address range I want to allow to connect:

IP address: 169.254.0.50 through: 169.254.0.60

IP address: 169.254.0.70 through: 169.254.0.80

IP address: 169.254.0.90 through: 169.254.0.100

IP address: 169.254.0.110 through: 169.254.0.120

Figure 4-17. IP address ranges.

4.8 Setting Up Advanced Network Settings

On the “Advanced Network Settings” window, you can configure if network connections are automatically closed due to inactivity and when serial data is forwarded to the network.

Data that is received by the serial port is normally buffered for a short period of time and then forwarded over the Ethernet to the remote device. The Hardened Serial Server automatically optimizes the data buffering to reduce the network overhead and minimize the data transmission latency. For most applications, the Hardened Serial Server will transmit data back and forth seamlessly between the end devices. However, certain applications may require additional control over this process. In these cases, the “Advanced Port Settings” can be used to fine-tune the Hardened Serial Server performance.



BLACK BOX (192.168.1.104)
Hardened Serial Server

Contents

- [General](#)
- [Network](#)
- [Port 1 Serial](#)
- [Port 1 Network](#)
- [Save](#)
- [Logout](#)

Port 1 - Advanced

I want to control when connections would be forced closed.

I want to control when data packets are sent over the network.

Help

Figure 4-18. Advanced Network Settings Window with nothing selected.

4.8.1 Configuring When Network Connections will be Forced Closed

1. Select the “I want to control when connections would be forced closed” checkbox.

The “Network Watchdog” and “Serial Watchdog” configuration boxes appear.




Figure 4-19. Advanced configuration—forcing connections closed.

To close a network connection if no data is received from the network for a period of time:

1. Select the “I want to close a connection when data is not received on that connection for a period of time” checkbox.
2. Type the desired time period (in seconds) into the text box.

To close a connection if no data is received by the serial port for a period of time:

1. Select the “I want to close all connections when data is not received by the serial port for a period of time” checkbox.
2. Type the desired time period (in milliseconds) into the text box.

4.8.2 Configuring when Data Packets are Sent

1. Select the “I want to control when data packets are sent over the network” checkbox.

The “Character Count,” “Forced Transmit,” “Intercharacter Timeout,” “Delimiter 1,” “Delimiter 2,” and “Delimiter Removal” configuration boxes appear.

BLACK BOX (192.168.1.104)
Hardened Serial Server

Contents
[General](#)
[Network](#)
[Port 1 Serial](#)
[Port 1 Network](#)
[Save](#)
[Logout](#)

Port 1 - Advanced

I want to control when connections would be forced closed.

I want to control when data packets are sent over the network.

Character Count

I want to wait for a specific amount of data to be received by the serial port before sending it.

characters

Forced Transmit

I want to wait no longer than a specific amount of time after data is received before sending it.

milliseconds

Intercharacter Timeout

I want to send data immediately when no more characters are received for:

milliseconds

Delimiter 1

I want to send data immediately when a specific character is received by the serial port.

ASCII value for character

Delimiter 2

I want to send data immediately when another specific character is received by the serial port.

ASCII value for character

Delimiter Removal

I want to remove the delimiter characters from the data before sending the data.

Help

Character Count controls the maximum number of characters to buffer before sending the characters to the network. Larger values will decrease the number of network packets, but will increase the amount of time to receive characters. Smaller values will increase the number of network packets, but will decrease the amount of time to receive characters. The range is 1 through 65535.

Forced Transmit controls the maximum amount of time that characters can be buffered before sending the characters to the network. Larger values will decrease the number of network packets, but will increase the amount of time to receive characters. Smaller values will increase the number of network packets, but will decrease the amount of time to receive characters. The range is 1 through 65535.

Intercharacter Timeout controls the maximum duration between received characters before sending the characters to the network. Larger values may decrease the number of network packets, but will increase the amount of time to receive characters. Smaller values may increase the number of network packets, but will decrease the amount of time to receive characters. The range is 1 through 65535.

Delimiter 1 controls sending of received characters to the network. When this character is received, the data is sent to the network. The range is 0 through 255.

Delimiter 2 controls sending of received characters to the network. When this character is received, the data is sent to the network. The range is 0 through 255.

Delimiter Removal controls removing of Delimiter 1 and Delimiter 2 from the received characters before the received characters are sent to the network.

Figure 4-20. Advanced Configuration—Configuring when data packets are sent.

To wait until a specific amount of data is received on the serial port before sending it across the network:

1. Select "I want to wait for a specific amount of data to be received by the serial port before sending it" in the "Character Count" box.
2. Type the desired number of characters into the text box.

To force the Hardened Serial Server to send all buffered data received on the serial port within a specified length of time:

1. Select "I want to wait no longer than a specific amount of time after data is received before sending it" in the "Forced Transmit" box.
2. Type the desired time period (in milliseconds) into the text box.

To force the Hardened Serial Server to send buffered data if another character is not received within a certain period of time:

1. Select "I want to send data immediately when no more characters are received for" in the "Intercharacter Timeout" box.
2. Type the desired time period (in milliseconds) into the text box.

To force the Hardened Serial Server to start buffering data only when it receives a specified ASCII character on its serial port:

1. Select "I want to send data immediately when a specific character is received by the serial port" in the "Delimiter 1" box.
2. Type the decimal value for the ASCII character into the text box. For instance, if you want to send data when a "\$" is received, enter "36" into the text box.

NOTE: If Delimiter 1 is selected, Delimiter 2 must also be used.

To force the Hardened Serial Server to send its buffered data when it receives a specified ASCII character on its serial port:

1. Select "I want to send data immediately when another specific character is received by the serial port" in the "Delimiter 2" box.
2. Type the decimal value for the ASCII character into the text box. For instance, if you want to send data when a "\$" is received, enter "36" into the text box.

To force the Hardened Serial Server to remove the delimiter characters from the received data when it sends it on to the Ethernet network:

Select "I want to remove the delimiter characters from the data before sending the data."

4.9 Saving/Restoring the Configuration Settings

When all configuration windows are complete, the "Save Configuration" page appears.




Figure 4-21. Save Configuration page.

To save the configuration to the Hardened Serial Server, and re-boot it so that the configuration settings will take effect:

1. Click "Save."

4.10 Adding Virtual COM Ports

Clicking the "Add" icon (located at the top of the Hardened Serial Server Software Configuration window) opens the Add Virtual COM Port dialog box.




Figure 4-22. Add Virtual COM Port dialog box.

Using the drop-down boxes, you can select the Hardened Serial Server you want to map the virtual COM port to, the number of the serial port on the Hardened Serial Server, and the COM port on the local computer. The information box displays the server name, its IP address, operating mode, and TCP port.

1. On the Hardened Serial Server Software window, click the "Add" icon.

The "Add Virtual COM Port" dialog box appears.

2. Select the Hardened Serial Server to which you want to map the virtual COM port.
3. Select the serial port number on the Hardened Serial Server.
4. Select the COM port number you want to use on the local computer.
5. Click the "Add" button.

When the process of adding the virtual COM port is complete (indicated by the progress bar), the “Serial port is successfully installed” dialog box appears.

6. Click “OK.”

4.11 Removing Virtual COM Ports

Clicking the “Remove” icon (located at the top of the Hardened Serial Server Software Configuration window) opens the “Remove Virtual COM Port” dialog box.




Figure 4-23. Remove Virtual COM Port dialog box.

Using the drop-down box, you can select the virtual COM port on the local computer. The information box displays the server name, its IP address, operating mode, and TCP port.

1. Click the “Remove” icon.

The “Remove Virtual COM Port” dialog box appears.

2. Select the COM port number you want to remove from the local computer.

3. Click the “Remove” button.

When the process of removing the virtual COM port is complete (indicated by the progress bar), the “Serial port is successfully deleted” dialog box appears.

4. Click “OK.”

5. Upgrading the Hardened Serial Server Firmware

Occasionally, updated firmware may become available for your Hardened Serial Server. The firmware can be upgraded using the Hardened Serial Server Software. The following procedure describes the firmware updating process:

1. Click the “Upgrade” button to open the Firmware Upgrade window.




Figure 5-1. Firmware Upgrade dialog box.

The name of the currently selected Hardened Serial Server appears in the top drop down list. Other Hardened Serial Servers (that have already been discovered) can be selected from the drop-down list, if desired.

The current firmware version of the selected Hardened Serial Server is shown in the text below the Hardened Serial Server name. Information about the selected firmware file is shown in the third text box.

5.1 Downloading Firmware Files

The “Firmware File” list (second box) displays all firmware files in the firmware installation folder. Only firmware that is compatible with the selected Hardened Serial Server is available in this list.

To download the latest firmware files from an FTP site on the Internet:

1. Click the “Internet” button at the bottom of the window.

The Hardened Serial Server Software connects to an FTP server on the Internet.

2. Click the “Check for Updates” button.

“Progress Bar” and “Progress Box” display information about and progress of the download.

To download the latest firmware files from a file:

1. Click the “Browse” button to open an “Open File” dialog box.
2. Browse to the drive and folder containing the firmware file.
3. Select and download the file to the local firmware folder.

5.2 Uploading the Firmware to the Hardened Serial Server

1. In the "Hardened Serial Server Selection" drop-down list, select the Hardened Serial Server to be upgraded.
2. In the "Firmware Description" drop-down list, select the firmware to upload to the Hardened Serial Server.
3. Click the "Upgrade" button.

"Progress Bar" and "Progress Box" provide information on the progress of the transfer.

4. In the "Firmware File" drop-down list, select the firmware file to upload to the Hardened Serial Server.
5. Click "Upgrade."

The Progress box and Progress bar display information on the upgrading process.

6. When the upgrade process is complete, click "Close."

6. Operation

6.1 LED Indicators

Hardened Serial Servers have LED indicators for Power, Serial Server Ready, Ethernet Speed and Link status, and Serial Port status. Figures 6-1 through 6-3 show the location of the LEDs on the LES421A, LES422A, and LES424A servers.




Figure 6-1. Front and top panels of the LES421A.

Table 6-1. LEDs and switches on the LES421A serial server.

Number in Figure 6-1	LED Indicator	Description
1	(1) Serial Port LED (P1)	The serial port has an associated LED. The Serial Port LED flashes (green) when data is being transmitted or received on the serial ports. When the LED is illuminated, it indicates the serial port is open.
2	(1) Ready LED	The Ready LED (green) illuminates continuously while the unit is initializing. It flashes once per second when the system is operating correctly. If the LED is not flashing, it indicates that something is wrong (e.g., another device on the network at the same IP address).
3	(1) Ethernet Link LED	Lights when a connection is made. Flashes when there is data traffic on the Ethernet link.
4	(1) Reset switch	A recessed momentary Reset switch is located on the side of the enclosure. To activate the switch, insert a small plastic tool through the hole in the enclosure and press lightly.




Figure 6-2. Front panel of the LES422A.

Table 6-2. LEDs and switches on the LES422A serial server.

Number in Figure 6-2	LED Indicator	Description
1	(2) Serial Port LEDs (P1, P2)	Each serial port has an associated LED. The Serial Port LED flashes (green) when data is being transmitted or received on the serial ports. When the LED is illuminated, it indicates the serial port is open.
2	(1) Ready LED	The Ready LED (green) illuminates continuously while the unit is initializing. It flashes once per second when the system is operating correctly. If the LED is not flashing, it indicates that something is wrong (e.g., another device on the network at the same IP address).
3	(1) Ethernet Link LED	Lights when a connection is made. Flashes when there is data traffic on the Ethernet link.
4	(1) Reset switch	A recessed momentary Reset switch is located on the side of the enclosure. To activate the switch, insert a small plastic tool through the hole in the enclosure and press lightly.




Figure 6-3. Front panel of the LES424A.

Table 6-3. LEDs on the LES424A serial server.

Number in Figure 6-3	LED Indicator	Description
1	(1) Power LED	The Power LED illuminates when 10 to 58 VDC power is applied to either power connector.
2	(1) Ready LED	The Ready LED (green) illuminates continuously while the unit is initializing. It flashes once per second when the system is operating correctly. If the LED is not flashing, it indicates that something is wrong (e.g. another device on the network at the same IP address).
3	(2) Ethernet Speed LEDs	Lights green when the Ethernet connection is operating at 100 Mbps. Off when the connection is operating at 10 Mbps.
4	(2) Ethernet Link LEDs	Lights when a connection is made. Flashes when there is data traffic on the Ethernet link.
5	(4) Serial Port LEDs (P1, P2, P3, and P4)	Each serial port has an associated LED. Serial Port LEDs flash (green) when data is being transmitted or received on the serial ports. When the LED is illuminated, it indicates the serial port is open.
6	(1) Reset switch	A recessed momentary Reset switch is located on the side of the enclosure. To activate the switch, insert a small plastic tool through the hole in the enclosure and press lightly.

NOTE: LEDs on the Hardened Serial Server are also used to indicate various Reset modes, as described in the following section.

6.2 Reset Switch

Figure 6-4 shows the location of the Reset switch on the LES421A, LES422A, and LES424A Hardened Serial Servers.




Figure 6-4. Left: top view of the LES421A or LES422A; Right: back view of the LES424A.

The Reset switch is used to:

- Initiate a hardware reset.
- Enter Console mode.
- Reload factory defaults.

6.2.1 Using the Reset Switch to Initiate a Hardware Reset

Hold the Reset switch in for 0 to 2 seconds. The P1 LED illuminates while the switch is being held in. Release the switch in less than two seconds or the Hardened Serial Server will enter Console Mode.

6.2.2 Using the Reset Switch to Enter Console Mode

Hold the Reset switch for between two and ten seconds. The P1 LED illuminates for the first two seconds and the P1 LED goes out, then the P2 LED illuminates until the Reset switch is released. Release the switch in less than 10 seconds or the Hardened Serial Server will reset to factory default settings. The Hardened Serial Server will re-boot and enter Console Mode. LED P1 will be on while the unit is in Console Mode.

6.2.3 Using the Reset Switch to Exit Console Mode

Press the Reset switch for less than two seconds, or remove power from the Hardened Serial Server, wait a few seconds, and turn the power on again. The LEDs go back to their normal states when the device resumes normal operation.

6.2.4 Using the Reset Switch to Reload Factory Default Settings

Hold the Reset switch for more than ten seconds. The P1 LED illuminates for the first two seconds; then the P2 LED illuminates. After 10 seconds the P1 and P2 LEDs will illuminate. When the switch is released, both the P1 and P2 LEDs will go out. The Ready LED will flash quickly while the Hardened Serial Server re-initializes to factory default settings, and then the server will re-boot.

7. Diagnostics

Clicking the “Diagnostics” icon opens the Diagnostics dialog box and enables you to check the operation of connected serial servers and VCOM ports on the local computer.

The Computer Information box displays information about the type of network connections, the IP addresses, Subnet Masks, and Default Gateways in use.




Figure 7-1. Diagnostics dialog box.

7.1 Testing a Hardened Serial Server Connection

1. Click the “Diagnostics” icon.

The “Diagnostics” dialog box appears.

2. Select the option: “a serial server”

3. In the drop-down box, select the specific serial server you want to check.

4. Click the “Start” button.

Information about the progress of the pinging process is displayed in the “Test Progress” box.




Figure 7-2. Testing a Hardened Serial Server Connection.

7.2 Testing a Virtual COM Port

1. Click the “Diagnostics” icon.

The “Diagnostics” dialog box appears.

2. Select the option: “a virtual communications port”

3. In the drop-down box, select the specific COM port you want to check.

4. Click the “Start” button.

Information about the progress of the pinging process is displayed in the “Test Progress” box.




Figure 7-3. Testing a VCOM port.

8. Listing/Descriptions of Hardened Serial Server Settings

The following Hardened Serial Server properties are ordered alphabetically to assist you in finding the information you need.

Baud Rate is the communication speed of the link between the Hardened Serial Server and the device attached to its serial port. Both devices must be configured to operate at the same baud rate. Baud rate values range from 75 to 230,400 Baud. (Refer to Chapter 1 for specific baud rates that are supported.)

Character Count controls the maximum number of characters to buffer before sending the characters to the network. Larger values decrease the number of network packets, but increase the amount of time to receive characters. Smaller values increase the number of network packets, but decrease the amount of time to receive characters. The range is 1 through 65535.

Configuration files contain all of the configuration settings for the Hardened Serial Server. When the Hardened Serial Server settings have been configured, you can save the settings using Hardened Serial Server Software. Existing configuration files can be Opened (from Hardened Serial Server Software), which loads them into the Hardened Serial Server. This allows the same configuration to be applied to multiple Hardened Serial Servers, or to reload a previously used configuration.

Data/Parity/Stop Bits. The number of Data bits, type of Parity, and number of Stop bits selected define the serial port parameters at which the Hardened Serial Server will operate. These parameters must be configured to match the parameters set on the serial device connected to the Hardened Serial Server's serial port.

- **Data Bits** controls the number of bits of data in each character. Options include 5, 6, 7, or 8 data bits.
- **Parity** controls the error-checking mode. Options are No Parity, Odd, Even, Mark, or Space.
- **Stop Bits** controls the number of bits to indicate the end of a character. Options include 1, 1.5, and 2. (1.5 bits is only valid when 5 data bits is selected, which is rare. The 2 stop bits setting is only valid when 6, 7, or 8 data bits is selected.)

The **Default Gateway** address sets the default route to remote networks, enabling users to access the Hardened Serial Server from outside the local network.

Delimiter 1, Delimiter 2, and Delimiter Removal. Delimiters and Delimiter Removal enable you to control how characters received on a serial port are sent across the network. Delimiters are ASCII characters specified by the user when configuring the Hardened Serial Server. The Hardened Serial Server takes action when it recognizes the specified character(s) on its serial port.

- **Delimiter 1** is a start delimiter. The range of ASCII values is 0 through 255.
- **Delimiter 2** is an end delimiter. The range of ASCII values is 0 through 255.
- **Delimiter Removal** controls removing of Delimiter 1 and Delimiter 2 from the received characters before the received characters are sent to the network.

How Delimiters Work. When only Delimiter 2 (the end delimiter) is enabled, characters received by the serial port are accumulated in a buffer. When the end delimiter is received on the serial port, the buffered characters, including the end delimiter, are sent to the network. All characters received after the end delimiter are again buffered until another end delimiter is received.

When both Delimiter 1 (start delimiter) and Delimiter 2 (end delimiter) are enabled, characters received by the serial port will be discarded until the start delimiter character is detected on the serial port. The Hardened Serial Server then buffers the start delimiter character and all subsequent characters received after it until the end delimiter is detected. When the end delimiter is received, the buffered characters, including the start and end delimiters, are sent to the network.

When Delimiter Removal is enabled, the Hardened Serial Server removes the delimiter character(s) before sending the other characters across the network.

Chapter 8: Listing/Descriptions of Hardened Serial Server Settings

Dynamic Host Configuration Protocol (DHCP) is a protocol used on special servers that supply IP addresses to network nodes on request.

When DHCP is enabled on the Hardened Serial Server, on power up it sends a DHCP request to the DHCP server, which assigns a dynamic IP address, subnet mask, and default gateway to the Hardened Serial Server.

When DHCP is disabled (static IP addressing), the IP Address, Subnet Mask and Default Gateway fields must be set manually by entering the appropriate addresses in these fields. If you do not know what addresses to use in these fields, ask your network administrator.

NOTES:

- 1. This product is factory-defaulted to the DHCP mode. Your network's DHCP Server is expected to provide the IP address assignment. If there is not a DHCP server on your network, the device will default to IP address 169.254.102.39.*
- 2. A dynamic address assigned by the DHCP server may change if the server loses the Ethernet connection or power is removed. If a device on the network that normally communicates with the Hardened Serial Server is configured to communicate with a specific IP address of the Hardened Serial Server, and the IP address has been changed, the device will not be able to communicate with the Hardened Serial Server.*

The **Firmware Version** number (Vx.x.x) indicates the Hardened Serial Server's currently loaded firmware release. From time to time new firmware is made available and can be uploaded into the serial server using Hardened Serial Server Software.

Flow Control determines the type of handshaking that is used to control sending and receiving of messages. Options include No Flow Control, Hardware Flow Control (RTS/CTS) and Software Flow Control (X-ON/X-OFF). The Flow Control setting must match the requirements of the serial device connected.

NOTE: Select No Flow Control when setting the port as RS-422 or RS-485 4-wire.

Forced Transmit controls the maximum amount of time that characters can be buffered before sending the characters to the network. Larger values decrease the number of network packets, but increase the amount of time to receive characters. Smaller values increase the number of network packets, but decrease the amount of time to receive characters. The range is 1 through 65535.

The **Hardware Version** number of the Hardened Serial Server hardware is displayed on the Login page of the Hardened Serial Server Software.

Inter-character Timeout controls the maximum duration between received characters before sending the characters to the network. Larger values may decrease the number of network packets, but increase the amount of time to receive characters. Smaller values may increase the number of network packets, but decrease the amount of time to receive characters. The range is 1 through 65535.

IP Address. Software or hardware attempting to access the Hardened Serial Server via the network must know the IP Address of the server. In DHCP mode (factory default), the serial server requests and receives a dynamic IP address from a DHCP server when it first connects to the network. If there is not a DHCP Server on your network, this device will automatically default to IP Address **169.254.102.39**. If the Hardened Serial Server is unable to connect to your network using this address, there are two methods to manually configure the IP Address.

1. Method One: Change your PC Network to Match the Hardened Serial Server
 - a. Open the network connection on your PC.




Figure 8-1. Network IP properties.

b. Click "Internet Protocol (TCP/IP)" and then click "Properties." Change the parameters to the following:

- IP Address = 169.254.102.1
- Subnet Mask = 255.255.255.0
- Default Gateway = 169.254.102.100




Figure 8-2. TCP/IP properties.

- c. Use the Hardened Serial Server Software to search for, discover, and configure the unit.
2. Method Two: Change the Hardened Serial Server's network setting to match your PC using Console mode.
 - a. Connect a null-modem serial cable (crossover cable) from any port on the Hardened Serial Server to an available COM port on your PC.
 - b. Open Hardened Serial Server Software and connect to the COM port used in the previous step. Ensure the port is configured to 115,200 baud, 8 data bits, and 1 stop bit.
 - c. Enter Console Mode. Press and hold the serial server's reset switch for 2 to 10 seconds. The LED indicators will respond as follows:

Table 8-1. Serial server information table.

Model	Port 1 LED	Port 2 LED	Port 3 LED	Port 4 LED	Ready LED
1-Port	OFF	N/A	N/A	N/A	ON
2-Port	OFF	ON	N/A	N/A	OFF
4-Port	OFF	ON	OFF	OFF	OFF

- d. Release the Reset button. The Ready LED will flash twice per second for 5 seconds. This indicates that the serial server is re-booting in Console Mode.
- e. When the Hardened Serial Server has successfully restarted in Console Mode, the Ready LED will be off and the Port 1 LED will be on.
- f. Open the Hardened Serial Server Software and select "Serial Port" as the method to connect to the device.
- g. After logging in, click "Network."
- h. De-select "I want DHCP to setup the Network."
- i. Re-configure the serial server's network settings to an address within the range of your PC's network setting.

For example, if your PC is configured to the following settings:

IP Address = 192.168.0.1

Network Mask = 255.255.255.0

Default Gateway = 192.168.0.100

Configure the Hardened Serial Server to:

IP Address = 192.168.0.50

Network Mask = 255.255.255.0

Default Gateway = 192.168.0.100

- Save the settings and remove power from the serial server.
- Apply power to the Hardened Serial Server.
- Open the Hardened Serial Server Software and select "Network" as the method to connect to the Hardened Serial Server.

Link Status of the currently selected Hardened Serial Server is shown on the Login page of Hardened Serial Server Software. Link status indicates the type of Ethernet connection between the computer and Hardened Serial Server. It will either display 10BASE-T or 100BASE-TX in full duplex or half duplex. Link status is dependent on the LAN, switches, and hubs used in the LAN topology.

The **MAC Address** is a hardware level address of the Hardened Serial Server that cannot be changed. It is assigned in the factory. Every Ethernet device manufactured has its own unique MAC address. The MAC address of each serial server is printed on the device's label. The MAC address of the currently selected serial server is also displayed on the Login page of Serial Server Software.

Chapter 8: Listing/Descriptions of Hardened Serial Server Settings

The **model** number of the currently selected Hardened Serial Server is displayed on the Login page of Serial Server Software.

Network Protocols available for use on Hardened Serial Servers (LES421A, LES422A, and LES424A) include TCP, UDP, VCOM, and Paired Mode.

Network Watchdog controls the duration of network inactivity when a network connection is determined idle and causes the connection to be forced closed. The range is 1 through 65535 milliseconds.

Paired Mode enables two Hardened Serial Servers to operate across the network like a “wire replacement” between two serial devices. (Paired Mode is also called serial tunneling.) Serial devices connected to Hardened Serial Servers on each end of the link can communicate as if they were connected by a serial cable.

- For Paired Mode to work, one Hardened Serial Server must be configured as a TCP server and the other as a TCP client.
- The Hardened Serial Server configured as the TCP client initiates connections. You must set up the IP address and port number of the server that you want the client (Hardened Serial Server) to communicate with. You also select whether you want the Hardened Serial Server to connect at power up or only when it receives data from the device connected to its serial port.
- The Hardened Serial Server configured as a TCP server waits for connections to be initiated by another network device. You must set up the TCP port number on which it will listen for connections and set the maximum (one, up to two, or up to four) number of simultaneous connections it will accept. You can filter the connections it will accept based on specific IP addresses or ranges of IP addresses that you specify.

Password. When you first receive the LES421A, LES422A, or LES424A Hardened Serial Server from the factory, the password is blank so that you can initially access the Hardened Serial Server without entering a value into this field. To ensure security, you should create and save a password the first time you configure the serial server. After a password has been set up it must be entered each time you login to Hardened Serial Server Software. The password is used to access the configuration pages from the Hardened Serial Server Software Login page and can be changed from the General page.

Serial Interface Modes. Four serial interface modes of operation are:

- **RS-232**—Point-to-point serial communications connection used by PC COM ports and many other systems. Capable of baud rates up to 115.2 kbaud over short distances (about 50 feet). Typically uses DB9 connectors, but a 5-screw terminal block can also be used on LES421A serial servers.
- **RS-422**—Point-to-point communications using a transmit pair and a receive pair. RS-422 can operate at higher speeds and longer distances than RS-232. Typically uses two shielded twisted pairs and screw terminals but DB9 connectors are used on LES421A, LES422A, and LES424A serial servers.
- **RS-485 2-wire**—Similar speed and distance specifications as RS-422, but allows multidrop connections. Typically uses one shielded twisted pair and screw terminals but DB9 connectors are used on LES421A, LES422A, and LES424A serial servers.
- **RS-485 4-wire**—Similar speed and distance specifications as RS-422 but allows full-duplex connections. Typically uses two shielded twisted pairs and screw terminals but DB9 connectors are used on LES421A, LES422A, and LES424A serial servers.

Select the appropriate serial interface mode for the type of connection between the Hardened Serial Server’s serial port and the device connected to it.

NOTE: Refer to Appendix B for connector and pinout details.

Hardened Serial Server Name is a unique name assigned to the serial server. It must be a valid hostname as defined by RFC-952 and RFC-1123. The rules are:

- It must consist only of the characters “A” to “Z,” “a” to “z,” “0” to “9,” or “-”
- It can start or end with a letter or a number, but it must not start or end with a “-”
- It must not consist of all numeric values.

The **Server Serial Port Number** of the currently selected port is shown in this field. For more information, refer to the TCP/UDP Ports table in Section 1.4, which shows the ports used for several modes of operation.

Serial Watchdog controls the duration of serial inactivity when the serial port is determined idle and causes all connections for that serial port to be forced closed. The range is 1 through 65535 milliseconds.

The **Subnet Mask** specifies the network mask the Hardened Serial Server uses when on a subnetted network.

- For a Class A network (IP addresses 0.0.0.0 through 127.255.255.255), the default subnet mask is 255.0.0.0.
- For a Class B network (IP addresses 128.0.0.0 through 191.255.255.255), the default subnet mask is 255.255.0.0.
- For a Class C network (IP addresses 192.0.0.0 through 233.255.255.255), the default subnet mask is 255.255.255.0.
- For a Class D network (IP addresses 224.0.0.0 through 239.255.255.255) and Class E Networks (IP addresses 240.0.0.0 through 255.255.255.255), the subnet mask is ignored.
- LES421A, LES422A, and LES424A servers come from the factory with a default subnet mask value of: 255.255.255.0.

Transmission Control Protocol (TCP) provides reliable connection-oriented network communication with error checking. In TCP mode the Hardened Serial Server can be configured as a client or a server.

TCP client. When the Hardened Serial Server is configured as a TCP client, it initiates connections with a server on the network. You must set up the IP address and port number of the server that you want the client (serial server) to communicate with. You also select whether the Hardened Serial Server is to connect at power up or only when it receives data from the device connected to its serial port.

TCP server. When the Hardened Serial Server is configured as a TCP server it waits for connections to be initiated by another network device. You must set up the TCP port number that it will listen to for connections and set the maximum (one, up to two, or up to four) number of simultaneous connections it will accept. You can filter the connections it will accept based on specific IP addresses or ranges of IP addresses that you specify.

User Datagram Protocol (UDP) enables applications using UDP socket programs to communicate with the serial ports on the serial server. UDP protocol provides connectionless communications, which allows data to be broadcast to and received from multiple nodes on a network. (Because it is a connectionless protocol, UDP does not guarantee the delivery of a datagram and the datagram is only sent once.)

- In UDP mode, if you want to control what network node receives data, you must specify the IP address and UDP port the data will be sent to. You can choose to send to:
 - Nobody
 - All nodes at a specific UDP port number. (This is called broadcast.)
 - Specific IP addresses and UDP port numbers. (This is called unicast.)
 - A range of IP addresses and UDP port numbers. (This is called unicast range.)
- You can also configure the Hardened Serial Server to receive from nodes on the network using the same list of configuration options.

In VCOM (Virtual COM Port) mode the Hardened Serial Server communicates over the network with a PC, acting as a remote COM port for the computer.

Both the Hardened Serial Server and the computer must be configured for VCOM operation. Virtual COM ports can be set up on the PC using the Serial Server Software.

Appendix A: Default Server Settings

Appendix A. Default Server Settings

Table A-1. Default server settings.

Setting	Default Value
Server Name	LES421A, LES422A, or LES424A
Serial Number	Printed on side of unit.
Password	Password field is blank from factory.
DHCP	Enable
IP Address	BASED ON DHCP SERVER If a DHCP assignment is not available, the device will default to 169.254.102.39
Net Mask	255.255.255.0
Gateway	169.254.102.100
MAC Address	Fixed—see bottom label
Firmware Version	X.X.X (Current Version)
Hardware Version	X.X (Current Version)
Port	1, 2, 3, 4
Serial port mode	RS-232
Baud Rate	9600
Data bits	8
Parity	None
Stop bits	1
Flow Control	None
Protocol	TCP
Serial timeout	0 seconds
TCP alive timeout	0 minutes
Connection Mode	Server
Delimiter HEX 1	00
Delimiter HEX 2	00
Remove delimiters	Disable
Force transmit	0 ms
Inter-character timer	0 ms
Character count	0
Max connection	1

Appendix B. Connector Pinouts

B.1 DB9 M Connector




Figure B-1. DB9 M connector.

Table B-1. DB9 M connector pinout.

DB9 M Pin	RS-232	Direction (RS-232)	RS-422/485 4-Wire	RS-485 2-Wire
1	DCD	Input	RDA (-)	—
2	RD	Input	RDB (+)	—
3	TD	Output	TDB (+)	Data B (+)
4	DTR	Output	TDA (-)	Data A (-)
5	GND	—	GND	GND
6	DSR	Input	—	—
7	RTS	Output	—	—
8	CTS	Input	—	—
9	—	—	—	—

B.2 Terminal Block




Figure B-2. Terminal block connector.

Table B-2. Terminal block connector pinout.

Terminal	RS-232	Direction (RS-232)	RS-422	RS-485
A	RTS	Output	TDA (-)	Data A (-)
B	TD	Output	TDB (+)	Data B (+)
C	CTS	Input	RDA (-)	—
D	RD	Input	RDB (+)	—
E	GND	—	GND	GND

Appendix B: Connector Pinouts

NOTES:

1. In the RS-422 mode, TX lines are outputs and RX lines are inputs. Connect the Hardened Serial Server TXB(+) line to the RXB(+) line of the serial device, and the Hardened Serial Server TXA(-) to the RXA(-) of the serial device.
2. Ground is signal ground and provides a common mode reference for the RS-422 Receiver and Transmitters.

B.3 Standard Ethernet Cable RJ-45 Pinout




Figure B-3. RJ-45 Ethernet cable pinout.

Table B-3. RJ-45 cable pinout.

RJ-45 Pin	Signal	Wire Color	RJ-45 Pin
1	TX+	White-Green	1
2	TX-	Green	2
3	RX+	White-Orange	3
4	Not used	Blue	4
5	Not used	White-Blue	5
6	RX-	Orange	6
7	Not used	White-Brown	7
8	Not used	Brown	8

Black Box Tech Support: FREE! Live. 24/7.

Tech support the
way it should be.



Great tech support is just 30 seconds away at 724-746-5500 or blackbox.com.



About Black Box

Black Box provides an extensive range of networking and infrastructure products. You'll find everything from cabinets and racks and power and surge protection products to media converters and Ethernet switches all supported by free, live 24/7 Tech support available in 30 seconds or less.

© Copyright 2013. Black Box Corporation. All rights reserved. Black Box® and the Double Diamond logo are registered trademarks of BB Technologies, Inc. Any third-party trademarks appearing in this manual are acknowledged to be the property of their respective owners.

LES421A user manual, version 2

724-746-5500 | blackbox.com