

SAMSUNG Galaxy Fit

Quick Start Guide

Printed in Korea
GH68-50086M



Device layout




Charge the battery

Before using Galaxy Fit for the first time, charge the battery.



Download and connect

Wearable app

Connect your Galaxy Fit using the Galaxy Wearable app 

Once connected, use the app to view connection status, battery percentage, manage notifications, and customize various settings.

The Galaxy Wearable app requires Android 5.0 (API 21) or higher, with at least 1.5GB RAM.



Explore

The Watch screen is the starting point for viewing notifications and widgets. Press the Power key or swipe left or right, to view notifications and widgets.

Notification



Widget



Samsung Electronics America, Inc.

85 Challenger Road
Ridgefield Park, New Jersey 07660
Phone: 1-800-SAMSUNG (726-7864)
Internet: www.samsung.com

©2019 Samsung Electronics America, Inc.

Samsung, Samsung Galaxy, Samsung Health, and Galaxy Fit are all trademarks of Samsung Electronics Co., Ltd.







Other marks are the property of their respective owners.

Screen images are simulated. Appearance of device may vary.

Quick panel


Swipe down from the top edge of any screen to view current status and configure settings.



-  Adjust screen brightness
-  Turn off vibration, incoming calls, and alerts in Do Not Disturb mode
-  Activate water lock mode
-  Find your misplaced connected device
-  Turn vibration on or off.
-  Silence notifications while you sleep in Goodnight mode

Calls

You can only make and answer calls using your connected smartphone.

Swipe up  to reject calls and send to voicemail.

Missed call

If you miss a call, a notification displays on the screen.

Swipe right to view the notification.




Messages

View and send messages


- 1 Swipe right on the Watch screen to open the notification panel and view a new message.
- 2 Swipe up or down on the screen and select a quick reply message.

Delete messages

Swipe right on the Watch screen to open the notification panel > swipe up and then tap 



Learn more

To view the user manual, launch the Galaxy Wearable app on your smartphone and tap  > User manual or visit samsung.com/support.

