

Preface

About this Manual

- The contents of this manual and the bundled Basic Reference are subject to change without notice.
- Note that the example screens and product illustrations shown in this User's Guide may differ somewhat from the screens and configuration of the actual camera.

Copyright

This manual contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

© Copyright 2015

Declaration of Conformity

This device complies with Part 15 of the FCC rules. Operation is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

CE Mark Warning

This is a Class B product, in a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

FCC: SAR standard Value: 1.6 W/Kg, Maximal Measure: 0.27 W/Kg

CE: SAR standard Value: 2.0 W/Kg, Maximal Measure: 0.077 W/Kg

Trademark Recognition

Windows XP/Vista/Win7/Win 8 are registered trademarks of Microsoft Corporation in the United States and/or other countries. Windows is an abbreviated term referring to the Microsoft Windows Operation System. All other companies or product names are trademarks or registered trademarks of their respective companies.

Federal Communication Commission Interference Statement APPLIES TO USA AND CANADA ONLY

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference,

and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.*
- Increase the separation between the equipment and receiver.*
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.*
- Consult the dealer or an experienced radio/TV technician for help.*

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device is intended only for OEM integrators under the following conditions:

- 1) The antenna must be installed such that 20 cm is maintained between the antenna and users, and*
- 2) The transmitter module may not be co-located with any other transmitter or antenna.*

As long as 2 conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed.

IMPORTANT NOTE: *In the event that these conditions can not be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.*

End Product Labelling

This transmitter module is authorized only for use in a device where the antenna may be installed such that 20 cm may be maintained between the antenna and users. The final end product must be labelled in a visible area with the following: "Contains FCC ID: 2AAD3AA0D0". The grantee's FCC ID can be used only when all FCC compliance requirements are met.

Manual Information To the End User

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module.

The end user manual shall include all required regulatory information/warning as shown in this manual.

Industry Canada statement

This device complies with RSS-210 of the Industry Canada Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Ce dispositif est conforme à la norme CNR-210 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

This device is intended only for OEM integrators under the following conditions: (For module device use)

- 1) *The antenna must be installed such that 20 cm is maintained between the antenna and users, and*
- 2) *The transmitter module may not be co-located with any other transmitter or antenna.*

As long as 2 conditions above are met, further transmitter tests will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements when this module is installed.

Cet appareil est conçu uniquement pour les intégrateurs OEM dans les conditions suivantes: (Pour utilisation de dispositif module)

- 1) L'antenne doit être installée de telle sorte qu'une distance de 20 cm est respectée entre l'antenne et les utilisateurs, et*
- 2) Le module émetteur peut ne pas être coimplanté avec un autre émetteur ou antenne.*

Tant que les 2 conditions ci-dessus sont remplies, des essais supplémentaires sur l'émetteur ne seront pas nécessaires. Toutefois, l'intégrateur OEM est toujours responsable des essais sur son produit final pour toutes exigences de conformité supplémentaires requis pour ce module installé.

IMPORTANT NOTE: *In the event that these conditions cannot be met (for example certain laptop configurations or co-location with another transmitter), then the Canada authorization is no longer considered valid and the IC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate Canada authorization.*

NOTE IMPORTANTE : *Dans le cas où ces conditions ne peuvent être satisfaites (par exemple pour certaines configurations d'ordinateur portable ou de certaines co-localisation avec un autre émetteur), l'autorisation du Canada n'est plus considéré comme valide et l'ID IC ne peut pas être utilisé sur le produit final. Dans ces circonstances, l'intégrateur OEM sera chargé de réévaluer le produit final (y compris l'émetteur) et l'obtention d'une autorisation distincte au Canada.*

End Product Labelling

This transmitter module is authorized only for use in device where the antenna may be installed such that 20 cm may be maintained between the antenna and users. The final end product must be labelled in a visible area with the following: "Contains IC: 10290A-AA0D0".

Plaque signalétique du produit final

Ce module émetteur est autorisé uniquement pour une utilisation dans un dispositif où l'antenne peut être installée de telle sorte qu'une distance de 20cm peut être maintenue entre l'antenne et les utilisateurs. Le produit final doit être étiqueté dans un endroit visible avec l'inscription suivante: "Contient des IC: 10290A-AA0D0".

Manual Information To the End User

The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module.

The end user manual shall include all required regulatory information/warning as shown in this manual.

Manuel d'information à l'utilisateur final

L'intégrateur OEM doit être conscient de ne pas fournir des informations à l'utilisateur final quant à la façon d'installer ou de supprimer ce module RF dans le manuel de l'utilisateur du produit final qui intègre ce module.

Le manuel de l'utilisateur final doit inclure toutes les informations réglementaires requises et avertissements comme indiqué dans ce manuel.

Safety and Handling Precautions

Camera Information

- Do not take apart or attempt to service the camera yourself.
- Do not expose the camera to moisture, or extreme temperatures.
- Allow the camera to warm up when moving from cold to warm temperatures.
- Do not touch and put pressure on the camera lens.
- Do not expose the lens to direct sunlight for extended periods.
- Do not use abrasive chemicals, cleaning solvents or strong detergents to clean the product. Wipe the product with a slightly damp soft cloth.
- Do not use the flash or LED Light near a person's eyes to prevent possible eye injury.
- To prevent you from falling over or resulting in traffic accident, please do not use the camera while you are walking, driving or riding a vehicle.
- Please handle the camera strap with care, and never place the strap around the neck of an infant or child. Wrapping the strap around a neck may cause suffocation.
- Do not subject the LCD monitor to impact.
- To prevent the risk of fire or electric shock, do not expose this appliance to rain or moisture.

Battery Information

- Turn off the camera before installing or removing the battery.
- Use only the provided batteries or type of battery and charger that came with your camera. Using other types of batteries or chargers may damage the device and invalidate the warranty.
- Inserting the battery upside down can cause damage to the product and possibly cause an explosion.

- When the camera is used for an extended period of time, it is normal for the camera body to feel warm.
- Download all pictures and remove the battery from the camera if you are going to store the camera for a long period of time.
- The type of battery and the battery power level may cause the lens to stick. Ensure you use the correct battery type and use a fully charged battery.
- Risk of explosion if battery is replaced with an incorrect battery. Dispose of used batteries according to the instructions.
- Please keep the batteries out of the reach of children to prevent them from swallowing batteries, which might cause poisoning.

USB adapter Information

- Do not expose the adapter to high temperatures or places with high levels of moisture. Otherwise, it may cause a fire or electric shock.
- Do not attempt to repair, disassemble, change or transform the adapter.
- Avoid sudden changes in temperature, which may cause condensation on the adapter's internal surfaces. Please do not use it immediately in this situation.
- Do not touch the plug with wet hands as it may cause an electric shock.
- Do not use the travel voltage converter or AC/DC power inverter. Otherwise, it may cause damage, overheating, malfunction or fire to the camera.

Using this Menu

Symbols used in this manual are explained below:

| | |
|---|---|
|  | <p>This indicates useful information when using your camera.</p> |
|  | <p>This indicates an important message that should be read before using the function.</p> |

Table of Contents

| | |
|--|----|
| Preface | 1 |
| About this Manual | 1 |
| <i>Federal Communication Commission Interference Statement</i> | 1 |
| <i>Industry Canada statement</i> | 3 |
| Safety and Handling Precautions..... | 5 |
| Using this Menu | 6 |
| Introduction | 10 |
| System Requirements | 10 |
| Main Features..... | 10 |
| Package Contents | 11 |
| Camera Views..... | 12 |
| Navigation Control | 15 |
| Getting Started..... | 17 |
| Attach the Camera Strap | 17 |
| Inserting the Battery | 17 |
| Camera Memory | 18 |
| Inserting an SD/SDHC/SDXC Memory Card..... | 19 |
| Charging the Battery by USB | 20 |
| Turning the Power On and Off..... | 20 |
| Initial Settings | 21 |
| Modes..... | 21 |
| Using the LCD monitor..... | 22 |
| LCD Monitor Layout | 22 |
| Recording Images and Videos | 27 |
| Taking Images..... | 27 |
| Setting the Zoom Control | 27 |
| Using EV Compensation | 28 |
| Using Flash..... | 29 |

| | |
|--|----|
| Using Self-timer | 30 |
| Setting the Focus Mode | 31 |
| Using the AE/AF LOCK/Delete Button | 32 |
| Recording Videos | 35 |
| Using the Record Menu | 47 |
| Using the Movie Menu | 56 |
| Playback | 58 |
| Viewing in Single Navigation | 58 |
| Viewing Thumbnails | 58 |
| Magnify | 59 |
| Playing Videos | 60 |
| Playing Voice Memo | 61 |
| Playback Menu | 62 |
| Using the Setup Menu | 73 |
| Setting Sounds | 73 |
| Setting Power Save | 74 |
| Setting Date & Time | 74 |
| Setting Display Mode | 75 |
| Setting LCD Brightness | 75 |
| Setting Format | 75 |
| Reset All | 76 |
| Wi-Fi Settings | 76 |
| Using Wi-Fi function | 77 |
| Steps of connecting your digital camera and smart device | 77 |
| Making Connections | 84 |
| Connecting the Camera to a PC | 84 |
| Connecting the Camera to a Printer | 85 |
| Setting the Print Mode Menu | 85 |
| Appendix | 87 |

| | |
|-----------------------------------|----|
| About Folder and File Names | 87 |
| Troubleshooting | 87 |

Introduction

Congratulations on the purchase of your new digital camera.

Capturing high-quality digital images is fast and easy with this state-of-the-art smart camera.

System Requirements

In order to get the most out of your camera, your computer must meet the following system requirements:

For Windows:

- Windows XP/Vista/Win7/Win8
- Processor: Intel Pentium D 3.0GHz or equivalent AMD Athlon, or faster
- Memory: 2 GB or above
- HDD space: 300MB or above
- 32bit colour display monitor
- Microsoft DirectX 9.0C
- USB port and CD-ROM drive

For Macintosh:


- Mac OS 10.3.9 ~ 10.8 <Mass storage>
- Memory: 1 GB or above
- Q. Time player ver. 6.0.3 or above
- USB port and CD-ROM drive

Main Features


- 20 mega pixels resolution
- Up to 12x optical zoom and 8x digital zoom
- 2.7 inch colour LCD monitor
- 64MB internal flash memory with optional external SD/SDHC/SDXC card
- Supports up to 4GB SD card, and up to 32GB SDHC card and 64GB SDXC card
- Easy-to-use button interface
- DCF, DPOF, PictBridge compatibility
- Slide show enables you to playback photos, videos and corrupted files
- USB port to transfer images and videos to your PC

Package Contents

Please check the contents of your camera package. It should contain:



Digital camera




Rechargeable
battery
x 1 pcs




USB cable



Wrist strap




CD-Rom



Quick Start Guide


Camera Views

Front View




- 1. Flash
- 2. Self-timer
LED/AF Assist
Lamp
- 3. Lens
- 4. Microphone

Back View



- 5. LCD monitor
- 6. LED indicator
light
- 7. Movie button
- 8. AE/AF LOCK
button/Delete
- 9. OK
button/4-way
navigation
control
- 10. Menu button
- 11. Playback button


Top View




- 12. Shutter button
- 13. Wi-Fi button
- 14. Power button
- 15. Speaker
- 16. Zoom dial

Bottom View

- 17. Battery/Memory card compartment
- 18. Tripod screw hole



Right View



- 19. Strap ring
- 20. USB


Camera Buttons

Your camera is equipped with different buttons for ease of use.

| Button | Description |
|--------------------------|--|
| Power | Press the Power button to turn the power on/off. |
| Shutter | Press to capture an image. |
| Zoom dial | In Photo mode and Recording video, spin the zoom dial left to zoom out, right to zoom in. In Playback mode, spin to zoom in to magnify image or zoom out to enter thumbnails. |
| Menu | Press to enter or exit menu/submenu. |
| AE/AF LOCK button/Delete | Press this button on your camera to lock focus and exposure, or delete an image, video or audio clip. See "Using the AE/AF LOCK/Delete Button" on page 32 to know more about AE/AF LOCK/Delete button. |
| Playback | Press to enable Playback mode or return Record mode. |
| Movie | Press to start/stop recording video. |
| Wi-Fi | Press to enter or exit Wi-Fi menu. See "Using Wi-Fi" on page 78 to know more about Wi-Fi button. |

Navigation Control

The **4-way Navigation Control** and the **OK** button allows you to access the various menus available from the On Screen Display (OSD). You can configure a wide range of settings to ensure maximum results from your images and videos. Further functions of these buttons are as follows:



| No. | Description |
|-----|-------------------|
| 1 | EV/Rotate Button |
| 2 | Macro Button |
| 3 | Self-timer Button |
| 4 | Flash Button |
| 5 | OK Button |


| Button | Description |
|-------------|---|
| OK | <ol style="list-style-type: none"> 1. Confirm a selection when using the OSD menus. 2. In Playback Movie mode, press to start video playback. |
| Flash/Right | <ol style="list-style-type: none"> 1. In Photo Mode, press to scroll through the flash mode options. (Auto Flash, Red-eye Reduction, Forced On, Slow Sync and Forced Off) 2. In Playback mode, press to view the next image or video clip. 3. In playback Movie mode, press to Forward video playback. 4. In Menu, press to enter the submenu or to navigate through the menu selections. |

| | |
|-----------------|--|
| Focus/Left | <ol style="list-style-type: none"> 1. In Photo Mode, press to scroll through Focus options. (AF, Macro, Super Macro, Infinity, MF) 2. In Playback mode, press to view the previous image or video clip. 3. In Playback movie mode, press to Rewind video playback. 4. In Menu, press to exit a submenu or to navigate through the menu selections. |
| EV/Rotate/Up | <ol style="list-style-type: none"> 1. In Photo mode press to change the EV settings. 2. Playing Video file, press to Pause/Start video playback. 3. In Playback photo mode, press to rotate the image clockwise 90 degrees by each press of the button. This feature is applicable for still images only. 4. In Menu, press to navigate through the menu and submenu selections. |
| Self-timer/Down | <ol style="list-style-type: none"> 1. In Photo Mode, press to scroll through Self-time options. (Off, 10 sec., 2 sec. and Double) 2. Playing video file, press to stop video playback. 3. In Menu, press to navigate through the menu and submenu selections. |

Getting Started

Attach the Camera Strap

Wrist strap



Inserting the Battery


Follow these instructions to insert the rechargeable battery into the battery/memory card compartment.

Please read "Battery Information" on page 5 before inserting/removing batteries.


1. Make sure the power is off before inserting the battery.




2. Unlock and open the battery/memory card compartment at the bottom of the camera.



3. Insert the battery into the compartment with the terminal facing inside the camera with correct orientation as shown.



4. Close and lock the battery/memory card compartment. In order to prevent the battery from dropping, please make sure the compartment is locked firmly.



Camera Memory

Internal memory

Your camera is equipped with 64 MB of internal memory. Users can store files up to approximately 24 MB. If there is no memory card inserted in the memory card slot, all images and videos recorded are automatically stored in the internal memory.

External storage

Your camera supports SD cards of up to 4 GB in size. It also supports SDHC cards with a maximum capacity of 32 GB and SDXC cards with a maximum capacity of 64 GB. If there is a storage card inserted in the memory slot, the camera automatically saves all images and videos onto the external storage card. The icon  indicates the camera is using the SD card.





Not all cards will be compatible with your camera. When purchasing a card, please check the card's specifications and take the camera with you.

Inserting an SD/SDHC/SDXC Memory Card

Expand your camera's storage by using SD, SDHC or SDXC memory cards.

1. Unlock and open the Battery/memory card compartment at the bottom of the camera.
2. Insert the SD/SDHC/SDXC card into the memory card slot with the metallic part facing the back side of the camera.
3. Push the SD/SDHC/SDXC card into the memory slot until it clicks into place.
4. Close and lock the Battery/memory card compartment.



To remove the SD/SDHC/SDXC card


5. Unlock and open the battery/memory card compartment.
 6. Gently push the card until it pops out.
 7. Pull out the card carefully.
- Windows 2000/XP does not support SDXC card (exFAT format). But in Windows XP (Service Pack 2 or 3), you can download exFAT patch update to support SDXC card.
 - To use the SDXC card with Mac OS, the OS version should be 10.5 or higher.
 - The memory card that is not inserted correctly may cause damage to the camera. Please be careful when inserting the memory card.
 - To prevent children from swallowing the memory card, please keep the memory card out of reach of children.



Charging the Battery by USB

You can also charge the battery by connecting the USB cable to your camera and PC.

1. Connect the camera with the USB cable as shown.
2. Connect the other end with the USB adapter and plug it into a power outlet or into the PC's USB port.
 - When the battery is charging, the LED indicator flashes.
 - When the battery is fully charged, the LED indicator goes off.
 - When the battery is unusually charged, the LED indicator flashes rapidly.
 - When the camera charges without the battery inside, the LED indicator goes off.
 - It's recommended to not operate the camera when charging. Actual charging time depends on current battery capacity and charging conditions.
 - You can also charge the battery with an Apple adapter. Its power output meets the standard 5V/500mA.
 - If the battery is removed during charging, it will only recover charging after you unplug and replug the USB.



Turning the Power On and Off

There are two ways to turn on the camera:

- The startup image displays briefly and the startup sound plays if enabled. The zoom lens extends and the camera is turned on in Record mode.
- The camera is turned on in Playback mode. The zoom lens is not extended.

To turn off the camera, press the **Power button**.

See "Modes" on page 21 to know more about Record and Playback mode.

Initial Settings

When you turn on your camera for the first time, you will be asked to do the initial settings of your camera. First is the setup of language menu. Specify in which language menus and messages are to be displayed in on the LCD monitor.

Setting the Language

1. Press ▲, ▼, ◀ or ▶ to move through the selection.
2. Select a language, and then press **OK** to apply.

Setting the Date & Time

1. Press ◀ or ▶ to move through the selection.
2. Press ▲ or ▼ keys to change the value for the date and time.
3. Press **OK** to apply.
4. If necessary, press  to cancel and return to the menu.

Now, you are ready to start taking images and videos.



Holding down ▲ or ▼ keys to change the values continuously.

Modes

Your camera has three modes:

Record Mode

This is the default mode when you turn on the camera every time. You are able to take images in this mode.

Playback mode

Press the **Playback button**  after the camera is turned on to view and edit captured images or playback videos. The recording of voice memos attached to images is available in this mode.

Movie mode


Press the **Movie button**  after the camera is turned on to start/stop recording video in this mode.

Using the LCD monitor

The LCD monitor shows all important information regarding camera settings as well as the visual image of your image or video. The display on the LCD monitor is called the On Screen Display or OSD.

LCD Monitor Layout

Photo Mode Screen Layout



| No. | Item | Description |
|-----|-----------------|--|
| 1 | Record Mode | Indicates the current mode. |
| 2 | Flash | Indicates flash settings. |
| 3 | Self-timer | Indicates self-timer settings. |
| 4 | Zoom indicator | Displays zoom. |
| 5 | Shots remaining | Indicates the remaining shots available. |
| 6 | Battery | Indicates battery level. |
| 7 | Storage media | Indicates current storage media in use. |

| | | |
|----|---------------------|--|
| 8 | Wind Cut | Reduces wind noise during movie recording. |
| 9 | Movie size | Indicates movie size. |
| 10 | Date stamp | Indicates date stamp is enabled. |
| 11 | Shake warning | Indicates the light is not enough and the camera is shaking, which may cause the captured image to blur. If the shake warning appears, you can still capture images. However, enable Stabilizer, flashlight or use of a tripod is recommended to stabilize the camera. |
| 12 | Stabilizer | Indicates stabilizer function is enabled. |
| 13 | Histogram | Graphic display of Brightness. |
| 14 | ISO | Displays ISO settings. |
| 15 | Shutter speed | Displays shutter speed settings. |
| 16 | Aperture value | Displays aperture settings. |
| 17 | Focus area | Indicates focus area. |
| 18 | AE/AF Lock | Indicates AE/AF Lock is enabled. |
| 19 | EV Compensation | Displays exposure compensation settings. |
| 20 | Focus mode | Indicates focus is enabled. |
| 21 | White balance | Displays white balance settings. |
| 22 | Face tracking | Indicates face tracking is enabled. |
| 23 | Tracking AF | Indicates tracking AF is enabled. |
| 24 | Metering | Displays metering settings. |
| 25 | Quality | Displays quality settings. |
| 26 | Photo size | Displays photo size settings. |
| 27 | AF lamp | Indicates AF lamp is enabled. |
| 28 | Exposure bracketing | Displays Exposure bracketing settings. |
| 29 | Stylish | Indicates Stylish function is enabled. |

Movie Mode Screen Layout




Recording Layout

| No. | Item | Description |
|-----|------------------|---|
| 1 | PIV available | Indicates that you can capture a screenshot without stopping movie recording. |
| 2 | Recording status | Indicates recording status. |
| 3 | Recorded time | Displays recorded time. |
| 4 | AE/AF lock | Indicates AE/AF Lock is enabled. |
| 5 | Key indicator | Displays the commands on 4-way Navigation Control button. |

Playback Mode Screen Layout


The Playback mode display varies depending on the type of image being viewed.

Playback mode display of still images:



| No. | Item | Description |
|-----|-----------------------|---|
| 1 | Playback mode | Indicates playback mode. |
| 2 | Protect | Indicates file is protected. |
| 3 | Voice memo | Indicates voice memo is attached. |
| 4 | Button intro | Indicates the button to press on the camera to play a video file. |
| 5 | File no./Total no. | Indicates the file number over the total number of files in the storage card. |
| 6 | Battery | Indicates battery level. |
| 7 | Storage media | Indicates used storage memory. |
| 8 | Recording information | Displays recording information of the file. |
| 9 | DPOF | Indicates the file is marked for printing. |
| 10 | Image Size | Displays the image size settings. |

Playback mode of videos:



| No. | Item | Description |
|-----|-----------------------|---|
| 1 | Playback mode | Indicates playback mode. |
| 2 | Protect | Indicates file is protected. |
| 3 | Video clip | Indicates the file is a video. |
| 4 | Button indicator | Displays the button info of Playback mode. |
| 5 | File no./Total no. | Indicates the file number over the total number of files in the storage card. |
| 6 | Battery | Indicates battery level. |
| 7 | Storage media | Indicates used storage memory. |
| 8 | Recording date & time | Displays the date and time of the video clip. |
| 9 | Video size | Indicates the size of the video clip. |
| 10 | Button intro | Indicates the button to press on the camera to adjust the volume. |
| 11 | Video length | Display the total length of the video clip. |
| 12 | Played time | Indicates the played time of the video. |
| 13 | Playing status | Displays playing status. |
| 14 | Button intro | Indicates the button to press on the camera to play a video file. |


Recording Images and Videos

Taking Images

Now that you are familiar with your camera, you are ready to take your images. Taking images with your camera is very simple.

1. Turn on the camera by pressing the **Power button**.
2. Frame the shot using the focus bracket on the LCD monitor. See illustration on the right.
3. Pressing the **Shutter button** down halfway automatically focuses and adjusts the exposure, and pressing the **Shutter button** down fully captures the images.


When the shake warning icon  appears, hold the camera steadily, with your arms at your side or use a tripod to stabilize the camera to prevent blurred images.




Setting the Zoom Control

Using a combination of 12 times optical zoom and 8 times digital zoom permits zoom photography up to 96 times magnification. While the digital zoom can be a useful feature, the more an image is enlarged (zoomed), the more pixelated (grainier) the image will appear. Please refer to "Setting the Digital Zoom" on page 53 on how to setup digital zoom.

To adjust the optical zoom:

1. Spin the **Zoom dial** to zoom in or zoom out of an image.
2. The zoom indicator appears on the LCD monitor. **W**  **T Zoom dial**


1. Spin the dial clockwise (right) to zoom in.  **T**
2. Spin the dial counterclockwise (left) to zoom out. **W** 



To adjust the digital zoom:

1. Activate digital zoom. See "Setting the Digital Zoom" on page 53.
2. Spin the **Zoom dial** clockwise/counterclockwise to set digital zooms in/out to the maximum until it stops.
3. Release the **Zoom dial**.

12x optical zoom **8x digital zoom**



Using EV Compensation

Images can be captured with the overall scene intentionally made brighter or darker. These settings are used when a suitable brightness (exposure) cannot otherwise be obtained in circumstances where the difference in brightness between the subject and the background (the contrast) is large, or when the subject that you wish to capture is very small within the scene. Available for still images only.

- Press the **EV/Up** button on your camera to **EV/Up button** launch the EV Compensation function.
- To adjust EV settings, press the ▲ or ▼ keys to increase/decrease the value. As you adjust the settings, the LCD monitor synchronously displays the image applying the EV settings. Press the **OK** button to save and apply changes.
- The EV setting is only available when shooting still images.



Using Flash

When taking pictures in difficult lighting conditions, use the **Flash/Right** button to get correct exposure. This function cannot be activated when recording videos or continuous shooting.

To activate Flash:

- Press the **Flash/Right** button on your camera to launch the Flash function.
- To select flash options, press the ◀ or ▶ button keys. Press the **OK** button to save and apply changes.



Your camera is equipped with five flash modes:

⚡A Auto Flash. The flash fires automatically whenever extra lighting is needed.

⚡👁 Red-eye reduction. The flash fires twice to reduce the red-eye effect.

⚡ Forced on. The flash fires whenever you press the Shutter button regardless of lighting conditions.

⚡SL Slow sync. The flash fires with a slow shutter speed.

⚡/ Forced off. The flash is turned off.



- Flash function is only available when shooting still images, but not available when Continuous shooting mode and D-Lighting are turned on.
- Do not charge the flash while spinning the Zoom dial. Charge the flash after releasing the zoom dial if necessary.

Using Self-timer

The Self-timer allows you to take images after a pre-defined delay while burst lets you take consecutive shots. This function is only available when recording still images. The Self-timer setting is automatically set to off when you turn off the camera.

To activate Self-timer:

- Press the **Self-timer/Down** button on your camera to launch the Self-timer function.
- To select Self-timer options, press the ▲ or ▼ keys. Press the **OK** button to save and apply changes.



Self-timer/Down button

Your camera is equipped with 4 Self-timer modes:

-  **Off.** Captures an image without time delay.
-  **10 Sec.** Sets a 10-second delay to capture image after pressing the Shutter button.
-  **2 Sec.** Sets a 2-second delay to capture image after pressing the Shutter button.
-  **Double.** Performs delay and captures twice:
 - Performs a 10-second delay, then captures the image.
 - Performs another 2-second delay then captures the image again.



Setting the Focus Mode

This function allows users to define the type of focus when recording a still image.

To set the Focus mode

- Press the **Focus/Left** button on your camera to launch the Focus function.
- To select focus options, press the ◀ or ▶ keys. Press the **OK** button to save and apply changes.

**Focus/Left
button**



Your camera supports the 4 focus modes:

AF Auto Focus. With auto focus, the camera will focus on the subject automatically.



Macro/Super

Macro. This mode is designed for close-up photography. When Super Macro is set, the focus cannot be adjusted until Super Macro is cancelled.



Infinity. When Infinity is set, the camera focuses on distant objects.

MF Manual Focus. With manual focus, you can adjust the focus distance from 5cm to infinity by pressing the Up/Down button. Press OK button to lock the focus and exit the adjusting screen.



Using the AE/AF LOCK/Delete Button



Use the **AE/AF LOCK/Delete** button on your camera to lock focus and exposure, or delete an image/video clip.

AE/AF LOCK function

1. To lock AE/AF, press the AE/AF LOCK button during movie recording or half press the shutter button then press the AE/AF LOCK button in Photo mode. The AE/AF will remain locked even if you release the shutter button.
2. To unlock AE/AF by any one of the following ways:
 - Press the AE/AF LOCK button
 - Rotate the zoom control
 - Press the MENU/Playback/Movie/Power button to launch

another function **Delete function**

The Delete function allows you to remove unwanted files from the internal memory or from the memory card. Protected files cannot be erased; to delete, unprotect the file first. See "Protect" on page 63.

To delete an image/video clip:

1. Press the **Playback button**  on the camera.
2. View images/videos clips in Single navigation mode.
3. Use the ◀ or ▶ keys to scroll the display.
4. When the desired image/video clip is displayed on the LCD monitor, press the **Delete** button.
5. A confirmation selection appears on screen.
6. To close the Delete function and go back to the single navigation mode, press **Menu** button.

To delete a single file:

1. After a confirmation selection appears on screen. Select **Single**.
2. Press the **OK** button and select **Yes** to delete.
3. The next image is displayed on the LCD monitor. To delete another file, use the ◀ or ▶ keys to scroll through the images/videos clip. Repeat steps 1 to 2.
4. To close the Delete function and go back to the single navigation mode, press **Menu** button.



To delete attached voice memo:

1. After a confirmation selection appears on screen. Select **Single**.
2. A delete voice memo option will be added to the selection.
3. Select and press **OK** to delete voice memo




only and back to single navigation.


4. Or select **Yes** to delete both image and its voice memo.

To delete multiple files:

1. After a confirmation selection appears on screen. Select **Multi**.
2. The images are displayed in thumbnail view on the LCD monitor.
3. Use the ◀ or ▶ keys to move through the files.




4. When the desired image/video clip is highlighted, use the ▲ or ▼ keys to mark/unmark image/video clip for deletion.
5. Repeat step 4 until all desired images which you would like to delete are marked.
6. Press the **OK** button. A confirmation selection appears.
7. Select **Yes** to confirm.
8. Press the **OK** button to delete marked files.



To delete all files:

1. After a confirmation selection appears on screen. Select **All**.
2. Select **Yes**.
3. Press the **OK** button to delete all files.



Recording Videos

You can record videos with this camera, the available recording time depends on the capacity of the memory card. Videos can be recorded until the maximum memory capacity has been reached. However the length of a single video may be limited (the limitation depends on the camera model).



1. Press the **Movie button** to start

recording. 

2. Focus your camera on the subject that you want to take.
3. Use the **Zoom dial** to zoom in and zoom out of an image.
4. To stop recording, press the **Movie button**.



- The camera will automatically stop recording when the memory capacity is full.
- It will automatically stop recording when the 29 minutes recording time is over or the file size is over 4 GB.
- When the temperature of CCD Sensor is over 63°C, the camera will display the warning message.
- When the temperature of CCD Sensor is over 65°C, the camera will shut down automatically.

PIV function

During the movie recording, press shutter button, an icon  displayed on LCD means that the current screen can be stored as a photo without stopping movie recording by fully pressing the shutter button. The PIV feature is only applicable to movie size: 720p30 and VGAp30.




- When the movie size is 720p (30fps), the captured photos are saved at 1280 x 720 resolution.
- When the movie size is VGA (30fps), the captured photos are saved at 640 x 480 resolution.

Settings of Recording Videos

See "Using the Movie Menu" on page 56 for more details. Setting the Scene Mode

By simply selecting one of the following 26 modes, you can capture the image with the most appropriate settings.

1. From the Record Menu, press to select **Scene Mode**.
2. Use the navigation controls to move through the selection.



3. Press the **OK** button to save and activate the selected scene mode.

The table below shows the available scene mode settings.

| Icon | Item | Description |
|------|-------------------|---|
| | Intelligent Scene | The camera detects the shooting conditions and automatically switches to the appropriate scene mode. See "Using Intelligent Scene" on page 38 for more details. |
| | Program | The camera automatically adjusts suitable shooting settings like shutter speed and aperture values. |
| | Portrait | The camera blurs the background to focus on the subject. |
| | Landscape | This feature is used to emphasize wide scenic views. |
| | Sunset | This feature enhances the red hue for recording sunset images. |
| | Backlight | This feature is used to capture the image of a backlight object by changing the metering. |
| | Kids | This feature is used to capture still images of moving kids. |
| | Night Scene | This feature is used to capture images with night scenery background. |
| | Fireworks | This feature slows shutter speed to capture fireworks explosions. |

| | | |
|---|--------|---|
|  | Snow | This feature is used for beach and snow scenes. |
|  | Sports | This feature captures still images in high speed motions. |

| | | |
|---|----------------|---|
|  | Party | This feature is used for wedding or indoor party settings. |
|  | Candlelight | This feature is used to capture warm candle light effects. |
|  | Night Portrait | This feature is used to capture portrait pictures with night or dark backgrounds. |
|  | Soft Skin | This feature enhances skin tone thus facial skin appears smooth. |
|  | Flowing Water | This feature enhances smooth effects like water or silk. |
|  | Food | This feature is used to capture food images. The increased saturation in this mode makes the captured image more enticing. |
|  | Love Portrait | This feature uses face tracking to auto detect faces to capture portraits images without the help of others. When over two faces are detected, AF is automatically activated. The camera starts count down and captures a picture in two seconds. |
|  | Self Portrait | This feature sets zoom to wide. When one face is detected, AF automatically activated and plays the sound (Bi) for notice. Then camera starts count down and captures a picture in two seconds. |
|  | D-Lighting | This feature applies digital processing only to the necessary portion(s) of the image and preserves details in highlights and shadows with natural contrast. |
|  | Time Lapse | Use this feature to take photos automatically at the specified intervals. See "Using Time Lapse" on page 40 for more details. |
|  | Panorama | Use this feature to create a panoramic photo by panning or tilting the camera. |

| | | |
|---|--------------|---|
| ART | Art Effect | This feature applies different art effect on the still images. |
|  | Burst | Fully press and hold the shutter button to continuously shoot until you release the shutter button or memory card is full. |
|  | Speedy Burst | Captures 30 images in a shot when the Shutter button is pressed. Auto set Photo Size to 4:3 VGA only. |
|  | GIF Capture | Use this feature to take a specific number of images in a specific shooting interval. The taken images will be combined into a GIF file and will no longer exist individually. See "Using GIF Capture" on page 46 for more details. |

Using Intelligent Scene

This feature is most useful for novice users to capture great images even without basic knowledge of photography. Simply frame the shot with the help of Intelligent Scene Mode, the camera automatically recognizes 7 kinds of scenes - Portrait, Landscape, Macro, Backlight, Backlight Portrait, Night Scene and Night Portrait - and selects the ideal settings.

Intelligent scene icon. After the camera detects the shooting conditions, this icon changes to show the detected scene mode.



The camera changed to Landscape mode automatically.


To activate Intelligent Scene

1. Select **Intelligent Scene** in **Scene Mode** menu. 
2. Focus the camera on the subject to capture.
3. The camera detects the shooting conditions and switches to an appropriate scene mode.
4. Half press the Shutter button to focus the subject. The frame turns green to indicate focus is set.
5. Press the Shutter button to take the shot.



Using Kids Mode

Tactically, kids are the most difficult to photograph. They tend to be highly animated and can be a real challenge to make them pay attention for more than just a second or two. To capture a great moment for your kids, just keep the camera in kid mode. The mode provides higher shutter speed and always focuses on moving subjects.



Using Sports Mode

When you need a series of sports motion images, such as a golf swing, or try to capture the images of a flying hummingbird/butterfly, be sure to switch the scene mode to sports mode.

Using Party Mode

Leave Party mode on! It can be difficult to get a photograph of everyone at the party. While you have the whole gang together, take a group or family portrait. Party mode features Red-eye reduction flash and face tracking. You'll miss fewer shots, and have more time to focus on enjoying the party.

Using Food Mode

Share your dining experiences online with Food mode. This mode features on macro focus and auto flash designed for close-up photography.



Macro focus and Auto Flash are enabled by using Food mode.

Using Love Portrait

Want to take a good image when there are just two of you? All you have to do is hold the camera and smile.

If two faces have been recognized, the camera performs a 2-second countdown with a beep notice then takes a shot without you having to press the **Shutter button**.

When you are taking a photograph of yourself select self portrait mode. First the camera begins face tracking. If a face had been recognized, the camera performs a 2-second countdown and then takes a photograph without you having to press the **Shutter button**.

Using Time Lapse

Use this feature to take photos automatically at the specified intervals. The photo size will be 16:9 (2M). In Time Lapse mode, press **Down** button to launch the Time Lapse menu, and then press **Up/Down** button to select the options.



Available options are 30 sec. (Default), 1 min., 5 min., 10 min., 30 min., 60 min. Press **OK** button to apply the setting and close the menu.



You can fully press the Shutter button to start and also stop recording, and fully press the Shutter button again to stop recording. The Time Lapse photos will be merged into a Time Lapse movie at 10 fps.



Photos taken from Time Lapse will be combined into a movie and will **NOT** exist as individual photos .

Using Panorama Mode

Use this feature to create a panoramic photo from multiple shots. You can combine several shots into one single image quickly and easily.



- The actual size of the image may differ from time to time.
- It is recommended to use a tripod to stabilize the camera, and then move the camera slowly during capturing.

- A time limit of 30 seconds is given to capture the photograph.
- If you select **From Top to Bottom** or **From Bottom to Top** in **360-degree** panorama, it is recommended to turn the camera over 90 degrees in order to make sure the camera is stable.
- In Panorama mode, uneven brightness may result in the photograph looking slightly different than what you expected.

To stitch the still image

1. Press ▼ key to launch the **Angle Menu**. Use the ▲ or ▼ keys to select options. Press the **OK** button to save and apply changes.




2. Press ► key to launch the **Direction Menu**. Use the ◀ or ▶ keys to select options. Press the **OK** button to save and apply changes.




3. Fully **press** the shutter button to start shooting. When shooting starts, a white-cross locates on the center and a yellow line displays horizontally (or vertically) through the screen. In addition, a shooting bar displays to present the shooting position and the white portion of the bar indicates where has been taken.



4. If **you** move camera without keeping straight, the yellow line will move with the moving scene.




5. When the white portion of the bar gets to the end the camera will finish automatically and save the panorama image.



Using Art Effect

Effect that cannot be presented on Preview.
Does not apply to movie recording and continuous shooting.



Press ▲ or ▼ keys to select between the following settings:

| Icon | Item | Description |
|------|------------------|--|
| | Stylish | This feature is used to capture images with over-saturated colours, off-kilter exposure or blurring. |
| | Soft Focus | Produces halo around the photographed object to achieve the effect of soft focus. |
| | Light Tone | Reduces contrast to create a smooth and relaxed atmosphere. |
| | Vivid | The camera captures the image with more contrast and saturation emphasizing on the bold colours. |
| | Miniature Effect | Blurs parts of the photo to make the scene look like a miniature scale model. It is recommended to capture from a high angle to simulate the miniature effect. |

| | | |
|---|------------------------|--|
|  | Fisheye Lens | This feature captures images with fisheye lens effects. |
|  | Astral | Image is applied with starburst. |
|  | Poster | This feature captures images with old poster or illustration effects. |
|  | Impressive Art | This feature captures images with dramatic contrast. |
|  | B&W | Images are captured in black and white. |
|  | Sepia | Images are captured in sepia tones. |
|  | Colour Accent (Red) | Retains red tone while the rest of the scene becomes black and white. |
|  | Colour Accent (Orange) | Retains orange tone while the rest of the scene becomes black and white. |
|  | Colour Accent (Yellow) | Retains yellow tone while the rest of the scene becomes black and white. |
|  | Colour Accent (Green) | Retains green tone while the rest of the scene becomes black and white. |
|  | Colour Accent (Blue) | Retains blue tone while the rest of the scene becomes black and white. |
|  | Colour Accent (Purple) | Retains purple tone while the rest of the scene becomes black and white. |

Using Burst/Speedy Burst

Burst and Speedy Burst allow you to easily capture fast-moving targets, for example children playing, running dogs or exciting sport events.



| Icon | Item | Description |
|---|--------------|--|
|  | Burst | Fully press and hold the shutter button for a continuous shooting. It will only stop when you release the shutter button or memory card is full. |
|  | Speedy Burst | Captures 30 images in a shot when the Shutter button is pressed. Auto set Photo Size to 4:3 VGA only. |

- If the remaining shots are less than 30 images, **Speedy Burst** will be disabled.
- When **Speedy Burst** is enabled, the Photo Size will be fixed at VGA, the Flash will be fixed at Forced Off, and the ISO will be fixed at Auto.



Using GIF Capture

Use this feature to take a specific number of images in a specific shooting interval. The images will be combined into a GIF file and will no longer exist individually.

Press **OK button** in Preview to launch the GIF Setting. Use **Up/Down button** to adjust the shooting interval. Available options are 1 sec, 2 sec and 3 sec.

Use **Left/Right button** to adjust the number of shots. Available options are 5 pic and 10 pic.

A Pie Chart showing progress will be displayed on lower right of screen during GIF Capture. If all shots have been taken, these JPGs will be combined into a GIF and will be played in loop immediately, then a confirm box shows up. Select **Save** to save the file or select **Cancel** to erase the generated GIF.



Pie Progress



The taken images will be combined into a GIF file and will no longer exist individually.

Using the Record Menu

If you are in Photo Mode, you can access the Record menu simply by pressing the **MENU button** on your camera.

When the menu is displayed, use the 4-way navigation control and the **OK** button to move through menu selections and apply your desired settings. To close the menu anytime, press the menu button again. **Record Menu**

The Record menu allows you to change modes, and setup other capture settings.

To go to Record Menu:

Turn on the camera by pressing **Power button**.

Press  to launch the Record Menu.

Use the **▲** or **▼** keys to move through the menu

To select an item, press **▶** or **OK** button.

Change the submenu settings using the 4-way navigation control.

Press the **OK** button to save and apply settings.



Photo Size

The Photo Size function is used to set the resolution before you capture the image. Changing the Photo Size affects the number of images that can be stored in your memory card. The higher the resolution, the more memory space is required.



The table below shows the Photo Size values for still images.

| Icon | Printing Size | |
|---|---------------|------------|
| | Pixel Size | Suggestion |
|  | 5152 x 3864 | A2 Size |
|  | 3264 x 2448 | A3 Size |
|  | 2592 x 1944 | A4 Size |
|  | 2048 x 1536 | 4" x 6" |
|  | 640 x 480 | E-mail |

| Icon | Printing Size | |
|---|---------------|----------------------|
| | Pixel Size | Suggestion |
|  | 5152 x 3435 | Standard print paper |
|  | 5152 x 2898 | HDTV |
|  | 1920 x 1080 | HDTV |
|  | 2992 x 2992 | Square Composition |

Quality

The Quality sets the quality (compression) at which the image is captured. The quality determines the amount of compression is applied to your images. Fine quality will give you the best images with sharper details and less compression. However, the higher the quality, the more memory space is required in your memory card.



| Icon | Item | Description |
|---|-----------|-----------------------|
|  | Superfine | 5x compression rate. |
|  | Fine | 8x compression rate. |
|  | Normal | 12x compression rate. |

White Balance

This sets the white balance for a variety of lighting conditions

- As you move through the selection, you can see the preview on the LCD monitor synchronously.
- Press ► to enter **WB Shift**. This feature allows you to correct the white balance of **AWB** option.



| Icon | Item | Description |
|---|--------------------|---|
|  | Auto White Balance | The camera automatically adjusts the white balance. |
|  | Daylight | Ideally used for bright sunny conditions. |
|  | Cloudy | Ideally used for cloudy conditions. |
|  | Tungsten | Ideally used for indoor images with tungsten or halogen lighting without a flash. |
|  | Fluorescent 1 | Ideally used for indoor images with bluish fluorescent lighting conditions. |
|  | Fluorescent 2 | Ideally used for indoor images with reddish fluorescent lighting conditions. |
|  | Custom | Used when light source cannot be specified. Press ► for the camera to automatically adjust the appropriate white balance setting according to the environment. |

ISO

This sets the sensitivity for capturing images. When the sensitivity is raised (and the ISO figure is increased), photography will become possible even in dark locations, but the more pixelated (grainier) the image will appear.

- Use a higher ISO setting in dim conditions and a lower ISO setting in brighter conditions.




Maximum ISO Auto

This feature allows the camera to adjust the ISO Auto from ISO 100 to the value set in Maximum sensitivity, according to light conditions. Available options are 200, 400, 800 (Default).



Metering

This sets the metering method for calculating exposure.




| Icon | Item | Description |
|---|--------|---|
|  | Multi | The entire area of the screen is measured, and the exposure is calculated. |
|  | Centre | Averages the light metered from the entire frame, but gives greater weight to the subject matter at the centre. |
|  | Spot | A very small portion of the centre of the screen is measured, and the exposure is calculated. |

Setting the Exposure Bracketing

Use this feature to take photos with different exposure compensation. Bracketing records 3 continuous images in the following order: Standard exposure, Underexposure and Overexposure.

Available settings are: Off, ± 0.3 , ± 0.7 and ± 1.0 .



Setting the AF Area

AF stands for Automatic Focus. This feature determines the area which the camera focuses.

To set AF Area

1. From the Record menu, select **AF Area**.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the **OK** button to save and apply changes.



The table below shows the available AF area settings.

| Icon | Item | Description |
|------|---------------|---|
| | Face Tracking | This feature auto detects faces and tracks continuously. |
| | Wide | The camera automatically selects focus area within the wide frame. |
| | Centre | The focus area is fixed on the centre. |
| | Tracking AF | The camera will focus the subject as it moves and keep it continually in focus automatically. |

Setting the AF Lamp

The AF Lamp function allows you to record images even low light conditions.

If AF Lamp is set to Auto, the AF lamp located in the front of the camera, see "Front View" on page 12, emits a red light by half pressing the Shutter button allowing the camera to focus easily.

To set AF Lamp

1. From the Record menu, select **AF Lamp**.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the **OK** button to save and apply changes.



Setting the AE-L/AF-L

This feature allows locking exposure or focus or both of them by pressing the AE/AF LOCK button. You can define the AE/AF LOCK button to be one of the following functions:

- AE-L: Lock/Unlock exposure.
- AF-L: Lock/Unlock focus.
- AE-L & AF-L: Lock/Unlock both exposure and focus.

Press the AE/AF LOCK button to unlock it.



To lock AE/AF, press the AE/AF LOCK button during movie recording or half press the shutter button then press the AE/AF LOCK button in Photo mode.



This function is shown only when Program mode is used.

Setting the Digital Zoom


This feature controls the digital zoom mode of your camera.

Your camera enlarges an image using the optical zoom first. When the zoom scale exceeds 12x, the camera uses digital zoom.

To set Digital Zoom

1. From the Record menu, select **Digital Zoom**.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the **OK** button to save and apply changes.

The table below shows the available Digital Zoom settings.



| Icon | Item | Description |
|------|------|---|
| | On | Enlarges all image sizes, but the image quality deteriorates. |
| | Off | Uses the optical zoom only. |



Digital Zoom is not available if Face Tracking is on.

Setting the Date Stamp


The date of recording can be printed directly on the still images. This function must be activated before the image is captured. Once date and time are stamped on an image, they can no longer be edited or deleted.

Limitations of Date Stamp functions are as follows:

- Available for still images only.
- This feature does not apply to continuous shooting mode.
- In vertical or rotated images, the date and time on your images still appear horizontally.

To set Date Stamp

1. From the Record menu, select **Date Stamp**.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the **OK** button to save and apply changes.



Setting Auto Review

The Auto Review function lets you view the captured image right after shooting it.

If Auto review is On, the camera will display the captured image for **1 second** on the LCD monitor.

To set Auto Review

1. From the Record menu, select **Auto Review**.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the **OK** button to save and apply changes.




Blink Detection

Nothing ruins a great picture more than having your subjects' eyes closed. Blink Detection provides you with extra assurance when capturing once-in-a-lifetime moments like holding a trophy with teammates after winning a basketball game.

If closed eyes are detected, a saving confirmation menu appears on the screen, allowing you to re-take the shot before your subject or subjects move on.

To activate Blink Detection

1. Enable Blink Detection from Record menu.
2. Half press the **Shutter button** to focus the subject. The frame turns green to indicate focus is set.
3. Press the **Shutter button** to capture the image and automatically save the Image.
4. If the camera detects subject blinked eye, a "**Save image**" or "**Cancel**" option appears on the screen.
5. Select **Save image** to save or **Cancel** to disregard




Blink Detection appears in Record menu only when Face Tracking is turned on

Setting Grid Line

The Grid Line function will show a framing grid on the preview of your pictures. Available settings are: **On**, **Off**.

The configuration of Grid Line will be changed with different aspect ratio.



Setting Stabilizer

This function allows you to prevent blurred images caused by shaking.

1. Enable the Stabilizer under the Record Menu.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the OK button to save and apply changes.



Using the Movie Menu

You can access the Movie menu simply by pressing the **MENU button** on your camera.

When the menu is displayed, use the 4-way navigation control and the **OK** button to move through menu selections and apply your desired settings. To close the menu anytime, press the menu button again.

Setting Movie Mode


Use this function to adjust the resolution and quality of movie clips.



- The options FHD and HD are only available when a SDHC class 4 or class 6 card is inserted.
- Due to limits from the FAT format, VGA recording requires approximately 2 hours.

Setting Prerecord

You can catch the first three seconds of action you would have potentially missed. Once enabled the camera starts recording video automatically before you press the Movie button. As soon as the Movie button is hit, the most recent three seconds of video are added to the beginning of the clip.



The icon is shown in red while the Prerecord button is on.



Prerecord will be cancelled in the following situation:

- After recording starts.
- Switch to Playback mode.
- Launch the Menu.
- Enter USB mode.
- Power off the camera.



Prerecord function will be disabled in the following situations:

- The prerecord time is less than 2 seconds.
- There is not enough internal memory to enable this function unless an additional memory card is inserted to the camera.

Setting Wind Cut


This feature reduces wind noise during movie recording.



Continuous AF

This function allows you to record video with auto focus.

1. Enable the Continuous AF under the Movie Menu.
2. Use the ▲ or ▼ keys to go through the selection.
3. Press the OK button to save and apply changes.



Playback


You can playback still images and video clips on the LCD monitor.

Viewing in Single Navigation

The Single navigation mode displays the image one by one on the LCD monitor. To view images/video clips, follow the steps below.

1. Press the **Playback button**  on the camera.
2. The LCD monitor displays an image. To understand the icons and other information on the screen, please see "Photo Mode Screen Layout" on page 22.

Still Image



Video



3. Use the ◀ or ▶ keys to view next/previous image/video.
4. To play a video clip, press the **OK** button. See "Playing Videos" on page 60 for more details.



When playing videos under playback mode, lens will retract after 15 seconds, but the video playback will still continue.

Viewing Thumbnails

This function allows you to view 9 or 36 thumbnail images on the LCD monitor at the same time. Searching numerous images is much easier than single view navigation.

To set 9-images or 36-images mode

1. Press the Playback button  on the camera.
2. Spin the Zoom dial counterclockwise (left) once to enter 9-images mode or twice to enter 36-images mode.
3. Use the navigation controls to move through the items.
4. Press the OK button to select the image and view it normally.

Scroll bar.

If scroll bar appears, it indicates that the screen can be scrolled. 9 images (3x3) or 36 images (6x6) can be displayed at one time in Thumbnail Screen. Use the **4-way navigation control** to select the file and press the **OK button** to display the selected file in Single Navigation.



Thumbnail 3x3



Thumbnail 6x6

Thumbnail icons:

When you view the thumbnails, some images may contain icons. These icons indicate the type of file or recording.

| Icon | Type | Description |
|---|------------|--|
|  | File Error | Indicates an error file. |
|  | Video | Indicates videos with roll film pattern. |

Magnify

The zoom view function works with still images only.

- In normal view, spin the **Zoom dial** clockwise (right) repeatedly until the desired zoom view appears.
- You can zoom to view an image of up to 12X.
- Use the navigation controls to view the zoomed image.



- Press the **Menu** button from any magnify ratio to return to Single Navigation.

Playing Videos

1. Press the **Playback button**  on the camera.
2. Use the navigation controls to scroll through the saved images. A video clip has a video icon displayed on screen.
3. Press the **OK** button to play the video.
4. During playback, press and hold the   keys to fast forward or rewind the video. The camera supports forward and rewind speed of up to 4x.
5. During playback, use the **Zoom dial** to control volume. Spin clockwise (right) to increase volume/Spin counterclockwise (left) to decrease volume.
6. Press the  key to pause playback. Press the key  again to resume. When paused, the play info will remain on screen except  .
7. To forward or rewind the video frame by frame, press the key  to pause playback, then press the  or  keys.
8. Press the  key to stop the playback. The LCD monitor displays the video frame image in Single navigation mode.



- The play info, except the icon  , will be displayed when the video is paused, during REW/FF or frame by frame modes
- Volume cannot be adjusted when paused or during REW/FF modes.

Playing Voice Memo

Voice memo is separately recorded and attached to a captured image. See "Voice Memo" on page 65 on how to record voice memo.

Press the **Playback button**  on the camera.

Use the navigation controls to scroll through the saved images. An image file with voice memo has a voice memo icon located on the top centre of the LCD monitor. See picture on the right.



Press the OK button to play the voice recording.

During playback, use the **Zoom dial** to control volume. Spin clockwise (right) to increase volume/Spin counterclockwise (left) to decrease volume.

Press the key  to pause playback. Press the  key to resume. When paused, the play info will remain on screen except



To forward or rewind the video frame by frame, press the  key to pause playback, then press the  or  keys.

Press the  key to stop the playback. The LCD monitor displays the video frame image in Single navigation mode.



Volume cannot be adjusted when you pause the voice memo.

Playback Menu

The Playback menu allows you to edit images, record voice memos, and setup playback settings.

To go to Playback Menu:

1. Press the **Playback button**  on the camera.
2. Press **Menu button** to launch the Playback Menu.
3. Use the **▲** or **▼** keys to move through the menu selections.
4. To select a menu, press **▶** or the **OK** button.
5. Change the submenu settings using the 4-way navigation control.
6. Press the **OK** button to save and apply settings.



Slide Show


The slide show function enables you to playback your photos, videos and error files according to naming order.

To view Slide Show:

1. From the Playback menu, select **Slide Show**. The Slide Show menu appears.
2. Set the slide show settings.
3. Select **Start**, then press the **OK** button to start the slide show.
4. During Slide Show, press the **UP** button to pause slide show.
5. Use the **▲** or **▼** keys to move through the options. Select whether to **Continue** or **Exit** the slide show.
6. Press the **OK** button to apply selected option.

To change slide show settings:

1. From the Slide show menu, use the ▲ or ▼ keys to move through the selections.
2. Select Interval setting. Press the ◀ or ▶ keys to adjust. Choose among the available interval settings: 1 sec., 3 sec., 5 sec., and 10 sec.
3. Select Repeat setting. Press the ◀ or ▶ keys to adjust. Available settings are: Yes, No.



Protect

Set the data to read-only to prevent images from being erased by mistake.

A protected file has a lock icon  when viewed on Playback mode.

To protect files:

1. From the Playback menu, select **Protect**.
2. The Protect submenu is displayed on the LCD monitor.




Available select settings:

- **Single.** Select one file to lock/unlock.
- **Multi.** Select multiple files from the thumbnail view to lock/unlock.
- **Lock all.** Lock all files
- **Unlock all.** Unlock all files.


To protect/unprotect a single file:

1. Select **Single** in the Protect submenu, the images are displayed on the LCD monitor in single navigation mode.
2. Use ◀ or ▶ keys to scroll the display.
3. When the desired file is displayed on the LCD monitor, press the **OK** button to select **Lock/Unlock**.
4. To close the protect/unprotect function and go back to Playback menu, select **Exit**.




To protect/unprotect multiple files:

1. Select Multi in the Protect submenu, the images are displayed in thumbnail view on the LCD monitor.
2. Use the ◀ or ▶ keys to move through the files.
3. When the desired file is highlighted, use the ▲ or ▼ keys to mark/unmark the file for protection.
4. Repeat step 3 until all desired files to protect are marked.
5. Press the **OK** button to lock files and go back to Playback menu.




To protect all files:

1. Select **Lock all** in the Protect submenu. A confirmation message appears.
2. Select **Yes**.
3. Press the **OK** button to lock all files.



To unlock all files:

1. Select **Unlock all** in the Protect submenu. A confirmation message appears.
2. Select **Yes**.
3. Press the **OK** button to unlock all protected files.




Voice Memo

A maximum of 30 seconds of audio can be recorded as a memo for captured still images.

To record voice memo:

1. Press the **Playback button**  on the camera.
2. Press the ◀ or ▶ keys to scroll and select an image to attach voice memo to.
3. Press the **MENU** button to launch the Playback menu.
4. Select **Voice Memo**.
5. Select **Start**, then press the **OK** button to start recording.
6. Press the **OK** button again to stop recording.



Time left (n seconds) for recording.




When you record a voice memo for an image with an existing voice memo, the old recording file would be replaced by the new one.

Filter Effects

Filter Effects function is only applicable to aspect ratio **4:3** photos with different artistic effect. Edited images in this function are saved as new files.

To activate Filter Effects:

1. Press the Playback button  on the camera.
2. Press the ◀ or ▶ keys to scroll and select an image to edit.
3. Press the **MENU** button to launch the



Playback menu.

4. Select **Filter Effects**. The Filter Effects submenu appears.
5. Press the ▲ or ▼ keys to scroll and **OK** button to select an option.

The succeeding table shows the available settings.


| Item | Description |
|-------------------------|--|
| Soft | Image is applied with soft effect. |
| Colour Emphasis | Retains the colour tone you choose while the rest of the scene becomes black and white. |
| Vivid | Image is applied with more contrast and saturation emphasizing the bold colours. |
| Miniature Effect | Part of the image will be blurred making the scene look like a miniature scale model. It is recommended to apply it to an image that is captured from a high angle to simulate the miniature effect. |
| Astral | Image is applied with starburst. |
| Impressive Art | Image is applied with dramatic contrast. |
| Painting | Image is applied with watercolour effect. Please note that if one image is applied with Painting function already, it cannot be applied with Astral again. |
| Negative | Image appears to be the opposite of the original image. |
| B&W | Image is applied with black and white. |
| Mosaic | Image is applied with mosaic tiles. |
| Sepia | Image is applied with sepia tones. |

Trimming

The Trim function allows you to trim an image to another image size. This function is only available for still images.

To trim an image:

1. Press the Playback button  on the camera.
2. Press the ◀ or ▶ keys to scroll and select an image to trim.
3. Press the **MENU** button to launch the Playback menu.
4. Select **Trimming**. The Trim screen layout is displayed on the LCD monitor.
5. Use the **Zoom dial** to change the trimming frame as zoom in/out.



| No. | Description |
|-----|--|
| 1 | Enlarged image |
| 2 | 4-way indicator |
| 3 | Trimmed size |
| 4 | The approx. location of the trimmed area |
| 5 | Image area |



6. Use the navigation controls to move the image.
7. Press the **OK** button to apply changes. A menu selection appears.
8. Select whether to:
 - **Yes.** Save the new file as a new one.
 - **Cancel.** Cancel setting and go back to Playback Menu.
9. Press the **OK** button to save/cancel changes.
 - Trim function is not available for images with image size set to VGA.
 - All images will be trimmed in 4:3 ratio regardless of its original image ratio.





Resize

Resizes a previously saved image to create a small copy photo; only resizing to a smaller size is available.

To resize an image:

1. Press the **Playback button**  on the camera.
2. Use the ◀ or ▶ keys to scroll and select an image to resize.
3. Press the **MENU** button to launch the Playback menu.
4. Select **Resize**. The Resize submenu is displayed on the LCD monitor.
5. Select size among: 640, 320, and 160.
6. After selecting size, a menu selection appears.
7. Press the **OK** button to save/cancel changes.
8. The resized image is saved as a new photo.




- Resize function is only applicable to aspect ratio 4:3 photos.
- The original photos can be resized more than once. However, each resized photo cannot be resized again.

Startup Image

You can specify the startup image from the captured images on the camera.

1. Press the **MENU** button to launch the Playback menu.
2. Select **Startup Image**. The menu selection appears.
3. Select options:
 - **System**. Use camera default image.
 - **My Photo**. Use the ◀ or ▶ keys to scroll and select desired image.
 - **Off**. Disable the startup image.
4. Press the **OK** button to apply changes.





The startup image will still be displayed even if the selected image was deleted.

DPOF

DPOF is the abbreviation for Digital Print Order Format, which allows you to embed printing information on your memory card. You can select the images to be printed and how many prints to make with the DPOF menu in the camera or insert the memory card to the card compatible printer. When the printer starts printing, it will read the embedded information on the memory card and print the specified images.

To set DPOF:

1. Press the **Playback button**  on the camera.
2. Press **Menu button** to launch the Playback Menu. 3. Select **DPOF**. The submenu appears.



Available settings are as follows:

- **Select Images.** Mark images in the memory card.
- **Reset.** Reset all DPOF settings to initial default settings.

To set DPOF on images:

1. Select **Select Images** on the DPOF submenu.
2. Use the ◀ or ▶ keys to scroll and select images to mark for printing.
3. When the desired image is highlighted, use the ▲ or ▼ to increase/decrease number.
4. Press the **OK** button to define the DPOF settings and select **Done** to save DPOF settings.
5. To reset DPOF:
 1. Select **Reset** on the DPOF submenu.




2. The camera auto reset all DPOF settings.

Copy

Use this feature to copy images between internal memory and memory card.


To copy images between internal memory and memory card:

1. Press the **Playback button**  on the camera.
2. Press **Menu button** to launch the Playback Menu.
3. Select **Copy** and choose a method you want to copy images to. After choosing, available settings are as follows:
 - **Selected images.** Select the images that should be copied to the storage device you prefer.
 - **All images.** Copy all images to the storage device you prefer.




To copy selected images:

1. Select **Selected images** on the Copy submenu.
2. Use the ◀ or ▶ keys to scroll and select images to mark for Copying.
3. When the desired image is highlighted, use the ▲ or ▼ keys to mark/unmark the file for copying.
4. Press the **OK** button and select **Yes** to start copying.



To copy all images:

1. Select **All images** on the Copy submenu.
2. Select **Yes** to start copying.





If no memory card or a locked card is inserted, this option would be in grey.

Movie Paste

Use this feature to combine two videos with the same specification (movie size and fps) into one video. To combine two videos:

1. Press the **Playback button**  on the camera.
2. Use the ◀ or ▶ keys to scroll and select the original video.
3. Press the **MENU** button to launch the Playback menu.
4. Select **Movie Paste**. The videos with the same specification as the original video are displayed on the LCD monitor.
5. Use the ◀ or ▶ keys to scroll and the ▲ or ▼ keys to mark/unmark the second video.
6. Press the **OK** button and select **Yes** to merge it to the end of the original video and overwrite it.



The total length of the combined video cannot be over 30 minutes.

After combining videos, the second video will no longer exist with a separate file.

Face Retouch

This function is only applicable to still images that were captured with Face Tracking.

When you enter the Face Retouch menu, , if the photograph has over two faces locate the cursor on the picture, if the photograph has one face locate the cursor on the function at the right side of the menu.

Only one face can be retouched at a time. All functions will be reset to 0 when you exit from Face Retouch menu, no matter if you save the picture or cancel the setting.

Pictures that have been edited with Face Retouch will be saved as new images and can be edited with this function again.




| Item | Available Settings | Description |
|---------------------|--------------------|----------------------------------|
| Smoothing | 0-3 | The Smoothing levels are 0-3. |
| Brighten | 0-3 | The Brighten levels are 0-3. |
| Enlarge Eyes | 0-3 | The Enlarge Eyes levels are 0-3. |
| Save | N/A | Save the image. |

Using the Setup Menu

You can access the Setup menu whether you are in Record or Playback mode. The Setup menu allows to configure general camera settings.

To go to Setup Menu:

1. Press **Menu** button to launch the Record/Playback Menu.
2. Use the ◀ or ▶ keys to switch the menu tab to **Setup** menu.
3. Use the ▼ or ▲ keys to move through the menu selections.
4. To select an item, press the **OK** button or ▶ key.
5. Change the submenu settings using the 4-way navigation control.
6. Press the **OK** button to save and apply settings.



Setting Sounds

Use the Sound menu functions to control the sounds produced by the camera.

1. From the Setup menu, select **Sounds**.
2. Adjust sound settings.
3. Press the **OK** button to apply changes.




| Item | Available Settings | Description |
|--------------------|--------------------------------|---|
| Startup | Sound 1, Sound 2, Sound 3, Off | Selects the startup sound when camera is turned on. |
| Shutter | On, Off | Enables or disables shutter sound when Shutter button is pressed. Shutter sound is not available when recording videos. |
| Beep volume | 0-4 | Adjusts volume. |

Setting Power Save

The Power Save function allows you to set an idle time after which the camera automatically gets into sleep mode to save power. After a minute of being in sleep mode, the camera eventually turns off power.

This function is not available in the following instances:

- Recording a video file
- Playing a Slide Show/video file
- Using the USB connector
- AE/AF has been locked
- During Movie Paste
- During interval time on Time Lapse



Setting Date & Time

Use the Date & Time function to set the date and time of your camera. This function is useful in attaching date stamps on captured images. Your camera uses a 24-hour time format.

1. Press the navigation controls to adjust date and time value. By holding down the ▼ or ▲ keys, the numeric values changes continuously.
2. Press the **OK** button to apply changes.



Setting Language

Specify in which language menus and messages are to be displayed on the LCD monitor.

1. Use the navigation control to scroll through the list and select the desired language.
2. Press the **OK** button to confirm and apply settings.




Setting Display Mode

This function controls the icon display on the LCD monitor for both Record mode and Playback mode.

Available settings are: On, Detailed Info, Off.

If you set Display Mode to Off, the mode icon and remaining shots will display for 2 seconds in the following situations:

- Power on the camera
- Switch from Playback to Record mode
- After shooting
- Close the menu and back to preview




Setting LCD Brightness

Select a brightness level for the LCD monitor.


Available settings are:

- **Auto.** Auto detects the LCD brightness.
- **Bright.** Enhance the LCD brightness.
- **Normal.** Normal LCD brightness.



Setting Format

This utility formats current used memory (Internal memory or Memory card) and erases all stored images and data.




If a locked card has been inserted, the option would be grey.

Reset All

Use this function to reset the camera to its factory settings. However, the following settings are exceptions and are not affected by Reset.

- Date & Time
- Language
- TV Settings
- Custom White Balance data





Wi-Fi Settings

The Wi-Fi Settings contains Camera Name and Password. You can use the 4-way navigation control to move the cursor and press OK button to enter the selected letter or numbers.

The default **Camera Name** is "Wi-Fi Camera", you can change it with 1~32 alphanumeric characters (case-sensitive).

The default **Password** is "12345678", you can change it with 8~16 alphanumeric characters (case-sensitive).



To switch the keyboard:

- In Lowercase Keyboard, select  and press **OK** button to switch the keyboard to Uppercase. Likewise, select  and press **OK** button in Uppercase Keyboard to switch the keyboard to Lowercase.
- In Uppercase/Lowercase Keyboard, select  and press **OK** button to switch the pages to Numeric Keyboard.



To make sure your experience of using Wi-Fi function is good, it's recommended to change your Camera Name and Password first.

Using Wi-Fi function

With Wi-Fi function, you can immediately transfer photos and videos from this camera to other smart devices and even share them to social networking sites when it is connected. In addition, your smart device can also be used as a remote control for your camera. Photo capturing and file download can be operated directly via your smartphone or tablet (video recording can only be controlled on the camera).

You can launch the Wi-Fi menu by pressing the Wi-Fi button in Preview or Single Navigation mode.

Steps of connecting your digital camera and smart device

1. Before using Wi-Fi mode, please download and install the Wi-Fi application

"Link123"  from Google Play (Android) or Apple Store (iOS) on your smart devices.

2. Power on the camera and press Wi-Fi button, and then tap Remote Control.



| Item | Description |
|--------------------------|--|
| Remote Control | Except video recording, you can use your smart device to control the camera remotely for taking pictures or download files from your camera. See "Remote Control" on page 80 for more details. |
| Geotag Recording | Synchronize the time of smart device and camera. |
| Download GPS Data | Download GPS data from smart device to geotag photos stored in your camera. See "Geotag Recording" on page 81 for more details. |
| Send to App | Upload photos or movies from camera to a smart device. See "Send to App" on page 82 for more details. |

3.

3. Turn on Wi-Fi network. Then choose and connect to the hotspot titled with the name of camera (the default is "Wi-Fi Camera") in the list of discovered networks.
4. Please enter the default password of hotspot "12345678" for the first time.
 5. When the smart device connects to the camera's network, please run application "Link123" to remotely control the camera with the smart device (view and download the photos and videos from the camera).



App menu



The Home Screen may vary due to different mobile OS.

The Link 123 App only supports portrait orientation. The screen will not be rotated when smart device is rotated to landscape or other orientations.

This function will be available in Android 2.3 or above.

This function will be available in iOS 5 or above.

Make the Wi-Fi connection between camera and smart device

If you would like to perform "Remote Control" or "Download GPS Data" function on the smart device, please connect the camera with your smart device via Wi-Fi. First of all, set a Wi-Fi option on camera and make sure the smart device is within Wi-Fi range. Then select the Camera Name from the Network List on your smart device. You will be asked to enter the password if it is the first connection with this camera.

Remote Control

Please refer to the following steps to launch Remote Control function:

1. Select "Remote Control" from the Wi-Fi Menu of the camera.
2. The camera will enter Wi-Fi Standby.
3. Tap the Camera Name from Network List on the smart device.
4. The camera will enter Remote Control Standby.
5. Run the "Link123" application on the smart device, and then click on "Remote Shutter" or "Camera Link".
6. If you tap "Remote Shutter", camera will enter Preview mode; if you tap "Camera Link", camera will display black screen.
7. Your smart device will then enter into the "Remote Shutter" or "Camera Link".



Wi-Fi Standby



Remote Control Standby

Geotag Recording

1. Select "Remote Control" from the Wi-Fi Menu of the camera.
2. Select "Geotagging" from App menu on the smart device.
3. Turn on your GPS in the smart device.
4. Run the "Link123" application on the smart device and click on the "Geotagging" option.



Operation Guide

5. Click on the red button on the "Geotagging" interface. The camera will synchronize with the smart device, after which the smart device will start to record GPS data. The camera will return to the remote control interface. To stop recording the GPS data, press the same button again.
6. Press the Wi-Fi button to disconnect between the camera and the smart device. During this time, you can take pictures and record videos normally with the camera. The "Link123" application on the smart device will remind you of the disconnection. Click on OK to confirm, but do not stop the GPS data recording on the "Link123" application.
7. Once done taking the photo, use the "Download GPS Data" feature to import where the photo was taken from the smart device and save this information onto the photo.




Use together with the "Download GPS Data" feature to display the location information in the property of the photo.

Download GPS Data

Please refer to the following steps to launch Download GPS Data function:

1. Select "Download GPS Data" from the Wi-Fi menu of the camera.
2. Tap the Camera Name from Network List on the smart device.
3. Tap "Upload to Camera" on the smart device.
4. The camera will display download screen.
5. Uploading progress bar will be displayed on the smart device.
6. A dialog box for user to confirm whether to keep the GPS data will be displayed on the smart device.
7. Wi-Fi will be disconnected automatically when the uploading is finished. Then, the camera will return to Preview mode or Playback mode.
8. You can see where the photo was taken by viewing the property of the photo on the PC.




Since the GPS data is recorded once per minute, the data will be imported to the photo with the same recording time. Non-corresponding data will not be imported to any photo.

Send to App

Please refer to the following steps to launch Send to App function:

1. Select "Send to App" from the Wi-Fi Menu of the camera.
2. The camera will enter 4 x 3 thumbnail view.
3. Tap ▲ key to mark the desired images on the camera, and then press OK button.
4. Tap the Camera Name from Network List on the smart device.
5. The camera will enter Wi-Fi Standby.



4 x 3 thumbnail view

6. Tap Start to start receiving images on the smart device.
7. The camera will display Sending Screen to start sending images.
8. The received images will be displayed on the smart device.
9. Wi-Fi will be disconnected automatically when the sending is finished. Then, the camera will return to Preview mode or Playback mode.



iOS Notice

10. A completion notification will be displayed on the smart device.



- All the camera functions will be disabled when Wi-Fi is connected, except **Power button** and **Wi-Fi button**.
- Wi-Fi is functioned even when no memory card is inserted into the camera.
- The Wi-Fi function will be stopped automatically in the following situations:
 1. Press the Wi-Fi button again to exit Wi-Fi mode.
 2. Press the Menu button to exit Wi-Fi mode and enter Photo Preview or Single Navigation.
 3. Out of the Wi-Fi range.
 4. Connect to the PC, TV, or Printer.
 5. Insert or remove the memory card.
 6. Remaining battery power lower than 10% ($\pm 5\%$).


Making Connections

You can connect your camera to a computer or a printer.

Connecting the Camera to a PC

You can transfer images and video files to your PC.

1. Connect one end of the USB cable to an available USB port on your computer
2. Connect the other end of the USB cable to the USB terminal on the camera.
3. Turn on the camera.



4. The PC starts to detect the connection while the LCD monitor displays **Connecting...**



5. Connection established and the LCD monitor will be turned off.
6. Access the files in the camera by your PC.




- The camera's internal memory and memory card will display as removable drives in Vista/Win7/Win8 PC.
- When this camera is connected to your PC, two removable drives will display. Please click AP link (Magix) in the second drive, and then Setup window will display (an Internet connection is required). After installation, you can import / edit your photos, movies and music. Please note that AP link (Magix) is the trial version and will be used permanently after registration.

Connecting the Camera to a Printer

You can print your images directly using a **PictBridge compatible** printer.

1. Turn on your Printer. Check that the printer is turned on, there is paper in the printer, and there are no printer error messages.
2. Connect one end of the USB cable to the printer while the other end to USB terminal on the camera.
3. Enter the print mode and print the selected images.




For more details on "Setting the Print Mode Menu" go on to the following page.

Setting the Print Mode Menu

Print Mode menu appears on the screen after the connection between a printer and your camera is established.

Print Mode includes three major settings:

- **Print Select.** An image can then be selected to print.
- **Print All.** Prints all images.
- **Print DPOF.** Prints the images which are set DPOF.




To set Print Select

1. Use the ◀ or ▶ keys to scroll and select an image for printing.
2. Specify the number of copies. Use the ▼ or ▲ key to increase/decrease number.
3. Press the **OK** button to enter printer settings.


To set Print All and Print DPOF

Repeat the same steps 1 to 2, then enter printer settings.



To set Printer Settings

1. Use the ▲ or ▼ key to specify a print option.
2. Modify paper size, quality, date and info by the◀ or ▶ keys. Available setting:
 - Paper size: Default / A4 / 4"x6"
 - Quality: Default / Fine / Normal
 - Capture Date: Yes / No
 - Capture Info: Yes / No
3. Select **Print** on the screen for printing.
Or **Cancel** to go back Print Mode.



Start Printing

- LCD monitor appears "Now printing...".
- Or press Menu button to stop printing anytime.



Appendix

About Folder and File Names

Your camera automatically creates a specific directory of folder in the internal memory cards to organize captured image and video files.

File Naming

File names begin with "DSCI" followed by a 4-digit number that increases in sequence. File numbering starts from 0001 when a new folder is created.

The highest file number is 9999, if files exceed 9999, the camera will start over the file number from 0001.



Do not change the folder and file names in the memory card using your PC. It may be unable to playback the data using the camera.

Troubleshooting

| Problem | Cause and/or Action |
|---|--|
| Camera does not turn on. | The battery may be exhausted, charge or replace. |
| Camera turns off automatically. | <ul style="list-style-type: none">• Power Saving may have activated. Turn power back on.• The battery may be exhausted. Charge the battery. |
| Empty battery icon is displayed on the LCD, then the camera turns off. | Battery is exhausted, please replace or recharge. |
| LCD monitor displays "Not available for this file". | Function is only available for specific file types. File format is not supported. |
| LCD monitor displays "Memory full". | Memory card is full. Replace the memory card with a new one or delete unnecessary images. |
| LCD monitor displays "File locked". | This file is locked. Unlock the file. See "Protect" on page 63. |

| Problem | Cause and/or Action |
|---|---|
| LCD monitor displays "Card locked". | The memory card is protected. Remove the card and slide the write-protect switch to its unlock position. |
| LCD monitor displays "Card error". | Memory card format may not be supported by the camera. Please go to Setup menu to format the card. |
| LCD monitor displays "Memory card is damaged". | The card may be damaged. You can either change the card or wipe to clean the connected points. |
| LCD monitor displays "Copy error". | The memory card is protected. Remove the card and slide the write-protect switch to its unlock position. The memory card is full. Replace card or delete unnecessary files. |
| The lens got stuck. | Do not force the lens to go back. The type of the battery used may be incorrect or the battery power level is too low. Change the battery or charge the battery before using the camera. |

Specifications

| | |
|-----------------------|---|
| Sensor | 20M Pixels |
| Lens | Focal Length: 24 mm ~ 288 mm 12x optical zoom, 8x digital zoom |
| LCD monitor | 2.7" Colour LCD |
| Focusing Range | Normal: Wide: 40 cm ~ infinity Tele: 150 cm ~ infinity Macro: Wide: 5 cm ~ 100 cm Tele: 150 cm ~ 200 cm Super Macro: Wide: 3 cm |
| Aperture | Wide: F3.1; Tele: F6.3 |
| Shutter | Shutter Speed: Auto: 1 - 1/2,000 sec. Night: 1/4 - 1/2,000 sec. Fireworks: 4 sec. |
| File Format | Still Image: EXIF 2.3 compatible format (JPEG compression) AVI (Video: MJPEG , Audio: mono) Audio: WAV |

| | |
|---------------------------|---|
| Resolution (Photo) | <p>Aspect ratio 4:3</p> <p>20M (5152 x 3864), 8M (3264 x 2448), 5M (2592 x 1944), 3M (2048 x 1536), VGA (640 x 480)</p> <p>Aspect ratio 3:2</p> <p>5152 x 3435</p> <p>Aspect ratio 16:9</p> <p>14M (5152 x 2898), 2M (1920 x 1080)</p> <p>Aspect ratio 1:1</p> <p>2992 x 2992</p> |
| Resolution (Movie) | <ul style="list-style-type: none"> • 720p30 • VGAp30 |

| | |
|-------------------------|--|
| Scene Mode | Intelligent Scene, Program, Portrait, Landscape, Sunset, Backlight, Kids, Night Scene, Fireworks, Snow, Sports, Party, Candlelight, Night Portrait, Soft Skin, Flowing Water, Food, Love Portrait, Self Portrait, D-Lighting, Time Lapse, Panorama, Art Effect, Burst, Speedy Burst, GIF Capture |
| ISO Equivalent | Auto, ISO 100, ISO 200, ISO 400, ISO 800, ISO 1600, ISO 3200, ISO 6400 |
| Maximum ISO Auto | ISO 200, ISO 400, ISO 800 |
| White Balance | Auto White Balance, Daylight, Cloudy, Tungsten, Fluorescent 1, Fluorescent 2, Custom |
| Exposure Control | +2.0EV / +1.7EV / +1.3EV / +1.0EV / +0.7EV / +0.3EV / 0EV / -0.3EV / -0.7EV / -1.0EV / -1.3EV / -1.7EV / -2.0EV |
| Metering | Multi, Center, Spot |
| Self-timer | Off, 10 sec., 2 sec., Double |
| Flash | Auto Flash, Red-eye Reduction, Forced On, Slow Sync, Forced Off |

| | |
|------------------------------|---|
| Storage | Internal memory: 64MB flash memory External memory: SD (up to 4GB), SDHC card (up to 32GB guaranteed), SDXC card (up to 64GB guaranteed) |
| OSD Language | English, Français, Español, Deutsch, Italiano, Русский, Português, Português BR, Nederlands, Türkçe, Polski, Magyar, Română, Čestina, Български, Hrvatski, Slovensky, Slovenščina, Ελληνικά, Svenska, Norsk, Suomi, Danish, عربي, Indonesia, Malay, ไทย, 日本語, 한국어, 简体中文, 繁體中文 |
| Interface | USB/AV OUT |
| Battery | Li-ion battery: NP45 (3.7V, 700mAh) |
| Battery Level | Full-Half (65% ± 15%) Half-Low (25% ± 15%) Low-Exhausted (10% ± 10%) |
| USB adapter | Rated input voltage: AC 100V-240V (160mA, 50/60Hz) Rated output voltage: DC 5V/1A Operating temperature: 0°C - 40°C |
| Operating Temperature | 0°C - 40°C |
| Operating Humidity | 0% - 90% |
| Microphone | Built-in |
| Speaker | Built-in |
| Dimensions | 100.9 x 61.1 x 26.7 mm (L / H / D) |
| Weight | 127 g (no battery) |