

Verbatim Nintendo Switch™ Accessories

Verbatim Nintendo Switch™ accessories are designed to enhance the experience of using your Nintendo Switch™. With a wide range of products including controllers, cases, grips, stands and more, Verbatim has everything you need to store, protect and transport your console. Verbatim Nintendo Switch™ accessories are backed by a 1-Year Limited Warranty.



Nintendo Switch™ Controllers



Wired Controller

- Wired controller – designed for use with Nintendo Switch™ console
- Direct connection to console (using included USB-C adapter) for lag-free performance
- Easy to use – ideal for long playing times
- Includes vibration function for more realistic game play
- 6 ft. cable lets you sit back and enjoy gaming
- 1-year limited warranty



Part No.	Description
99797	Wired Controller for use with Nintendo Switch™ – Black



Wireless Controller

- Wireless controller – designed for use with Nintendo Switch™ console
- 2.4Ghz wireless connection for lag-free performance
- Easy to use – ideal for long playing times
- Includes vibration function for more realistic game play
- Easily charge controller using included microUSB cable
- 1-year limited warranty



Part No.	Description
70221	Wireless Controller for use with Nintendo Switch™ – Black

Nintendo Switch™ Cases



Starter Kit

- Starter kit gives you everything you need to protect and travel with Nintendo Switch™
- Protective EVA case protects console while in transit
- Screen protection film protects console screen from everyday scratches, dust and more
- Soft insert offers additional screen protection as well as storage for 10 game cards
- Included expansion card slot stores 6 game cards and 2 SD cards
- Includes silicon controller covers, thumb stick covers and protective plugs – offers protection from dust and debris
- Included controller grip is ideal for long playing times
- 1-year limited warranty



Part No.	Description
99801	Starter Kit for use with Nintendo Switch™

Crystal Case

- Slim and lightweight crystal case protects console and controllers while in use
- Screen protection film protects console screen from everyday scratches, dust and more
- 1-year limited warranty



Part No.	Description
70220	Crystal Case with Screen Protection Film for use with Nintendo Switch™



Carrying Case

- Protective EVA case protects console while in transit
- Stores console, 2 controllers and 10 game cards
- Elastic band holds console safely in place
- Soft insert for additional screen protection
- Extra zippered pouch for additional storage
- 1-year limited warranty



Part No.	Description
99800	Carrying Case for use with Nintendo Switch™ – Black/Red



Storage Case

- Protective EVA case with fabric exterior protects console
- Foam-padded interior keeps console and accessories safe
- Stores console, 2 controllers, 2 controller straps, power adapter and HDMI cable
- Mesh pocket for additional storage
- Convenient carrying handle
- 1-year limited warranty



Part No.	Description
99799	Storage Case for use with Nintendo Switch™ – Black

Nintendo Switch™ Charging Stands



Console Charging Stand

- Charges console while in use – enables longer play times
- Compact, portable design – perfect to take on-the-go
- Compatible with Nintendo Switch™ power adapter*
- 1-year limited warranty



Part No.	Description
99794	Console Charging Stand for use with Nintendo Switch™



Dual Console Charging Stand

- Charges two consoles simultaneously – ideal for gaming with friends
- Charges consoles while in use – enables longer play times
- Compact, portable design – perfect to take on-the-go
- Compatible with Nintendo Switch™ power adapter*
- 1-year limited warranty



Part No.	Description
99795	Dual Console Charging Stand for use with Nintendo Switch™



Multi Controller Charging Stand

- Charges up to 4 Joy-Con™ controllers or 2 Pro controllers simultaneously – mix and match for the ultimate in charging function
- LED indicator for charge level – red indicates charging while green indicates fully charged
- Compact, portable design – perfect to take on-the-go
- Compatible with Nintendo Switch™ power adapter*
- 1-year limited warranty



Part No.	Description
99796	Multi Controller Charging Stand for use with Nintendo Switch™ Controllers

*Adapter not included.

Nintendo Switch™ Joy-Con™ Controller Grips



Controller Grips

- Designed for use with Nintendo Switch™ Joy-Con™ Controllers
- Includes 2 grips for either right or left controllers
- Simple to use – easy to attach and remove controllers
- Lightweight, ergonomic design – ideal for long playing times
- Includes SL and SR buttons
- 1-year limited warranty



Part No.	Description
99798	Controller Grips for use with Nintendo Switch™ Joy-Con™ Controllers – Black



Charging Controller Grip

- Charging grip charges controllers while in use
- Indicator lights display charge level
- Charge grip using included USB-C cable and any USB-C charger
- Simple to use – easy to attach and remove controllers
- Lightweight, ergonomic design – ideal for long playing times
- 1-year limited warranty



Part No.	Description
70219	Charging Controller Grip for use with Nintendo Switch™ Joy-Con™ Controllers – Black