

aquapix® W1400 Active



The AquaPix W1400 Active camera is shown in two views: a front view and a back view. The front view shows the camera's lens, flash, and the 'aquadix W1400' branding. The back view shows the 2.7" LCD display and the 1.8" TFT LCD screen. The camera is black with orange accents and is shown floating in clear blue water with bubbles. In the background, a person is swimming underwater, wearing a blue and white striped swimsuit, yellow fins, and a yellow snorkel. The person is swimming over a coral reef.

3m
Waterproof

14MP
Sensor

20MP
Max.
Resolution

4x
Digital
Zoom

2.7"/
6.8cm
TFT LCD

1.8"/
4.5cm
TFT LCD

Support
SD Cards
up to 32GB

Video
Recording
with sound



aquapix®
A brand of Easypix®

Sensor	14 Mega pixel CMOS sensor
Image Resolution	20 MP (5184 x 3888) by interpolation
	14 MP (4320 x 3240)
	8 MP (3264 x 2448)
	5 MP (2592 x 1944)
	3 MP (2048 x 1536)
	VGA (640 x 480)
Movie Clips	640 x 480 (VGA), 320 x 240 (QVGA), 30fps
Lens	F/2.8 f=8.5mm
Digital Zoom	4x
External Memory	Micro SD/SDHC Card support up to 32GB (not included)
Dual Display	6.8 cm (2.7") TFT LCD + 4.5 cm (1.8") TFT LCD
Waterproof	Up to 3 meters
File Format	JPEG, AVI (M-JPEG)
Interface	USB 2.0 High Speed
Auto Power Off	Off/1Minute/3Minute
Self timer	Off/10 sec.
Flash strobe	Auto/force/off
ISO	Auto/100/200/400/800
White balance	Auto/Daylight/Cloudy/Fluorescent/Tungsten
Exposure Compensation	-2.0 EV ~ +2.0 EV in 0.3 step
Shutter Speed	1/4 sec. - 1/4000 sec.
Special effect (preview)	Normal/B&W/Sepia/Negative/Lomo/Pencil Sketch/Red/Green/Blue/Vivid
Special effect(playback)	B&W/Sepia/Negative/Mosaic/Red/Green/Blue
USB Port	USB 2.0 high Speed
Support system	WinXP (SP3), Vista32/64, Win7 & Win8 32/64, Mac OSX 10.6.8 or above
Language	English/German/Italian/Portuguese/French/Spaish/Japanese
Power Source	2x AAA battery

Accessories

- USB cable
- Pouch
- Hand strap
- Manual
- CD
- 2x AAA battery

