Instant Camera Printer + App

Preliminary Version 1.0CN



"ICMPP1"

Take and print photos while getting creative with the free IVY app to add filters, effects, and fun!

The Perfect Addition

The Canon "ICMPP1" is the small and fun Instant Camera and Mini Photo Printer that can fit in your pocket so you can take it anywhere! The "ICMPP1" features a large 2" Selfie Mirror with an 8 LED ring light for great looking selfies! Easily connect your smartphone to the Canon Mini Print app via Bluetooth¹ and take a photo with your smartphone's camera or choose one of your own photos. Even use fun AR filters and add effects, frames, text, and stickers to your 2"x3" photos with a peel & stick back!

"ICMPP1" Features





Large 2" selfie mirror to get the perfect shot



MicroSD card slot²



Remote shutter via the Mini Print app¹



Print fun 2"x3" photos



8 LED ring light - for the perfect selfies



Get creative with Tile Print¹



All photos have a peel & stick back



Reprint button on camera



Print portrait or landscape photos

What is ZINK[™] and how does it work?



ZINKTM stands for "ZERO INK" printing technology. Instead of ink, it uses colorful dye-based crystals embedded inside the paper. Before printing, the embedded dye crystals are clear so ZINKTM Paper looks like regular, white photo paper. The ZINK-enabled device uses heat to activate and colorize these crystals.



"ICMPP1"

Instant Camera Printer + App Preliminary Version 1.0CN

TECHNICAL SPECIFICATIONS

PRINTER SPECIFICA	TIONS	
Print Technology	ZINK™- "Zero Ink"	
Print Speed ³	50 Seconds or less	
Print Resolution	314 x 600 dpi	
Borderless Printing	Yes	
Automatic Paper Sensor	Yes	
Supported Media Type	ZINK™ Photo Paper	
Maximum Paper Size	2.0" x 3.0"	
Paper Capacity	Up to 10 Sheets of Canon ZINK™ Photo Paper	
	&1 SMART SHEET™	
CAMERA SPECIFICA	TIONS	
Camera Resolution	8 MP	
Photo Format	JPEG	
Video Capable	No	
Camera Aspect/Print Size	2" x 3", 2" x 2"	
Flash	Yes	
8 LED Ring Light	Yes (8 LED / 4 LED)	
Focus	Auto	
Zoom	Fixed	
ISO	Auto (Range: 100 - 1600)	
White Balance	Auto	
Exposure Adjustment	Auto	
Self Timer ¹	Yes, via Mini Print app (10 Sec/5 Sec/ 3 Sec)	
Viewfinder	Yes	
Remote Shutter ¹	Yes, via Mini Print app	
Selfie Mirror	Yes - Large 2" Circular Selfie Mirror	
Tripod Mount	No	
Reprint Button	Yes	
CONNECTIVITY		
Bluetooth ¹	Bluetooth® 4.0	
Printer Connection ¹	Bluetooth - via the Canon Mini Print App	
Wi-Fi® Capable	No	
COMPATIBLE OPERA	ATING SYSTEMS & APP	
Compatible OS ¹	iOS®: 9.0 or later, Android™: 4.4 or later	
Mobile App ¹	Canon Mini Print app	
App Features ¹	Over 200 Stickers, Over 30 Frames & Filters,	
	Add Text & Drawing, Color Adjustment, AR Live	
	Filters & Face Distort, Tile Print, Collage Print,	
	Remote Shutter, Selfie Timer	
Photo Selection	Local/On Device, Facebook, Instagram, Google	
(Local/Cloud) ¹	Drive, Dropbox, iCloud (iOS Devices Only)	

CTODACE O MEMOR			
STORAGE & MEMOR Built-in Storage Memory	None		
	Yes, MicroSD Memory Card (Up to 256 GB)		
Mass Storage Mode ²	Yes, via included Micro USB 2.0 Cable		
ZINK TM PHOTO PAPE			
Photo Paper Information	2" x 3" Photo Paper Size, Sticker Back,		
•	Smudge-Free, Water & Tear Resistant		
Photo Paper Storage	Temperature: 34 - 77°F (1 - 25°C)		
Environment	Humidity: 40 - 55% Relative Humidity		
BATTERY & POWER			
Battery Type	Built-in Rechargeable Lithium-Polymer (700 mAh)		
Battery Life	Approx. 25 Photos		
Battery Charge Time			
battery charge rime	Full Charge in Approx. 90 Minutes		
LICD Down	(Measured at 5V/1A Charging Speed)		
USB Port	Micro USB for Charging & Data		
Auto Power Off 1	Yes (10 Min / 5 Min / 3 Min)		
GENERAL Control Panel	Power Button, Shutter Button, Reprint Button,		
Control Funci	Aspect Ratio Button (2x3 / 2x2), Flash Side		
	Switch (Auto / On / Fill Light)		
Diamless Toma			
Display Type	LED Light System		
Bottom LED (Charging)			
	Green: Charging Complete		
Top Power LED (Status)	Color Flashing Loop: Printing Photo, White: Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error		
Top Power LED (Status) Aspect Ratio LED	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer		
	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error		
Aspect Ratio LED	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes		
Aspect Ratio LED Speaker Status	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera		
Aspect Ratio LED Speaker Status	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card,		
Aspect Ratio LED Speaker Status (Customizable)	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card, SD Card Error		
Aspect Ratio LED Speaker Status (Customizable) Recommended	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card, SD Card Error Temperature: 59 - 90°F (15 - 32°C)		
Aspect Ratio LED Speaker Status (Customizable) Recommended Operating Environment	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card, SD Card Error Temperature: 59 - 90°F (15 - 32°C) Humidity: 40 - 55% Relative Humidity		
Aspect Ratio LED Speaker Status (Customizable) Recommended Operating Environment	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card, SD Card Error Temperature: 59 - 90°F (15 - 32°C) Humidity: 40 - 55% Relative Humidity Battery Charging (BC) Systems - California		
Aspect Ratio LED Speaker Status (Customizable) Recommended Operating Environment Certification	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card, SD Card Error Temperature: 59 - 90°F (15 - 32°C) Humidity: 40 - 55% Relative Humidity Battery Charging (BC) Systems - California Energy Commission (CEC) Compliant		
Aspect Ratio LED Speaker Status (Customizable) Recommended Operating Environment Certification Reset Button	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card, SD Card Error Temperature: 59 - 90°F (15 - 32°C) Humidity: 40 - 55% Relative Humidity Battery Charging (BC) Systems - California Energy Commission (CEC) Compliant		
Aspect Ratio LED Speaker Status (Customizable) Recommended Operating Environment Certification Reset Button Warranty ⁴	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card, SD Card Error Temperature: 59 - 90°F (15 - 32°C) Humidity: 40 - 55% Relative Humidity Battery Charging (BC) Systems - California Energy Commission (CEC) Compliant		
Aspect Ratio LED Speaker Status (Customizable) Recommended Operating Environment Certification Reset Button Warranty ⁴ BOX CONTENTS	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card, SD Card Error Temperature: 59 - 90°F (15 - 32°C) Humidity: 40 - 55% Relative Humidity Battery Charging (BC) Systems - California Energy Commission (CEC) Compliant Yes 1-Year Limited Warranty		
Aspect Ratio LED Speaker Status (Customizable) Recommended Operating Environment Certification Reset Button Warranty ⁴ BOX CONTENTS	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card, SD Card Error Temperature: 59 - 90°F (15 - 32°C) Humidity: 40 - 55% Relative Humidity Battery Charging (BC) Systems - California Energy Commission (CEC) Compliant Yes 1-Year Limited Warranty		
Aspect Ratio LED Speaker Status (Customizable) Recommended Operating Environment Certification Reset Button Warranty ⁴ BOX CONTENTS	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card, SD Card Error Temperature: 59 - 90°F (15 - 32°C) Humidity: 40 - 55% Relative Humidity Battery Charging (BC) Systems - California Energy Commission (CEC) Compliant Yes 1-Year Limited Warranty Canon "ICMPPI" Instant Camera Printer, ZINK™ Photo Paper Pack (10 Sheets & 1 SMART SHEET),		
Aspect Ratio LED Speaker Status (Customizable) Recommended Operating Environment Certification Reset Button Warranty ⁴ BOX CONTENTS	Power On/Standby, White Flashing: Processing SMARTSHEET™, Preparing to Print/Firmware Updating, Red: Device too high of temperature, Red Flashing: Cover Opened/Printing Error/No Paper/ Paper Jam, Red - White Flashing: Low Battery, Blue - White: Device is Booting, Blue Flashing: SMARTSHEET™ Error, Cyan: Device too low of temperature, Cyan Flashing: Printer Head Cooling, Magenta: Mass Storage Mode, Magenta Flashing: MicroSD Error Yes Power On/Off, Camera Focus Lock, Camera Shutter, Reprint Failed, Insert/Eject SD Card, SD Card Error Temperature: 59 - 90°F (15 - 32°C) Humidity: 40 - 55% Relative Humidity Battery Charging (BC) Systems - California Energy Commission (CEC) Compliant Yes 1-Year Limited Warranty Canon "ICMPP1" Instant Camera Printer, ZINK™ Photo Paper Pack (10 Sheets & 1 SMART SHEET), Micro USB Charging & Data Cable (USB A to		



"ICMPP1"

Instant Camera Printer + App Preliminary Version 1.0CN

ORDERING INFORMATION

ZP-2030-50

ZP-2030-20

MODEL NUMBER	DESCRIPTION	ITEM NUMBER	UPC CODE	
Minimum Order Quantity: 1, RECOMMENDED ORDER QUANTITY: 4				
ZV-123-Pearl White	"ICMPP1" Instant Camera Printer + App - Pearl White	3879C002[AA]	0 13803 32101 2	
ZV-123-Sapphire Blue	"ICMPP1" Instant Camera Printer + App - Sapphire Blue	3879C003[AA]	0 13803 32102 9	
ZV-123-Ruby Red	"ICMPP1" Instant Camera Printer + App - Ruby Red	3879C004[AA]	0 13803 32103 6	
ADDITIONAL ZINK™ PAPER				
Minimum Order Quantity: 1, RECOMMENDED ORDER QUANTITY: 48				
7D 2030 50	ZINK™ Photo Paper Pack	2215C001[4.4]		

(50 Sheets)

ZINK™ Photo Paper Pack

(20 Sheets)

Luy		
"ICMPP1" & BOX INFOR	RMATION	
Country of Origin	VIETNAM	
Tariff Number	8443321050	
"ICMPP1" Dimensions	4.8" (L) × 3.2" (W) × 0.8" (H)	
"ICMPP1" Weight	0.4 lbs.	
"ICMPP1" Box Dimensions ⁵	5.6" (L) × 4.2" (W) × 1.6" (H)	
"ICMPP1" Box Weight	0.6 lbs.	
Availability	March 2019	

PALLET INFORMATION					
Number of "ICMPP1" per Inner Carton	4				
Dimensions of Inner Carton	6.9" (L) x 4.4" (W) x 6.1" (H)				
Weight of Inner Carton	2.6 lbs.				
Number of Inner Cartons per Master Carton 4					
Number of "ICMPP1" per Master Carton	16				
Dimensions of Master Carton	13.9" (L) x 9.5" (W) x 6.7" (H)				
Weight of Master Carton	11.0 lbs.				
Number of Master Cartons per Pallet	84				
Number of Master Cartons per Layer	12				
Number of Layers per Pallet	7				
Total Number of "ICMPP1" Per Pallet	1,344				
Dimensions (Pallet & Master Cartons)	48.0" (L) x 40.0" (W) x 52.4" (H)				
Dimensions without Pallet	41.7" (L) x 38.0" (W) x 46.9" (H)				
Loaded Pallet Weight	974.0 lbs.				

3215C001[AA]

3214C001[AA]

SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL VIEWSCREEN AND OUTPUT IMAGES ARE SIMULATED.

- Requires mobile device to be connected to the Canon IVY Mini Photo Printer via Bluetooth* and the Canon Mini Print App, available for free on the App Store and at Google Play. Compatible with mobile devices running iOS 9.0 or later, and Android devices running Android 4.4 or later.
- 2 Mass Štorage Mode is available when using a supported microSD card that is installed and formatted and while using the included USB 2.0 cable and a compatible desktop operating system. Compatible desktop operating systems include Windows 10, 8.1, 8 or $\overline{7}$ and Mac OS X v10.10 - Mac OS 10.14. MicroSD card not included. 3 Depending on operating temperature.

- Warranty programs are subject to certain conditions and restrictions. For customers in the United States, visit www.usa.canon.com/support for more details, for customers in Canada, visit www.canon.ca/support
- 5 Product box dimensions measured in vertical box configuration









©2019 Canon U.S.A., Inc. Canon is a registered trademark of Canon Inc. in the United States and may be a registered trademark, or trademark, in other countries. "ICMPPI" is a trademark of Canon U.S.A., Inc. in the United States. SMART SHEET, the ZINK Technology and ZINK Trademarks are owned by ZINK Holdings LLC, used under license. Apple, the Apple logo, iPad, iPad Air, iPad Pro, and iPhone are trademarks of Apple Inc., registered in the United States and other countries. App Store is a service mark of Apple Inc. iOS is a trademark or registered trademark of Cisco in the United States and other countries and is used under license. Android, Google Play and the Google Play logo are trademarks of Google LLC. Bluetooth is a registered trademark of Bluetooth SIG. Wi-Fi is a registered trademark of the Wi-Fi Alliance. All other third-party product names, brand names and logos are trademarks of their respective owners.