


Network 3D Blu-ray Disc™ / DVD Player BP645

ENGLISH | SIMPLE MANUAL

To view the instructions of advanced features, visit http://www.lg.com and then download Owner's Manual. Some of the content in this manual may differ from your unit.




MEL 88102013

www.lg.com





TV Connection (HDMI OUT)





Wired Network Connection





Initial Setup


Follow the directions for the initial setup displayed on






Make sure that LAN cord is plugged or wireless router










Using HOME menu



Displays SmartShare menu.





Displays LG Apps titles provided to the unit.




Displays the [My Apps] screen.





Adjusts the system settings.



Disc, Data Playback







For the most Audio CD, BD-ROM and DVD-ROM discs, playback starts automatically.



Network Playback

SmartShare PC software Installation




Download SmartShare PC software on the support tab and install it.





Run the program, and set the share folder you

SmartShare Network Playback




Check the network connection and settings.







BP640-P.BGBRLLK_SIM_MFL68102013.indd 1 2014-01-28 5:33:44





Turn on the device and run its [Miracast] function.







Depending on your wireless network condition, mirroring may be unstable.

909

Enjoying Private Sound



Make sure that mobile device is connected to the same Wi-Fi network as this player.




Turn on the mobile device LG AV Remote App is Installed and run LG AV Remote App.



Not all modes support sound privacy and pairing multiple devices is not available.



Software Update







Additional Information

Customer Support

You can update the Player using the latest software to enhance the products operation and/or add new features. To obtain the latest software for this player (if updates have been made), proceed the software updates as wirtten or visit http://www.lg.com or contact LG Electronics customer

Open source software notice

To obtain the corresponding source code under GPL, LGPL and other open source licenses, please visit http:// opensource.lge.com. All referred license terms, warranty disclaimers and copyright notices are available to download with the source code.



Specification

ENGLISH

LINGLISH	
Power requirements	200 - 240 V ~ 50 / 60 Hz
Power consumption	12 W
Dimensions (W \times H \times D)	Approx. 430 mm x 43.5 mm x 205 mm
Net Weight (Approx.)	1.5 kg
Bus Power Supply (USB)	5 V === 500 mA

Design and specifications are subject to change without notice.

POWER: This unit operates on a mains supply of 200-240V~, 50/60Hz.

Wiring: This unit is supplied with a BS 1363 approved main plug. When replacing the fuse, always use of the same rating approved to BS 1362. Never use this plug with the fuse cover omitted. To obtain a replacement fuse cover contact your dealer. If the type of plug supplied is not suitable for the mains sockets in your home, then the plug should be removed and a suitable type fitted. Please refer to the wiring

Warning: A mains plug removed from the mains lead of this unit must be destroyed. A mains plug with bared wires is hazardous if inserted in a mains socket. Do not connect either wire to the earth pin, marked with the letter E or with the earth symbol 🚽 or coloured green or green and yellow. If any other plug is fitted, use same rating of fuse in the plug.

Important: The wires in this mains lead are coloured in accordance with the following codes:

- BLUE: NEUTRAL, BROWN: LIVE - As the colours of the wires in the mains lead of this unit may not correspond with the coloured marking identifying the terminals in your plug, proceed as follows. The wire which is coloured blue must be connected to the terminal which is letter L or coloured red.





Safety Information













within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric hock to persons. The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and

This lightning flash with arrowhead symbol within

an equilateral triangle is intended to alert the user

to the presence of uninsulated dangerous voltage

naintenance (servicing) instructions in the terature accompanying the product. WARNING: TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD, DO

NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE. WARNING: Do not install this equipment in a confined space such

CAUTION

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT

REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE

REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

as a book case or similar unzzit. CAUTION: Do not block any ventilation openings. Install in

accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings shall be never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.



Use of controls, adjustments or the erformance of procedures other than those pecified herein may result in hazardous

CAUTION concerning the Power Cord To disconnect power from the mains, pull out the mains cord plug. When installing the product, ensure that the plug is easily

CAUTION: The apparatus shall not be exposed to water (dripping or splashing) and no objects filled with liquids, such as vases, shall be placed on the apparatus.

This device is equipped with a portable battery or accumulator.

Safety way to remove the battery or the battery from the equipment: Remove the old battery or battery pack, follow the steps in reverse order than the assembly. To prevent contamination of the environment and bring on possible threat to human and animal health, the old battery or the battery put it in the appropriate container at designated collection points. Do not dispose of batteries or battery together with other waste. It is recommended that you use local, free reimbursement systems batteries and accumulators. The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

Disposal of your old appliance



disposed of separately from the municipal waste

stream via designated collection facilities appointed by the government or the local authorities. 3. The correct disposal of your old appliance will help

prevent potential negative consequences for the environment and human health. 4. For more detailed information about disposal of your

old appliance, please contact your city office, waste disposal service or the shop where you purchased

Disposal of waste batteries/accumulators



. When this crossed-out wheeled bin symbol is attached to batteries/accumulators of Your product it means they are covered by European Directive 2006/66/EC.

- 2. This symbol may be combined with chemical symbols for mercury(Hg), cadmium(Cd) or lead(Pb) if the battery Contains more that 0.0005% of mercury, 0.002% of cadmium or 0.004% of lead.
- 3. All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the

government or the local authorities.

- accumulators will help to prevent potential negative consequences for the environment, animal and human health.
- 5. For more detailed information about disposal of Your old batteries/ accumulators, please contact Your city office, waste disposal service or the shop where You purchased the product.

For Wireless product European Union Notice



requirements and other relevant provisions of Directive 1999/5/EC, 2004/108/EC, 2006/95/EC, 2009/125/EC and 2011/65/EU. Please contact to the following address for obtaining a copy of the

DoC (Declaration of Conformity).

Contact office for compliance of this product:

- EU Representative, Krijgsman 1
- 1186 DM Amstelveen, The Netherlands

RF Radiation Exposure Statement

• Please note that this is NOT a Customer Service contact point. For Customer Service Information, see Warranty Card or contact the dealer that you purchased this product.

This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

Technology with the human touch **GUARANTEE**

- LG Electronics U.K. Ltd. will provide the following services in order to expedite this Guarantee. 1. All faulty components which fail due to defective manufacture will be replaced free of charge for a period
- of 12 months from the original date of purchase.
- 2. The dealer (or his service agent) who sold the product will be
- reimbursed for any labour provided in the repair of this LG equipment, for a period of 12 months from the original date of purchase. These claims must be made in accordance with the published scale of service charges and relevant claims procedure.

PLEASE NOTE:

A. The dealer may restrict the guarantee to the original purchaser.

- B. The dealer is not obliged to carry out service under guarantee if unauthorized modifications are made to the apparatus, or if non standard components are used or if the serial number of the apparatus is removed, defaced, misused, or altered.
- C. Any claims made under guarantee must be directed to the dealer from whom the equipment was originally purchased. The dealer may, before carrying out service under guarantee, require a receipted account as evidence of the date of purchase.
- D. We respectfully point out that your dealer is not obligated to replace batteries if they become exhausted or worn in use.
- E. Aerial alignment and consumer control adjustments are not covered by this guarantee.

This guarantee does not affect your statutory rights.

- REQUIREMENTS TO MAINTAIN WARRANTY COVERAGE:
- RETAIN YOUR RECEIPT TO PROVE DATE OF PURCHASE. A COPY OF YOUR RECEIPT MUST BE SURRENDERED AT THE TIME GUARANTEE SERVICE IS PROVED.
- Product Registration Card :
- It is helpful to complete at least your name, address, phone, model & serial numbers and return it. This will enable LG to assist you in the future should you lose your receipt, your units be stolen, or should modifications be necessary.
- To obtain information or assistance: Call 0844 847 5454 Monday-Friday 8am-8pm

MODEL NO.*	SERIAL NO.*	DATE OF PURCHASE.*

In all cases of difficulty - consult your LG dealer from whom the product was purchased

LGEUK Website: www.lg.com/uk

(Service website : www.lg.com/uk/support)

BP640-P.BGBRLLK_SIM_MFL68102013.indd 2 2014-01-28 5:33:47