



Dirty windows can be a nuisance, especially after the winter months when dirt and stains reduce the quality of light within your home. At Kärcher, we believe that having the right tools for the job is essential and when it comes to window cleaning there's no substitute for the Kärcher WV5. The WV5 builds on Kärcher's original window vac design, promising you great looking, streak-free windows with the greatest of ease. Equipped with an extended long-life battery which is inter-changable, you can continue working without stopping to recharge. The unit's LED display shows the level of battery life so you're never caught short. Suitable for use inside and outside the home, the WV5 also simplifies cleaning other glass or mirrored items. If you're looking for a way to take better care of all smooth surfaces around your home, the versatile and lightweight WV5 is the ideal companion.

VOM ERFINDER DES
AKKU-FENSTERSAUGERS
**DAS
ORIGINAL**



WV5 Premium

Technical data

Order No.	1.633-451.0	
EAN code	4054278053332	
Working width of vacuum nozzle	cm	280
Dirty water container capacity	ml	100
Battery charging time	min.	185
Battery running time	min.	35
Cleaning performance per battery charge	Approx. 105 m ² = 35 windows	
Voltage	V	100-240
Frequency	Hz	50-60
Weight incl. battery	kg	0,7

Equipment

Glass cleaner concentrate	ml	20
Spray bottle with microfibre cloth	■	
Suction nozzle, wide with distance spacers	280 mm	
Suction nozzle, narrow	170 mm	
Removable lithium-ion battery	■	
Battery charger	■	

■ Included in delivery.

ACCESSORIES FOR WV5 PREMIUM

1.633-451.0



		Order No.					Price	Description	
Power supplies									
Window Vac Battery Charger	1	2.633-115.0						Replacement charger for your Kärcher window vacuum. This replacement charger is suitable for all models of Kärcher window vacuums.	■
Spray bottle									
Window Vac Spray Bottle Set	2	2.633-114.0						Keeping your windows clean is all about having the right tools for the job. Our window vac spray bottle set combines perfectly with our window vacs to give the same great results every time.	■
Base stations									
WV5 Charging station and replaceable battery	3	2.633-116.0						The Kärcher WV5 charging station and replacement battery allows you to keep your window vac 5 and a spare battery charged.	<input type="checkbox"/>
WV5 charging station	4	2.633-125.0						Charging station for the WV5 window vac. This charging station allows you to charge your WV5 window vac and a spare battery at the same time.	<input type="checkbox"/>
Accessory kits									
Window Vac Accessory Kit	5	2.633-122.0						The Kärcher window vac accessory kit is a perfect addition to your window vac, helping make your window cleaning task that bit easier.	<input type="checkbox"/>
Replacement blades									
Pull-off lip, wide	6	2.633-005.0						To replace pull off lips of Window Vacuums. For a streak-free finish on all even surfaces - without any dripping.	<input type="checkbox"/>
Pull-off lip, narrow	7	2.633-104.0							<input type="checkbox"/>
Extensions									
Extension set for Window Vac	8	2.633-111.0						The Kärcher Window Vac extension pole is compatible with any model of Window Vac, allowing you to clean high windows and hard to reach areas.	<input type="checkbox"/>
Hip bag									
Hip bag WV	9	2.633-006.0						Hip bag for practical storage of Window Vac and spray bottle.	<input type="checkbox"/>
Replacement cloths									
Window Vac Microfibre Cloths (2 pack)	10	2.633-100.0						A set of two replacement microfibre cloths for the Kärcher Window Vac spray bottle. Get a streak-free clean with these specially designed machine-washable cloths.	<input type="checkbox"/>
Replacement batteries									
WV5 replaceable battery	11	2.633-123.0						Additional battery for the WV5 window vac. This enables you to continue cleaning your whole house without interruptions. Giving you up to 1 hour and 10 minutes cleaning time.	<input type="checkbox"/>

■ Included in delivery. □ Available accessories.