

# Quick Start Guide

1


## PLUG IN SENTRY EMS

- Wait for up to 30 seconds.
- No need to restart your computer.
- Drive letters vary with computer.

2


## SETUP/UNLOCK\*

Device autostarts or **Double-click & Run**



3

## WORK



**Manage Files**



**Sentry EMS locks** when it is unplugged, powered down, timed out, locked from the menu or when you log out.

\* If this window does not appear, open it manually:

- Windows: Start > This PC > Unlocker > Unlocker.exe
- Mac: Finder > Unlocker > Unlocker

Securely manage all of your IronKey Enterprise devices with IronKey EMS (license sold separately).

For more information visit [datalocker.com/ems](https://datalocker.com/ems)