



## Cleaning and replacing the separation roller




## Support Information

[www.alarisworld.com/go/S2000support](http://www.alarisworld.com/go/S2000support)  
[www.alarisworld.com/go/S2000wsupport](http://www.alarisworld.com/go/S2000wsupport)

**When contacting support, have the following available:**

- A description of your problem
- Scanner model and serial number
- Computer configuration
- Software application you are using

## Cleaning the imaging area



## Supplies and Consumables

[www.alarisworld.com/go/S2000support](http://www.alarisworld.com/go/S2000support)  
[www.alarisworld.com/go/S2000wsupport](http://www.alarisworld.com/go/S2000wsupport)

© 2018 Kodak Alaris Inc.  
TM/MC/MR: Alaris  
A-61900 / Part #5K7580 May 2018

All trademarks and trade names used are the property of their respective holders. The Kodak trademark and trade dress are used under license from Eastman Kodak Company.



5K7735



# Alaris

S2000 Series Scanners  
S2000w Series Scanners





Reference Guide



## Cleaning the rollers



## Cleaning the feed rollers



## Cleaning and replacing the separation roller

