

SAMSUNG Galaxy Tab S6

Samsung Care



Samsung Premium Care

Get more than just protection for your device. Pick the time and place, and a team member will meet you to setup, troubleshoot, repair or replace your product.

Enroll, at samsung.com/us/support/premium-care

Get to know your product:

- Access user manuals, tips and more at samsung.com/us/support


Ask the community:

- Ask questions and get solutions from Samsung customers, at us.community.samsung.com

Contact us for support:

- For hardware or software support, visit samsung.com/us/support/contact or call us at 1.800.SAMSUNG
- Find a service location near you, at samsung.com/us/support/service/locations

About your device



©2019 Samsung Electronics America, Inc. Samsung and Galaxy Tab are both trademarks of Samsung Electronics Co., Ltd. Android, Google, Google Play, and other marks are trademarks of Google LLC. Other company and product names mentioned herein may be trademarks of their respective owners. Screen images simulated. Appearance of tablet may vary.

Printed in Vietnam
GH68-50998F



Device features

Expandable storage Expand storage with a microSD™ card.


Flexible security Biometric security features.

S PEN Enables accurate, and precise input while providing a natural writing experience.

Bixby Home See upcoming appointments, photos, tomorrow's weather and more.

Multuser Allows multiple users for one device.

Quick Reference Guide




Customize your device

Tap **Settings** to customize, connect or turn on options to personalize your device.

Wallpaper Change the look of the Home and Lock screens.

Accounts and backup Tap Users to add additional users for the device.

Biometrics and security Set biometric security options.



Connections Connect to Wi-Fi network, Bluetooth device and other connection options.

Lock screen Select a screen lock type and set security options.

Display Customize the Home screen and display brightness.

Sounds and vibration Set device volume and sounds.

Samsung Internet

USB/Audio port

Camera

S Pen

Camera

Side key (Power/Bixby)

Volume

microSD™ card slot

Messages

S Pen

The S Pen™ enables fast, accurate, and precise input while providing a natural writing experience. Write and draw directly into emails or the calendar, as well as Word, Excel, PowerPoint, and PDF documents.

S Pen button

Press and hold the S Pen button to open an app remotely.

A single or double press can open an app, capture a photo, navigate, scroll and more.

Remove the S Pen, and tap **Settings** > **Air actions** to set the S Pen remote features.


S Pen button

Air command

To launch Air Command, tap the screen with the tip of the S Pen and then tap .

- **Create note** Create short notes.
- **View all notes** Displays notes.
- **Smart select** Instantly outline and crop anything on the screen and freely edit or share with others.
- **Screen write** Capture a screen image and write or draw on it.
- **Live messages** Create a short animated message.
- **AR Doodle** Draw and write on photos.
- **Translate** Hover the S Pen over a word to view its definition and pronunciation.
- **Penup** Draw, color, edit, and share live drawings.
- **Add shortcuts** Select an app or function to open or turn on using Air command.

Set up your device



Install an optional microSD card

1. Use the tray removal tool to open the microSD™ card tray.
2. Insert the microSD card (sold separately) into the tray with the gold contacts facing down, as shown.

Charge the battery

Before turning on your device charge it fully with the provided charger.

Use only Samsung approved charging devices and batteries. Samsung accessories are designed for your device to maximize battery life. Using other accessories may void your warranty and may cause damage.

Bixby

Set reminders, see upcoming appointments, photos, tomorrow's weather and more.

To launch **Bixby**, from the home screen swipe right and follow the prompts to set up.

Visit samsung.com/us/support/owners/app/Bixby for more information.



Learn more

Use the Help feature to access the user manual and other information on how to use your device, including:



Downloading apps



Managing contacts



Downloading apps created for Galaxy devices.



Configuring accessibility settings



Connecting and controlling smart devices

To open the Help feature, from the Home screen, swipe up and tap **Settings** > **Help** .

