

SAMSUNG Galaxy Tab A



Let's get started



AT&T 5-Star
Eco-Rating 2.0
att.com/ecospace

WIRELESS
EMERGENCY
ALERTS
CAPABLE



AT&T Eco Rating 2.0 only applies to Galaxy Tab A. For limited factors evaluated visit att.com/Eco-Space. Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

Portions © 2020 Samsung Electronics America, Inc. Samsung and Galaxy Tab A are both trademarks of Samsung Electronics Co., Ltd. Portion of memory occupied by existing content. LTE is a trademark of ETSI. 4G LTE is not available everywhere. Wi-Fi is a trademark of the Wi-Fi Alliance. Contains Lithium ion battery - recycle or dispose of properly. Portions © 2020 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.



What's in the box?

- Galaxy Tab A
- Pre-installed SIM
- Travel Adapter
- USB Cable
- Inbox Guide
- Terms and Conditions

Useful Apps*



AT&T Messages

Send and receive text messages from your tablet or computer.



AT&T NumberSync

Make and receive calls on your tablet using your mobile phone number.



AT&T AllAccess

Stop worrying about data overages and take control with AT&T AllAccess data monitoring tools.



AT&T ProTech

With AT&T Mobile and Multi-Device Protection Packs, enjoy premium services and unlimited access to our team of trained support experts!

*Compatible device and subscription may be required. Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, visit att.com/shop/apps.

TV Mode

Quickly launch your favorite video app, with TV mode.

Access TV mode

- To launch TV mode:
 - From the Home screen, swipe right
 - Press the **Power button** twice
 - From the lock screen, swipe **TV mode**

To turn on TV mode and select a video app, from the home screen, swipe up and tap **Settings** > **Advanced features** > **TV Mode** and select an app.

Note: You can also turn on TV mode from the Notification panel. Simply swipe down, from the top edge of the screen and tap

Find More Information

Manage Your Account with myAT&T

- On your tablet: Swipe up for **Apps**, then tap **myAT&T**
- On the web: att.com/myATT

Compatible device and online account required. Data and messaging rates may apply for download and app usage.

Need More Help?

- On your tablet: Swipe up for **Apps**, then tap **AT&T folder** > **Device Help**
- On the web: att.com/DeviceHowTo

Give us a Call

- 611 from any AT&T wireless phone
- 800.331.0500 or prepaid 800.901.9878

Samsung Care

- To access user manuals, tips, videos, more visit samsung.com/us/support
- For hardware or software support, call 800.726.7864 or online support at samsung.com/us/support/contact
- To find a repair center near you, visit samsung.com/us/support/service/locations/

Your tablet




Need more help?
Swipe up for **Apps** > **AT&T** folder > **Device Help**

Easily Adjust Settings

Settings Menu




From the home screen, swipe up for **Apps**, then tap **Settings** .



Quick Settings

Drag the Status bar down to display the Notification panel.

The Notification panel provides quick access to device functions such as Wi-Fi, allowing you to quickly turn on or off.

Watch.
Stream.
Enjoy.

- Watch your favorite live and on demand shows anywhere with the DIRECTV App*
- Download your DVR recordings to your devices at home and watch offline anywhere*
- Enjoy thousands of movies and shows to stream anywhere

For Details:

Call 877.259.9450 Visit your local AT&T store


Go to att.com/takedirectv


NumberSync

Sync your AT&T smartphone number with a tablet to make and receive voice and video calls using your smartphone number.

- One number: Calls and texts* from your tablet will display as your smartphone number
- Simultaneous ring: Calls to your mobile phone will ring all synced devices at the same time


Setup NumberSync

1. From the Home screen, tap **Phone** .
2. Tap **OK** and follow the prompts.



Optimize the battery

From the home screen, swipe up for **Apps**, then tap **Settings**  > **Device care** .



*Req'g Internet-connected Genie HR44+ & elig. svc. Channels/content vary by pkg & location and must be streamed through the DIRECTV App. Restr's apply. Contact DIRECTV for details. ©2020 AT&T Intellectual Property. All Rights Reserved. AT&T, Globe logo, DIRECTV and all other DIRECTV marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T affiliated companies.

*Data rates may apply. Texting requires use of the AT&T Messages app.