




PJ-WMK-303

Quick Start Guide




Important Safety


1. Be sure this manual is completely understood before installation work.
2. Installation or dismantling of the projector from the projector wall mount must be carried out only by qualified service personnel (two or more).
- ▲ Use with products heavier than the maximum weights (Weight Capacity: <33lb(15kg)) indicated may result in instability causing possible injury.
3. For safety reasons, check the strength of the wall before installation. If the wall is not strong enough, reinforce it sufficiently before installation.
4. Do not make alterations to the projector wall mount.
5. Do not install the projector wall mount on a wall subject to vibration or impact.
6. To avoid fire, do not install the projector with the projector wall mount in a humid or excessively dusty place.
7. Use the supplied accessories only. Use of accessories other than those supplied may result in damage to the projector wall mount.
8. When dismantling the projector from the projector wall mount, be sure to unplug the AC power cord and other connecting cables beforehand.
9. Do not hit or hang any heavy objects on the projector wall mount. If the projector wall mount is damaged, stop use and contact a qualified service person immediately.
10. Please install this apparatus only on the horizontal surface instead of the slanting one.

* Manufacturer is not liable for any damages or injury caused by mishandling or improper installation.

Checking The Supplied Accessories




Fixed Support Arm x 1



Wall Plate x 1

NO	diagrammatic presentation	designation	quantity
A		Screw (T6X55)	5
B		Φ10mm Anchor bolt	5
C		L5 Allen key	1
D		L3 Allen key	1
E		Screw (M4X8)	4
F		Screw (M6X15)	4
G		Screw (M4X10)	4
H		M6 Connecting screws	4

* Screw G has been locked on the mount.



Wall Cover x 1




Wall Plate Cover x 1








Projector Mounting Plate x 1


To Set The Projector Wall Mount On The Wall



- The bracket is suitable for concrete wall mounting or wooden stud wall.
- Concrete wall mounting thickness must be a minimum 4" (100mm). Anchor bolt and screw (M6 × 55) are needed to be used for concrete wall installation.
- Dry-wall wall thickness must be a minimum 4.5" (114mm). Only screw (M6 × 55) is needed to be used for installation, and gypsum board thickness less than 0.59" (15mm).
- If the wall is not strong enough, reinforce it sufficiently before installation.
- Please contact reseller if you have any questions about mounting surface issue.




To Install The Projector On The Projector Wall Mount




Note: When the diameter of projector hole is M6, then Screw H shall be used.


Move the projector mounting plate leftwards/rightwards to determine the projector position.




To Adjust The Projector Forwards/Backwards




To Adjust The Projector Upwards/Downwards




To Adjust The Vertical Tilt Knob




To Adjust The Horizontal Roll Knob



To Adjust The Horizontal Rotation Knob




To Place The Decorative Cover



Note: When all adjustments are completed, the wall plate covers can be used to cover the blank area on the top of wall plate. Finally, put the wall cover on.

Product Information

Model	PJ-WMK-303
NET Weight	9.5lb(4.3kg)
Load Capacity	33lb (15kg)
Adjustable Range	10.71" -17.40" (272mm-442mm)
Adjustable Angle	± 5° tilt, left/right, front/rear and lateral rotation adjustment



中国 http://www.viewsonic.com.cn 电话: 4008 988 188	Europe http://www.viewsoniceurope.com http://www.viewsoniceurope.com/uk/support/call-desk/
香港 http://www.hk.viewsonic.com 電話: 852 3102 2900	Australia/New Zealand http://www.viewsonic.com.au Phone: 1800 880 818 (AUS) 0800 008 822 (NZ)
澳門 http://www.hk.viewsonic.com 電話: 853 2840 3687	South Africa http://ap.viewsonic.com/za/
台灣 http://www.viewsonic.com.tw 電話: 0800 899 880	Latin America (Chile) http://www.viewsonic.com/la/ http://www.viewsonic.com/la/soporte/servicio-tecnico
한국 http://ap.viewsonic.com/kr/ Phone: 080 333 2131	Latin America (Mexico) http://www.viewsonic.com/la/ http://www.viewsonic.com/la/soporte/servicio-tecnico
Singapore/Malaysia/Thailand http://www.viewsonic.com.sg Phone: 65 6461 6044	Latin America (Peru) http://www.viewsonic.com/la/ http://www.viewsonic.com/la/soporte/servicio-tecnico
India http://www.in.viewsonic.com Phone: 1800-419-0959	Latin America (Argentina) http://www.viewsonic.com/la/ http://www.viewsonic.com/la/soporte/servicio-tecnico
United States http://www.viewsonic.com Phone: 1-800-688-6688	Puerto Rico & Virgin Islands http://www.viewsonic.com Phone: 1-800-688-6688 (English) http://www.viewsonic.com/la/soporte/servicio-tecnico
Canada http://www.viewsonic.com Phone: 1-866-463-4775	