

★ HD connection


Using an HDMI Cable




DVD / Blu-ray player
/ HD Cable Box / HD
STB (Set-Top-Box)
satellite receiver

★ HD connection

Using an HDMI to DVI Cable



DVD /
Blu-ray player



VIDEO OUT AUDIO OUT VCR

Using an Audio/Video Cable

EXT VCR / DVD


Using a Scart Cable

Component connection

Using a Component Cable



DVD, Blu-ray
player, cable
box, STB satellite
receiver, VCR




Plasma TV

QUICK SETUP GUIDE

The Supplied Accessories

- Remote Control & Batteries (AAA x 2)
- Owner's Instructions
- Warranty Card / Safety Guide (Not available in some locations)
- Cleaning Cloth
- Power Cord




• Blanking Bracket




• Ferrite Core (3EA)
(depending on the country)

See separate guide for installing the stand.



• Stand (1EA)




• Guide Stand (1EA)




• Screws (10EA)

Ferrite Core: The ferrite cores are used to shield the cables from interference. When connecting a cable, open the ferrite core and clip it around the cable near the plug as shown in the figure.

- Distance between the ferrite core and one end of the cord put into the TV set



- A : below 50 mm
- B : below 20 mm



- C : 100 ~ 150 mm
- D : below 15 mm


(Switzerland only)




BN68-02789A-01

Installing the Stand


Preset



Step 1



Step 2



Preset: Place the Guide Stand and Cover Neck onto the stand and fasten it using the screws. Applicable to models (Depending on the model)


Step 1. Attach your PDP TV to the stand.

- Two or more people should carry the TV.
- Make sure to distinguish between the front and back of the stand when assembling them.
- To make sure the TV is installed on the stand at a proper level, do not apply excess downward pressure to the upper left or right sides of the TV.


Step 2. Fasten two screws at position 1 and then fasten two screw at position 2.

- Stand the product up and fasten the screws. If you fasten the screws with the PDP TV placed down, it may lean to one side.

Using the remote control buttons




Installing Batteries in the Remote Control



Plug & Play

When the TV is initially powered on, basic settings proceed automatically and subsequently. If you want to reset this feature, press the **MENU** button to display menu. You can set the Plug & Play by selecting 'Setup → Plug & Play'.



On the screen, you can set as follows.

The each step may vary depending on the Antenna source.

