An Important Product Information Guide has been preloaded onto your computer. To access this guide, do the following:

- 1. Open the Start menu and then click or tap **Lenovo Companion**. If Lenovo Companion is not displayed on the Start menu, click or tap **All apps** to display all programs, and then click or tap Lenovo Companion.
- 2. Click or tap Support → User Guide.

Models without preinstalled operating systems and Virtual Desktop Infrastructure (VDI) clients:

Go to the Lenovo Support Web site to access your manuals. See "Downloading manuals" for additional information.

Downloading manuals

The latest electronic publications for your computer are available from the Lenovo Support Web site. To download the publications, go to: www.lenovo.com/UserManuals.

Service and Support information

your product, during the warranty period or throughout the life of your product. Refer to the Lenovo Limited Warranty for a full explanation of Lenovo warranty terms. See "Lenovo Limited Warranty notice" later in this document for details on accessing the full warranty. If you purchased Lenovo services, refer to the following terms and conditions for detailed information:

The following information describes the technical support that is available for

- For Lenovo Warranty Service Upgrades or Extensions, go to: http://support.lenovo.com/lwsu
- For Lenovo Accidental Damage Protection Services, go to: http://support.lenovo.com/ladps
- Online technical support is available during the lifetime of a product at: http://www.lenovo.com/support

Replacing or upgrading hardware



Safety information for replacing CRUs

Do not open your computer or attempt any repairs before reading the "Important safety information" in the Safety, Warranty, Environment, Recycling Information Guide and Important Product Information Guide that was included with your

Information Guide and Important Product Information Guide, you can obtain one online from the website at http://www.lenovo.com/UserManuals.

- 1. Turn off the power to the system and all peripherals.

kevboard

optical drive

The parts listed below are optional CRUs for experienced users:

power supply

heat sink

Wi-Fi card

Instructions for replacing these parts can be found in the *Hardware* the Hardware Maintenance Manual, go to: www.lenovo.com/UserManuals.

This part contains instructions for cleaning or replacing the following parts:

- Optical drive (Follow steps: 2 3 6)





If you no longer have this copy of the Safety, Warranty, Environment, Recycling

Pre-disassembly instructions


Before proceeding with the disassembly procedure, make sure that you do the


- 2. Unplug all power and signal cables from the computer.
- 3. Place the system on a flat, stable surface.
- CRUs for your computer include:
- mouse
- memory module
- hard disk drive power cord
- graphics card
- fans
- CMOS battery

Maintenance Manual from the Lenovo Support Web Site. To obtain a copy of


- Bottom dust screen (Follow steps: 1) Memory module (Follow steps: 2 4)
- Hard disk drive (Follow steps: **2 6**)
- Front dust screen (Follow steps: 237)










Replacing or upgrading hardware **①**







Replacing or upgrading hardware 🔾






Replacing or upgrading hardware 🔾







ideacentre Y700/900 Series Quick Start Guide




1 Unpack



2 Connect the keyboard and mouse



3 Connect the Ethernet cable




4 Choose the right voltage

Selected models are equipped with a voltage selection switch. You can find it at the rear of your computer. Models without a voltage selection switch control voltage automatically.


If the electricity supply range is 100-127 V AC, set the switch to 115 V. If the electricity supply range is 200-240 V AC, set the switch to 230 V. 2




5 Connect the display and power cables



6 Turn on the computer



Front/Top view of the computer



Rear view of the computer


6 USB 3.0 connectors

Ethernet connector

8 Audio connectors

Power connector

9 PCI-Express card area²



connector on the graphics adapter.

Connecting to the Internet

To connect to the Internet, you'll need a contract with an Internet Service Provider (ISP) and some hardware. IPSs and ISP offerings vary by country. Contact your ISP for offerings available

Your computer is designed to support a wireless (selected models only) or wired network that connects your computer to other devices.

Wired network connection

For wired networks, connect one end of an Ethernet cable (purchased separately) to the Ethernet connector on your computer, and then connect the other end to the network router or broadband modem. Consult your ISP for detailed setup instructions.

NOTE: Broadband modem and router installation procedures vary depending on the manufacturer. Follow the manufacturer's instructions.

Wireless network connection

For wireless networks, you can use the built-in Wi-Fi antenna to access your wireless home network.

To connect your computer to the wireless network:

Click or tap the network icon on the taskbar, then select the name of your router. Click or tap **Connect**, then follow the steps on the screen. Test the wireless network by opening your Web browser and accessing any Web site.

Windows help system

The Windows help system provides you with detailed information about using the Windows operating system.

To access the Windows help system, do the following:

Open the Start menu and then click or tap **Get Started** to get more details. You also can enter **Get Started** or what you're looking for in the search box on the taskbar. You'll get suggestions and answers to your questions about Windows and the best search results available from your PC and the Internet.

To perform system recovery after a serious error in Windows 10, click or tap the Start button and select **Settings** → **Update & security** → **Recovery**. Then, follow the instructions on the screen for system recovery.

ATTENTION: The Windows operating system is provided by Microsoft Corporation, Please use it in accordance with the END USER LICENSE AGREEMENT (EULA) between you and Microsoft. For any guestion related to the operating system, please contact Microsoft directly.

> The following information refers to ideacentre Y700, Y900 machine type: 90DD [Y900-34ISZ Energy Star] / 90DF [Y700-34ISH Energy Star] 90DG [Y700-34ISH Non-Energy Star]

The descriptions in this guide might be different from what you see on your computer, depending on the computer model and configuration.

Product design and specifications may be changed without notice.

Lenovo, the Lenovo logo and ideacentre are trademarks of Lenovo in the United States, other countries, or both.

Windows is a trademark of the Microsoft group of companies.

Other company, product, or service names may be trademarks or service marks of others.

Copyright Lenovo 2015. LIMITED AND RESTRICTED RIGHTS NOTICE: If data or

software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-

