

Essential SurgeArrest[™] P3U3

by Schneider Electric



Safety and General Information

- •For indoor use only. Internal components are not sealed from the environment.
- •Do not install the SurgeArrest where there is excessive heat or humidity.
- Do not use extension cords into the SurgeArrest.
- Plug the unit into a 3 wire, 120 volt, grounded outlet. Verify the safety of the building wiring prior to connecting the unit to a wall outlet.
- Never install electrical wiring during a lightning storm.
 - CAUTION: To reduce the risk of electrical shock, inspect the premises carefully. Do not use the unit if a proper equipment ground cannot be verified.
- This device will disconnect the surge protective component at the end of its useful life. It will not continue to supply power to connected equipment.

Indicators

Protection Working-The LED is normally illuminated indicating that the surge protector is on and ready to protect connected equipment. If the LED is not illuminated the surge suppression circuitry has been compromised. Contact APC by Schneider Electric using the contact information provided in this guide.

Ground OK-The LED is normally illuminated indicating that the building wiring is grounded properly. The LED extinguishes to indicate that a wiring fault has been detected. Possible wiring faults include a missing ground, a hot neutral polarity reversal, or an overloaded neutral circuit. Discontinue use and have a qualified electrician correct the building wiring.

Specifications

Nominal Operating Voltage	120 Vac, 60 Hz
Maximum Amperage	12 A
USB Charge Port	3 ports, 5V 2.1A
Joule Rating	1080 Joules
Cord Length	1.86 m (6 ft)
Dimensions Height x Width x Depth	13 cm x 12.8 cm x 3.8 cm

Limited Warranty

Schneider Electric IT (SEIT) warrants its products to be free from defects in materials and workmanship under normal use and service for the lifetime of the original purchaser. Its obligation under this warranty is limited to repairing or replacing, at its sole option, any such defective products. To obtain service under warranty you must obtain a Returned Material Authorization (RMA) number from SEIT or a SEIT Service Center with transportation charges prepaid and must be accompanied by a brief description of the problem and proof of date and place of purchase. This warranty applies only to the original purchaser.