



★ HD connection

Using an HDMI Cable







★ HD connection

Using an HDMI to DVI Cable



★ Component connection

Using a Scart Cable




LCD TV

QUICK SETUP GUIDE


The Supplied Accessories

- Remote Control & Batteries (AAA x 2)
- Owner's Instructions
- Cleaning Cloth




- Blanking Bracket

See separate guide for installing the stand.



- Stand (1EA)



- Guide Stand (1EA)




- Screws (8EA)
(LE32C530: 7EA)




BN68-02687A-00

Installing the Stand


Preset



Step 1



Step 2



Preset: Place the Guide Stand and Cover Neck onto the stand and fasten it using the screws. Applicable to models (Depending on the model)


Step 1. Attach your LCD TV to the stand.

- Two or more people should carry the TV.
- Make sure to distinguish between the front and back of the stand when assembling them.
- To make sure the TV is installed on the stand at a proper level, do not apply excess downward pressure to the upper left or right sides of the TV.


Step 2. Fasten two screws at position 1 and then fasten two screw at position 2.

- Stand the product up and fasten the screws. If you fasten the screws with the LCD TV placed down, it may lean to one side.

Using the remote control buttons



Installing Batteries in the Remote Control




NOTE

- Use the remote control within 23 feet from the TV.
- Bright light may affect the performance of the remote control. Avoid using nearby special fluorescent light or neon signs.
- The colour and shape may vary depending on the model.

Plug & Play

When the TV is initially powered on, basic settings proceed automatically and subsequently. If you want to reset this feature, press the **MENU** button to display menu. You can set the Plug & Play by selecting 'Setup → Plug & Play'.



On the screen, you can set as follows.

The each step may vary depending on the Antenna source.

Step 1

Plug & Play

Select the OSD Language.

Nederlands

English

Menu Language : Eesti

Move Enter

Step 2

Plug & Play

Select the usage mode.

Store Demo Home Use

Previous Move Enter

Step 3

Plug & Play

Select

Turkey

United Kingdom

Country Estonia

Move Enter

Step 4

Plug & Play

Antenna Source : Air

Channel Source : Digital & Analogue

Search

Previous Skip Move Enter

Step 5

Plug & Play

Auto Store in progress.

Channels : 7

Digital	2	15%
TV:2	Radio:0	Data/Other: 0
Analogue	0	

Stop

Enter

Step 6

Plug & Play

Set the Clock Mode.

Clock Mode

Auto

Manual

Move Enter

Step 7

Plug & Play

How to get the best performance from your new HDTV 1/2

Step 1. Connect the HD Box to the using HDMI or Component cables.

TV rear view

HDMI Cable

Component

Audio Out

Component In

HDMI In

Previous Skip Next

Step 8

Enjoy your TV.

OK