


サーマルプリンタ MP-B20 シリーズ クイックスタートガイド

このたびは、サーマルプリンタ MP-B20 シリーズをお買い上げいただき、まことにありがとうございます。
ご使用前に、必ず「安全上の注意」、「取扱説明書」をよくお読みの上、プリンタを安全に正しくお取り扱いください。

プリンタと付属品が入っていることを確認してください。



①プリンタ



②サンプル感熱紙



④安全上の注意



③USB ケーブル




⑤クイックスタートガイド

プリンタを充電してください。


①USB ケーブルのプラグをプリンタのUSB ポートに接続してください。

②USB ケーブルのプラグを USB 充電器、またはパソコンなどの USB ポートに接続してください。



③POWER LED がオレンジ色に点灯し、充電を開始します。

④POWER LED が消灯したら充電完了です。



取扱説明書とソフトウェアをダウンロードしてください。

①Web ページにアクセスしてください。

<http://www.sii-ps.com/mpb20/>

②取扱説明書をダウンロードしてお読みください。

③各種ソフトウェアをダウンロードしてお使いください。




Thermal Printer MP-B20 series

Quick Start Guide

Read through the Safety precautions and the User's guide carefully before using the printer, and handle it safely and properly.

Make sure that the printer and its accessories are contained.



1. Printer




2. Sample thermal paper



4. Safety precautions



3. USB cable




5. Quick start guide

Charge the power into the printer.


1. Put the plug of USB cable into USB port of the printer.

2. Put the another plug of USB cable into the USB charger or USB port of host device.



3. POWER LED lights on orange and start charging.

4. POWER LED turns off and complete charging.



Download User's guide and software.

1. Visit our web site.

<http://www.sii-ps.com/mpb20/>

2. Download the User's guide and read it.

3. Download appropriate software.

