

Let's get started



SAMSUNG Galaxy Tab A

EC



AT&T 5-Star
Eco-Rating 2.0
att.com/ecospace



WIRELESS
EMERGENCY
ALERTS
CAPABLE

AT&T Eco Rating 2.0 only applies to Galaxy Tab A. For limited factors evaluated visit att.com/EcoSpace. Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

Portions © 2018 Samsung Electronics America, Inc. Samsung and Galaxy Tab A are both trademarks of Samsung Electronics Co., Ltd. Portion of memory occupied by existing content. LTE is a trademark of ETSI. 4G LTE is not available everywhere. Wi-Fi is a trademark of the Wi-Fi Alliance. Contains Lithium ion battery - recycle or dispose of properly. Portions © 2018 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.



GH68-49641A

Printed in USA

What's in the box?

- Samsung Galaxy Tab A
- Pre-installed SIM
- Travel Adapter
- USB Cable

Useful Apps*



AT&T Messages

Send and receive text messages from your tablet or computer.



AT&T NumberSync

Make and receive calls on your tablet using your mobile phone number.



AT&T AllAccess

Stop worrying about data overages and take control with AT&T AllAccess data monitoring tools.



AT&T ProTech

With AT&T Mobile and Multi-Device Protection Packs, enjoy premium services and unlimited access to our team of trained support experts!

*Compatible device and subscription may be required. Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, go to <https://att.com/shop/apps>.

TV Mode

Quickly launch DirecTV or your favorite video app, with a double press of the Power button or a swipe from the lock screen.


To turn on TV mode and select a video app, from the home screen, swipe up and tap **Settings** > **Advanced features** > **TV Mode** and select an app.

Note: You can also turn on TV mode from the Notification panel. Simply swipe down, from the top edge of the screen and tap .

Access TV mode

To launch TV mode:

- Press the Power button twice
- From the lock screen, swipe **TV mode**



Find More Information

Manage Your Account with myAT&T

- On your phone: Swipe up for **Apps**, and then tap **AT&T folder** > **myAT&T**
- On the web: att.com/myATT



Compatible device and online account required. Data and messaging rates may apply for download and app usage.

Need More Help?

- On your phone: Swipe up for **Apps**, and then tap **AT&T folder** > **Device Help**
- On the web: att.com/DeviceHowTo



Give us a Call

- 611 from any AT&T wireless phone
- 800.331.0500 or prepaid 800.901.9878

Samsung Care


- To access user manuals, tips, videos, and more at samsung.com/us/support.
- For hardware or software support, call 800.726.7864 or for online support visit us at samsung.com/us/support/contact.
- To find a repair center near you, visit support-us.samsung.com/cyber/locator/asc_locator.jsp.



Easily Adjust Settings

Settings Menu


From the home screen, swipe up for **Apps**, and then tap **Settings** .



Quick Settings

Drag the Status bar down to display the Notification panel.






The Notification panel provides quick access to device functions such as Wi-Fi, allowing you to quickly turn them on or off.




Capture Life's Moments

Take a Picture

From the home screen, tap **Camera** .

- Tap  to take a photo.
- Tap  to take selfies.
- Swipe right to select a shooting mode.
- Swipe left to select a shooting effect.
- Tap  to start recording.
- Tap  to pause recording.
- Tap  to end recording.
- Tap **STICKERS** to add animated images when capturing a photo.

Share a Picture or Video

1. After taking the picture, tap the Image viewer at the bottom right of the screen.
2. Select the photo you want to share and then tap **Share** .
3. Select the desired option to share your photo and follow the prompts.

Need more help?
Go to **Apps** > **AT&T folder** > **Device Help**



Watch.
Stream.
Enjoy.

- > Watch your favorite live and recorded shows anywhere with the DIRECTV App*
- > Download your home DVR to your devices and watch anywhere*
- > Enjoy thousands of movies and shows to stream anywhere

For Details:



Call 877.259.9450




Visit your local AT&T store




Go to att.com/takedirectv

AT&T Video Call


One-touch video calling built into your device, no app to download, no separate account to configure, and no password to enter.

- Simply tap  on the dialer or in your contacts.
- Switch between HD voice and video at any time during a call.



Optimize the battery

From the home screen, swipe up for **Apps**, and then tap **Settings**  > **Device maintenance** .



*Req's Internet-connected Genie HR44+ & elig. svc. Channels/content vary by pkg & location and must be streamed through the DIRECTV App.

Restr's apply. Contact DIRECTV for details. ©2018 AT&T Intellectual Property. All Rights Reserved. AT&T, Globe logo, DIRECTV and all other DIRECTV marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T affiliated companies.