SAMSUNG Galaxy Note10 | 10+

Quick Reference Guide



Samsung Care



Samsung Premium Care

Pick the time and place and a team member will meet you to set up, troubleshoot, repair, or replace your product.

Enroll at samsung.com/us/support/ premium-care

Get to know your product:

- Access solutions, videos, tips, and more at samsung.com/us/support
- Find support that's convenient on your device with the Samsung Members app. Download and install it from Google Play[™] store.

Contact us:

- Ask guestions and share solutions with other Samsung customers at us.community.samsung.com
- Get support at samsung.com/us/ support/contact or call us at 1.800.SAMSUNG
- Find a service location near you at samsung.com/us/support/service/ locations

Features

Camera

Capture and share pro-grade video.

- Live focus video
- Audio zoom
- Advanced super steady

S Pen

Enhanced S Pen functionality.

- Precision control for gaming
- Use gestures for remote shortcuts
- Transcribe, edit and export with Samsung Notes
- Customize videos and pictures with on-device editing

DeX integration

Share your computer's keyboard, mouse, and screen with your phone.

Mobile continuity

Wirelessly sync your phone and PC.


About your phone



Images shown are of the Galaxy Note10+ and are for reference only

Set up your phone

Your SIM card may be pre-installed.



SIM/microSD™ tray

Use the tool to open the SIM/microSD card tray.

Place the SIM card and if applicable the optional microSD card into the trays with the gold contacts facing

Charge your device

Before turning on your phone, charge it fully.

Backup and restore

Get help transferring contacts, photos and other content from your old phone at samsung.com/smartswitch

Search

From the Home screen swipe up and search for apps, settings, contacts, and more.



From the Home screen, swipe up, and then tap **Settings** o to customize, connect and personalize your phone:




Connect to a Wi-Fi[™] network, Bluetooth® device and other connection options.

Sounds and vibration Set device volume and sounds.



Customize the Home screen. navigation gestures, and display brightness.



fun and unique wallpapers and themes.

Lock screen

Select a screen lock type and set security options.


Biometrics and security Set facial or fingerprint security

Digital wellbeing Configure usage limits on your

device.

Customize your phone Learn more


Use **Tips and help** to access the user manual and other information on how to use your device, including:







Sending and receiving texts







Configuring accessibility settings

To open, from **Settings** 🔯 tap Tips and help .



Get creative with the S Pen

Unleash the S Pen

Push the S Pen inward and, then pull it out.

When you remove the S Pen, Air command launches.

open an app remotely.

gesture can capture a photo, navigate, scroll and more.

the S Pen and tap Settings (2) Air actions.

Write and draw directly into emails or the calendar, as well as Word, Excel®. PowerPoint®, and PDF documents

Air Command

Air Command gives you access to signature S Pen features.

Create note: Create customized notes.

View all notes: View all notes created.

Smart select: Outline and crop anything on the screen and freely edit or share.

Screen write: Capture a screen image and write or draw on it.

Live message: Create live messages and

Translate: Hover the S Pen over a word to view its definition and pronunciation.

PENUP: Use the S Pen to draw, color, edit, and share live drawings.

Add shortcuts: Select an app or function to add to the Air Command menu.



Camera

Tap to select settings or options



AR Emoji

Turn your selfie into an emoji

Ultra wide (forest)

Get more of the scene, by tapping the leaf, tree or forest icon

Scene optimizer

Recognize subjects in photos and automatically enhance the quality

Switch between the back and front cameras

Wireless PowerShare

Wirelessly charge compatible devices right from your phone.

- 1. Drag the Status bar down to display the Notification panel.
- 2. Touch and drag to access all Quick Settings options.

Wireless PowerShare works with most Oi-Certified devices. Requires minimum 30% battery to share. Speed and power efficiency of

charge varies by device. May not work with some accessories, covers, or other manufacturer's devices. If you have trouble connecting or

- 3. Tap Wireless PowerShare (1)
- 4. With the phone face down, place the device on the back of the phone to charge.

My Verizon Mobile app


Manage your account, track your usage, edit account information, pay your bill and more.

Manage your account



International travel

outside the US. visit:



Call 800.922.0204

Twitter @VZWSupport

For features and rates when

verizonwireless.com/International

Additional information

Your wireless device and third-party services

this wireless device, but many services and features offered through this device are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use and privacy policies apply. Please review carefully all applicable terms, conditions and policies prior to using this wireless device and any associated application. product or service.

Verizon Wireless is the mobile carrier associated with

Hearing aid compatibility information

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer technologies that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant to determine if you hear any interfering noise. Ask your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, ask your service provider or phone retailer.

and Galaxy Note are both trademarks of Samsung Electronics Co., Ltd. Other company and product names mentioned herein may be trademarks of their respective owners Screen images simulated. Appearance of phone may vary

charging is slow, remove any cover from each device. May affect call reception or data services, depending on your network environment. ©2019 Samsung Electronics America, Inc. Samsung


S Pen button

Press and hold the S Pen button to

A single press, double press, or a

To enable S Pen Air actions, remove

Bixby Vision



Tools Panel

Camera modes

View photos

Take photo

Gallery

Capture

Swipe left or right to select a mode

Create note +

View all notes

Smart select

Screen write

Live message

Translate A

Standard (leaf), Wide (tree), and

Toggle camera