

SAMSUNG
Galaxy Watch Active2

**Quick
Start
Guide**



Back

Touch bezel

Home/Power

Changeable watch band

Charge




Use only Samsung-approved charging devices and accessories. Using other accessories may void your warranty and may cause damage.

Navigate

Swipe the screen to:

- View notifications and widgets
- View the Quick Panel
- Navigate screens
- View additional apps




Tap to open Recent app

Drag the touch bezel around the edge of the display to scroll

From the watch screen, press to view apps or return to the watch screen

©2019 Samsung Electronics America, Inc. Samsung and Samsung Galaxy Watch are trademarks of Samsung Electronics Co., Ltd. Google Play Store is a trademark of Google LLC. Other company names, product names and marks are the property of their respective owners. Screen images simulated. Appearance of devices may vary.



Connect

Visit Galaxy Apps, Google Play Store or the App Store to install the Galaxy Wearable app to connect your watch and smartphone.

Open the app and follow the prompts to pair your watch to your smartphone.

Activate

The Galaxy Watch Active2 (R825 and R835) are 4G LTE-enabled. Get texts, alerts, make and receive calls, even when you leave your phone behind.

Consult your service provider for more information about activation.

For more information about the Galaxy Watch2, visit samsung.com/us/support/mobile/wearables

Explore

From the top edge of any screen, swipe down to view the Quick Panel

Silence notifications while you sleep in Goodnight mode

Turn off vibration, incoming calls, and alerts in Do Not Disturb mode



Adjust the screen brightness


Set ringtone volume, vibration or mute volume

Open settings

Keep your watch face on in Always On mode

If connected to a network and in Stand-alone mode, the signal strength and carrier name will display.





Customize

Touch and hold the watch face and select a preloaded watch face or download a new one.

Tap **CUSTOMIZE** to create a custom watch face or download additional watch faces by swiping to the last screen and tapping Galaxy Store.



Calls

-  Tap to make a call
-  Swipe to answer
-  Swipe to reject the call and send the call to voicemail

Swipe up to open **Decline messages** to send the call to voicemail and respond with a preloaded or customized message

4G LTE standalone connectivity is only available on Samsung Galaxy Watch LTE versions. Standalone voice calling on LTE version requires initial pairing with eligible smartphone and separate qualifying wireless plan. Your carrier may not support standalone voice calling, or support may be available in certain areas. Please check with your carrier for more information. Standalone functionality limited if paired phone is not powered on or connected to a wireless network. If connected to a network and in Stand-alone mode, the signal strength will display.

Find your device


 If you misplace your Galaxy Watch or the connected smartphone, you can use the Galaxy Wearable app to find it.

Find My Watch

From your smartphone, tap **Galaxy Wearable**  > **Find My Watch** and tap **Start** 

Find My Phone

From the watch, tap **Find My Phone**  > **Start** 



Useful apps

-  **Galaxy Store** Download apps optimized for your watch
-  **SmartThings** Control your smart devices and appliances from your watch
-  **Samsung Health** Help keep your body fit and healthy
-  **Bixby** Use your voice to check the weather, set an alarm and more

Visit samsung.com/us/support to learn more



Messages

-  Create, view and reply to messages. Swipe up to reply with a preloaded quick response.
-  Tap **Voice input** and speak your message
-  Tap **Emoji** to select and send an emoji
-  Tap to open **Handwriting** or **Keyboard** mode

