

SAMSUNG

Galaxy S9 | S9+

Quick Reference Guide



Unlocked¹

Table of Contents

2	Samsung Care
3	Know your device
5	Device setup
9	Home screen
12	Volume and ringtones
13	Hello Bixby
14	Useful apps
15	Calls
16	Voicemail
17	Contacts
18	Messages
20	Camera
21	Internet
22	Connections

Samsung Care

How can we help you?

Get to know your product

- To access user manuals, tips and more visit samsung.com/us/support.

Ask the community

- To ask questions and get solutions from other Samsung customers visit us.community.samsung.com.

Contact us for support

- For hardware or software support call us at 800.SAMSUNG or visit samsung.com/us/support/contact.
- To find a service location near you visit support-us.samsung.com/cyber/locator/asc_locator.jsp.

Know your device



Camera and
Fingerprint
scanner

Dual camera and
Fingerprint
scanner



SAMSUNG

SAMSUNG

Galaxy S9

Galaxy S9+

USB/Charger port

Device setup

Insert a SIM and optional microSD card

If you need to replace your SIM card or insert a microSD™ card, follow these steps.

1. Hold the device securely.
2. Use the SIM removal tool that came with your device to open the SIM/microSD card tray.
 - With the carrier logo facing up, place the SIM card into the tray.
 - With the gold contacts facing down, place the optional microSD card into the tray. (microSD card sold separately.)



3. Gently push the tray into the slot.

Charge the device

Before turning on your phone, charge it fully.

Your phone comes with an Adaptive Fast Charging charger and a USB cable. Use fast charge technology to quickly charge your phone.



Note: Use only charging devices and batteries approved by Samsung. Samsung accessories are designed for your device to maximize battery life. Using other accessories may invalidate your warranty and may cause damage.

Configure the device

When you first turn on your device, you need to set up a few things.

1. Select a language and tap **START** or tap **ACCESSIBILITY**.
2. Follow the prompts to complete the setup process.

Note: Select Smart Switch during setup, or open it later to easily transfer your photos, videos, music, apps and more.

From the Home screen swipe up for Apps and then tap  **Settings** >  **Cloud and accounts** > **Smart Switch** and follow the prompts.

Lock and unlock the screen

Use your device's screen lock features to secure your device.

- To Lock, press the **Power/Lock** key.
- To Unlock, press the **Power/Lock** key then swipe your finger across the screen.

Lock features

The Screen lock menu allows you to choose from a variety of locking features.

1. From the Home screen, swipe up for **Apps** and tap  **Settings** >  **Lock screen and security** > **Screen lock type**.
2. Tap a screen lock type and follow the prompts to begin registration:
 - Swipe
 - Pattern
 - PIN
 - Password
 - None
 - Intelligent Scan
 - Face
 - Iris
 - Fingerprints

Note: The Iris Scanner is not intended for use as a medical device; biometric data collected and stored locally by the Iris Scanner is not intended for any diagnostic, therapeutic, or preventative medical purposes. Please follow all instructions for use of this feature. For more information, refer to the online support content or visit samsung.com/us/irisscanner.

Home screen




- Swipe up or down to display the Apps panel.
- Swipe the Home screen left for additional panels.
- Swipe the Edge handle to access Edge panels.
- Swipe right to open Bixby.

Edge screen


The Edge screen provides a shortcut to call, text or email favorite contacts and much more.

1. From the Home screen, swipe the Edge handle to display the Edge panels.
2. Swipe to view Edge screens.
3. Tap  to customize, download, and add new Edge panels.



Customize your device


- Touch and hold a blank space on a home screens to access options.



- **Wallpapers:** Change the look of the Home and Lock screens. Display a favorite picture or choose from preloaded wallpapers. You can also customize the **Always on Display** screen.
- **Themes:** Change the look for system screens and icons.
- **Widgets:** Drag a widget to an empty space on the Home screen for quick access to applications.
- **Home screen settings:** Customize the look of the Home screen.

Volume and ringtones


- From the Home screen, swipe up for **Apps** and then tap  **Settings** >  **Sounds and vibration**.
- Tap **Volume** to increase or decrease device volume settings.
- Tap **Ringtone** to select a ringtone.



Hello Bixby

To launch **Hello Bixby** , press the **Bixby** button.

Hello Bixby allows you to quickly set reminders, create voice dictation, search and access content on your phone and on the Internet.



Note: For more information about Bixby, visit samsung.com/us/support/owners/app/Bixby.

Useful apps



Play Store: Download new apps from the Google Play store.

Visit play.google.com/store/apps to learn more.



Galaxy Apps: Download Samsung apps that are optimized for use with Galaxy devices.

Visit samsung.com/us/support/owners/app/galaxy-apps to learn more.



Smart Things: Monitor and control your Samsung devices and appliances from your phone.

Visit samsung.com/us/support/smart-home/smartthings to learn more.



Samsung Health: Provides core features to keep your body fit and healthy.

Visit samsung.com/us/support/owners/app/samsung-health to learn more.




Smart Switch: Easily transfer photos, videos, music, apps and more from your old phone to your new galaxy.

Visit samsung.com/us/support/owners/app/smart-switch to learn more.

Calls

1. To make a call, tap  **Phone**.



2. Tap  to make a phone call or tap  to make a video call.

Note: Video calling may not be available, consult your service provider for details.

3. When receiving a call or ending a call touch and slide the following:
 - To answer a call, touch and slide .
 - To reject and route a call to your voicemail, touch and slide .
 - To end a call, touch and slide .

Voicemail

Setup voicemail

1. From the Home screen, tap  **Phone**.
2. Touch and hold .
3. Follow the prompts to set up your mail box.

Access voicemail

1. From the Home screen, tap  **Phone**.
2. Touch and hold .

Contacts

Create a contact

1. From the Home screen, swipe up for **Apps** and tap  **Contacts**.
2. Tap  to add a new contacts.
3. Enter the desired information and tap **SAVE** to store the new entry.

Edit a contact

1. From the Home screen, swipe up for **Apps** and tap  **Contacts**.
2. Tap a contact name from the list and tap **Details** > **EDIT**.
3. Edit the desired information and tap **SAVE**.

Delete a contact

1. From the Home screen, swipe up for **Apps** and tap  **Contacts**.
2. Touch and hold a contact name from the list and tap **DELETE**.

Messages

Create and send a message

1. From the Home screen, tap  **Messages** >  **New message** .
2. Enter a phone number or contact name in the **Recipient** field.

Note: If entering a phone number, press  to add the phone number as a recipient.

3. Tap **START** to compose a message.
4. Tap **Enter message** and enter your text.
 - Tap  to add an attachment.
 - Touch and hold  to create an audio message.
 - Tap  to add a sticker or a GIF.
5. Tap  to send the message.

Gmail

Use Gmail™ to send and receive email.

Before you can access Gmail, you must first sign in or create a new Google account.

- From the Home screen, swipe up for **Apps** and then tap  **Gmail**.
 - Tap **Add an email address** to create a new account or to log into an existing Gmail account.
 - Tap **TAKE ME TO GMAIL** if you have an account set up on your device.

Setup Email accounts

Configure Email for most accounts in just a few steps.

1. From the Home screen, swipe up for **Apps** and then tap  **Email**.
2. Enter your email address and password into the appropriate fields and tap **SIGN IN**.
3. Follow the prompts to complete setup.

Camera

Take pictures and record videos with the Camera app.

Capture a photo

- From the Home screen, tap  **Camera**.
 - Tap  to take a photo.
 - Drag  left or right to zoom in or out.
 - Tap  or swipe up to take selfies.
 - Swipe right or left to select a shooting mode.

Note: When using the camera in landscape mode, drag  up or down to zoom in or out.

Record a video

- From the Home screen, tap  **Camera**.
 - Tap  to begin recording.
 - Tap  to capture a picture while recording.
 - Tap  to pause a recording.
 - Tap  to finish recording a video.

Internet

Access the Internet with a fully-featured web browser. You can view the latest news, check the weather, and follow your stocks.


- From the Home screen, tap  **Internet**.

Enter a URL

- From any webpage, tap the address field, enter the web address, and then tap **Go** on the keyboard.

Add a new tab

1. From your browser window, tap **Tabs** > **NEW TAB**. A new browser window displays.
2. Tap **Tabs** to see the open windows, and tap a window to view it.



Connections

Connect to Bluetooth

1. From the Home screen, swipe up for **Apps** and then tap  **Settings** >  **Connections** > **Bluetooth**.
2. Tap **ON/OFF** to turn on Bluetooth®.
3. Tap a device from the list to initiate pairing.
4. Enter the passkey/PIN code, if required, and tap **OK**. When connected  displays in the status bar.

Connect to Wi-Fi

1. From the Home screen, swipe up for **Apps** and then tap  **Settings** >  **Connections** > **Wi-Fi**.
2. Tap **ON/OFF** to turn on Wi-Fi®.
3. Tap a network and enter the password if prompted. When connected  displays in the status bar.