

## 1

**English**  
Mouse runs on 1 or 2 batteries.  
Place single battery in either slot.

**简体中文**  
鼠标使用一节或两节电池均可工作。  
将电池放入任一插槽即可。

## 2

## 3

**English**  
**Mac OS® X:** If the Keyboard Setup Assistant window appears, close the window.

**简体中文**  
**Mac OS® X:** 如果出现键盘安装助手窗口, 请关闭该窗口。

## 4


[www.logitech.com/support/anywheremx](http://www.logitech.com/support/anywheremx)

**English**  
For additional mouse features and configuration, download the Logitech® SetPoint™ software for Windows® or the Logitech® Control Center for Mac OS.

**简体中文**  
有关更多鼠标功能和配置, 请下载用于 Windows® 平台的 Logitech® SetPoint™ 软件或用于 Mac OS 的 Logitech® Control Center。

<p><b>M/N:C-U0007</b> Rating: 5V = 100mA Approval No.: ETA-418/2010/WRLO CMIIT ID: 2010DJ0355</p> <p>14418/POSTEL/2010 2100</p> <p>CCAI10LP0020T1</p> <p>Complies with IDA Standards DB101104</p> <p>Z855 N231</p>	<p><b>M/N:C-U0008</b> Rating: 5V = 100mA Approval No.: ETA-1115/2011/WRLO CMIIT ID: 2011DJ1853</p> <p>19088/SDPP I/2011 2100</p> <p>CCAI11LP0640T0</p> <p>Complies with IDA Standards DB101104</p> <p>Z855 N231</p>
--	---

[www.logitech.com/support/anywheremx](http://www.logitech.com/support/anywheremx)



## English

### Mouse features

1. Left and right buttons
2. Scroll wheel
  - Press wheel down to switch between hyper-fast and click-to-click scrolling.
  - Press wheel left to scroll left. Press wheel right to scroll right.<sup>1</sup>
3. Middle button (Function varies by application.)
4. Battery indicator (Red indicates low battery power.)
5. Battery door release
6. On/off switch
7. Back and forward buttons<sup>2</sup>

<sup>1</sup> For this feature in Windows, download and install the Logitech SetPoint software.  
<sup>2</sup> For this feature in Mac OS, download and install the Logitech Control Center.

## 简体中文

### 鼠标功能

1. 左右鼠标按键
2. 滚轮
  - 按下滚轮可在超快滚动和逐击式滚动之间切换。
  - 向左按滚轮以向左滚动。向右按滚轮以向右滚动。<sup>1</sup>
3. 中键 (功能依应用程序而异。)
4. 电池指示灯 (红灯表示电池电量低。)
5. 电池盖释放
6. 开启/关闭开关
7. 后退和前进按钮<sup>2</sup>

<sup>1</sup> 要在 Windows 下使用此功能，请下载并安装罗技 SetPoint 软件。  
<sup>2</sup> 要在 Mac OS 下使用此功能，请下载并安装 Logitech Control Center。



## English

Logitech® Unifying technology connects up to six compatible Logitech mice and keyboards to the same receiver, using only one USB port for multiple devices. To learn more, visit [www.logitech.com/unifying](http://www.logitech.com/unifying).

## 简体中文

罗技® Unifying 技术可将多达六个兼容的罗技鼠标和键盘连接至相同接收器，只需一个 USB 端口就可连接多个设备。如欲了解更多信息，请访问 [www.logitech.com/unifying](http://www.logitech.com/unifying)。

## English

### Troubleshooting

#### Mouse not working?

- Is the mouse turned on?
- Check the receiver connection. Try a different USB port on the computer. Connect directly to the computer and do not use a USB hub.
- Check battery orientation (positive poles point down) or replace batteries.
- Remove metallic objects near mouse.

#### Additional help

For online help, go to [www.logitech.com/support/anywheremx](http://www.logitech.com/support/anywheremx)

## 简体中文

### 疑难解答

#### 鼠标不工作?

- 鼠标是否已开启?
- 检查接收器的连接。尝试使用计算机的其他 USB 端口。直接连接到计算机而不要使用 USB 集线器。
- 检查电池方向 (正极向下) 或更换电池。
- 移除鼠标附近的金属物体。

#### 更多帮助

请访问 [www.logitech.com/support/anywheremx](http://www.logitech.com/support/anywheremx) 获取联机帮助。

Table of Toxic and Hazardous Substances/Elements and their Content

产品中有毒有害物质或元素的名称及含量  
根据中国《电子信息产品污染控制管理办法》

Control Device 鼠标						
有毒有害物质或元素						
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
电缆 Cable	X	○	○	○	○	○
电路板组件 PWAs	X	○	○	○	○	○
塑料外壳 Plastic enclosure	○	○	○	○	○	○
塑料部件 Plastic parts	○	○	○	○	○	○
金属部件 Metal parts	X	○	○	○	○	○

○ = 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。

X = 表示该有毒有害物质至少在该部件的某一均质的含量超出 SJ/T11363-2006 标准规定的限量要求。

表中标有“X”的所有部件都符合欧盟 RoHS 法规

“欧洲议会和欧盟理事会 2003 年 1 月 27 日关于电子电器设备中限制使用某些有害物质的 2002/95/EC 号指令”

注：环保使用期限的参考标取决于产品正常工作的温度和湿度等条件

Table of Toxic and Hazardous Substances/Elements and their Content

产品中有毒有害物质或元素的名称及含量  
根据中国《电子信息产品污染控制管理办法》

Wireless Receiver 接收器						
有毒有害物质或元素						
部件名称	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
电缆 Cable	X	○	○	○	○	○
电路板组件 PWAs	X	○	○	○	○	○
塑料外壳 Plastic enclosure	○	○	○	○	○	○
塑料部件 Plastic parts	○	○	○	○	○	○
金属部件 Metal parts	X	○	○	○	○	○

○ = 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。

X = 表示该有毒有害物质至少在该部件的某一均质的含量超出 SJ/T11363-2006 标准规定的限量要求。

表中标有“X”的所有部件都符合欧盟 RoHS 法规

“欧洲议会和欧盟理事会 2003 年 1 月 27 日关于电子电器设备中限制使用某些有害物质的 2002/95/EC 号指令”

注：环保使用期限的参考标取决于产品正常工作的温度和湿度等条件