

# alcatel IDOL4

## QUICK START GUIDE

LED indicator/  
Front flashlight

Power key



Front camera


Volume up/down

Boom Key

6055K

6055P


6055Y




⓪ Charge the battery

Single-SIM

- ⓪ Insert or remove the SIM card
- ⓪ Install or remove the microSD card



Dual-SIM



User guide and FAQ are available online  
[www.alcatel-mobile.com](http://www.alcatel-mobile.com)

SAVE  
PAPER  
SAVE  
TREES

PLEASE CONSIDER THE  
ENVIRONMENT BEFORE PRINTING