SAMSUNG Galaxy Tab 57 5G



Let's get started

AT&T 5-Star Eco-Rating 2.0 att.com/ecospace



Contains Li-ion battery - recycle or dispose of properly. AT&T Eco Rating 2.0 only applies to smartphone. For limited factors evaluated visit att.com/EcoSpace. Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA - The Wireless Association. Requires a compatible plan for 5G and 5G+ connections. Limited AT&T 5G and 5G+ availability. May not be available in your area. For coverage details visit att.com/5Gforyou.

Samsung Electronics America, Inc. Samsung, Galaxy Tab S are all trademarks of Samsung Electronics Co., Ltd. Bluetooth is a registered trademark of Bluetooth SIG Inc. Android is a trademark of Google LLC. © 2020 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property and/or AT&T.

What's in the box?

- · Galaxy Tab S7 5G
- S Pen
- SIM card
- Travel Adapter
- USB Cable
- Inbox Guide
- Terms and Conditions

TV Mode

Quickly launch your favorite video app, with TV mode

Access TV mode

- To launch TV mode:
- Press the Power button twice
- From the lock screen, swipe TV mode 🔼

To turn on TV mode and select a video app, from the home screen, swipe up and tap Settings (> Advanced features (> TV Mode and select an app.

Note: You can also turn on TV mode from the Notification panel. Simply swipe down, from the top edge of the screen and tap

Useful Apps*



AT&T Messages

Send and receive text messages from your tablet or computer.



AT&T NumberSync

Make and receive calls on your tablet using your mobile phone number.



AT&T AllAccess

Stop worrying about data overages and take control with AT&T AllAccess data monitoring tools.



AT&T ProTech

With AT&T Mobile and Multi-Device Protection Packs, enjoy premium services and unlimited access to our team of trained support experts!

*Compatible device and subscription may be required. Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, visit att.com/shop/apps.

Find More Information

Manage Your Account with myAT&T • On your tablet: Swipe up for Apps, then

tap myAT&T



Compatible device and online account required. Data and messaging rates may apply for download and app usage.

Need More Help?

- On your tablet: Swipe up for Apps. then tap AT&T folder > Device Help
- On the web: att.com/DeviceHowTo

Give us a Call

- 611 from any AT&T wireless phone
- 800.331.0500 or prepaid 800.901.9878


Samsung Care

- To access user manuals, tips, videos, more visit samsung.com/us/support
- For hardware or software support, call 800.726.7864 or online support at samsung.com/us/support/contact
- To find a repair center near you, visit samsung.com/us/support/service/ locations/





Your tablet







- > Watch your favorite live and on demand shows anywhere with the DIRECTV App*
- Download your DVR recordings to your devices at home and watch offline anywhere*
- > Enjoy thousands of movies and shows to stream anywhere

For Details:



Go to att.com/takedirectv

*Req's Internet-connected Genie HR44+ & elig. svc. Channels/content vary by pkg & location and must be streamed through the DIRECTV App. Restr's apply. Contact DIRECTV for details. ©2020 AT&T Intellectual Property, All Rights Reserved. AT&T, Globe logo, DIRECTV and all other DIRECTV marks contained herein are trademarks of AT&T intellectual Property and/or AT&T affiliated companies.

NumberSync

Sync your AT&T smartphone number with a tablet to make and receive voice and video calls using your smartphone number.

- One number: Calls and texts* from your tablet will display as your smartphone
- Simultaneous ring: Calls to your mobile phone will ring all synced devices at the same time

Setup NumberSync

- 1. From the Home screen, tap **Phone** (1)
- 2. Tap **OK** and follow the prompts.



*Data rates may apply. Texting requires use of the AT&T Messages app.

Easily Adjust Settings

Settings Menu

From the home screen, swipe up for **Apps**, then tap **Settings** .



Quick Settings

Drag the Status bar down to display the Notification panel.

The Notification panel provides quick access to device functions such as Wi-Fi, allowing you to quickly turn on or off.



Optimize the battery

From the home screen, swipe up for **Apps**, then tap **Settings** (> **Device care** ().

