Samsung Care

About your device

SAMSUNG Galaxy Tab S6

Quick Reference

Guide

How can we help you?

Get to know your product:

 Access user manuals, tips and more at samsung.com/us/support

Ask the community:

 Ask questions and get solutions from Samsung customers, at us.community.samsung.com

Contact us for support:

- For hardware or software support, visit samsung.com/us/support/contact or call us at 1.800.SAMSUNG.

• Find a service location near you, at samsung.com/us/support/service/ locations



Set up your device

Remove SIM/microSD tray Use the tool to open the SIM/microSD™ card tray.

Insert SIM/microSD card Slide the SIM card and the optional microSD card (microSD card sold separately) into the tray with the gold contacts facing down.

Charger your device Before turning on your device, charge it. 100%

Activating your tablet

Activate your tablet to use the Internet on Verizon's 4G LTE network.

Turn on your tablet. Then follow the onscreen instructions in the Setup Wizard.

Subject to specific terms of use. For coverage details, visit verizonwireless.com/CoverageLocator.

Customize your device Customize, connect or turn on options to

personalize your device:



Wallpaper Change the look of the Home and Lock screens.



Accounts and backup Tap Users to add additional users for the device.



Biometrics and security Set biometric security options.



Connections Connect to Wi-Fi network. Bluetooth device and other connection options.



Lock screen Select a screen lock type and set security options.




Display Customize the Home screen and display brightness.



Sounds and vibration Set device

volume and sounds.



Printed in Vietnam



Search From the home screen swipe up, and

search for anything on the device. For example enter an app or settings name.



Bixby Set reminders, see upcoming appointments, photos, tomorrow's weather and more. From

the home screen, swipe right to launch Bixby and follow the prompts to complete setup.



Keyboard sold separately

Visit samsung.com/us/support/owners/app/Bixby for more information.

S Pen

The S Pen™ enables fast, and precise input while providing a natural writing experience. Write and draw directly into emails or the calendar, as well as Word, Excel, PowerPoint, and PDF documents.

S Pen button

Press and hold the S Pen button to open an app remotely.

A single or double press can open an app, capture a photo, navigate, scroll and more.

Remove the S Pen, and tap Settings (3) Air actions to set the S Pen remote features.

Air Command To launch Air Command, press the S Pen

button and then tap

- Create note Create short notes.
- View all notes Displays notes.
- Smart select Instantly outline and crop anything on the screen and freely edit or share with others.
- Screen write Capture a screen image and write or draw on it.
- Live messages Create a short animated message.
- AR Doodle Draw and write on
- Translate Hover the S Pen over
- a word to view its definition and pronunciation.
- Penup Draw, color, edit, and share
- function to open.


Need help?

Learn more

Use the Help feature to access the user manual and other information on how to use your device, including:




Downloading apps











live drawings. To open, from the Home screen, swipe up Add shortcuts Select an app or and tap Settings (> Help ?

My Verizon Mobile app Manage your account, track your

Manage your account

usage, edit account information, pay vour bill and more.



(nternational travel For features and rates when outside

the US, visit: verizonwireless.com/International.

Customer service

Call 800.922.0204

Twitter @VZWSupport

©2019 Samsung Electronics America, Inc. Samsung and Galaxy Tab are both trademarks of Samsung Electronics Co.,

Ltd. Google Play, Gmail, Chrome, YouTube and Google are trademarks of Google LLC.

LTE is a trademark of ETSI. Device and screen images simulated. Appearance of device may vary.