

Let's get started



SAMSUNG Galaxy A6




AT&T Eco Rating 2.0 only applies to Galaxy A6. For limited factors evaluated visit att.com/EcoSpace. Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

Portions © 2018 Samsung Electronics America, Inc. Samsung and Galaxy A6 are both trademarks of Samsung Electronics Co., Ltd. Portion of memory occupied by existing content. LTE is a trademark of ETSI. 4G LTE is not available everywhere. Wi-Fi is a trademark of the Wi-Fi Alliance. Contains Lithium ion battery - recycle or dispose of properly. Portions © 2018 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.



Optimize the battery

From the home screen, swipe up for **Apps**, and then tap **Settings** > **Device maintenance** .



What else is in the box?

- Samsung Galaxy A6
- Pre-installed SIM
- Travel Adapter
- USB Cable

Useful Apps*



AT&T Call ProtectSM

More control over nuisance calls with AT&T Call Protect.



AT&T DriveMode

Help avoid distractions while driving. Silence incoming text alerts.



AT&T Device Help

Simplify the management of your device and identify potential issues.



AT&T Smart Wi-Fi

Finds and auto-connects to available hotspots.



Setup and Transfer

Restore content from your old device, set up your email, social networking, and more.



AT&T Mobile Security

Protect your phone from malware, viruses, and system threats.

*Compatible device and subscription may be required. Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, go to <https://att.com/shop/apps>.

Find More Information

Manage Your Account with myAT&T

- On your phone: Swipe up for **Apps**, and then tap **AT&T folder** > **myAT&T**
- On the web: att.com/myATT



Compatible device and online account required. Data and messaging rates may apply for download and app usage.

Need More Help?

- On your phone: Swipe up for **Apps**, and then tap **AT&T folder** > **Device Help**
- On the web: att.com/DeviceHowTo



Give us a Call

- 611 from any AT&T wireless phone
- 800.331.0500 or prepaid 800.901.9878

Samsung Care

- To access user manuals, tips, videos, and more at samsung.com/us/support.
- For hardware or software support, call 800.726.7864 or for online support visit us at samsung.com/us/support/contact.
- To find a repair center near you, visit support-us.samsung.com/cyber/locator/asc_locator.jsp.






Need more help?
Go to **Apps** > **AT&T** folder > **Device Help**

Easily Adjust Settings

Settings Menu


From the home screen, swipe up for **Apps**, and then tap **Settings**.



Quick Settings

Drag the Status bar down to display the Notification panel.

The Notification panel provides quick access to device functions such as Wi-Fi, allowing you to quickly turn them on or off.




Fun Camera Features

Take a Picture

From the home screen, tap **Camera**.

- Tap **Camera** to take a photo.
- Tap **Selfie** to take selfies.
- Swipe right to select a shooting mode.
- Swipe left to select a shooting effect.
- Tap **Record** to start recording.
- Tap **Take picture while recording** to capture a picture while recording.
- Tap **Pause** to pause recording.
- Tap **Stop** to end recording.
- Tap **STICKERS** to add animated images when capturing a photo.



Bixby Vision

From the camera viewfinder, tap **BIXBY VISION**. With Bixby Vision you can do the following and much more.


- Translate foreign languages
- Identify landmarks and businesses
- Shop
- Track calories



AT&T Video Call

One-touch video calling built into your smartphone, no app to download, no separate account to configure, and no password to enter.

- Simply tap **Video Call** on the dialer or in your contacts.
- Switch between HD voice and video at any time during a call.





For more info visit att.com/videocall

For more information about Bixby vision visit samsung.com/global/galaxy/apps/bixby/vision/

How to replace the SIM

Install a SIM/microSD

1. With the screen facing up, insert the tool that came with your phone into the hole on the SIM/microSD™ card tray to open it.
2. Insert the SIM with gold-colored contacts facing down.
3. Insert the optional microSD™ card (not included) with the gold-colored contacts facing down.



Turn on your new phone

- Press and hold the **Power/Lock** key until the device turns on.