



K600 TV

TV Keyboard with Integrated Touchpad and D-pad



MAKE YOUR TV WORK SMARTER.

The K600 TV is the smarter way to control your Smart TV. Sit back and navigate menus with the D-pad and control the cursor with the precision touchpad from up to 15 meters (49 feet) away. Familiar typing allows you to quickly search for content, enter your complicated mix-cased password and browse the internet with ease. The dedicated media and navigation keys allow you to play and pause movies, control the volume and immediately launch Home and Search screens. Connect the K600 TV to your Smart TV, PC and mobile devices – and switch between them with the touch of a button.

FEATURES

- Integrated precision touchpad for hassle-free web browsing
- D-Pad for easy navigation in on-screen menus
- Fast and familiar typing
- 15-meter¹ wireless range with a reliable connection
- Media and navigation keys
- Compatible with select Smart TVs²

WHAT'S IN THE BOX

- Wireless Keyboard with integrated touchpad and D-pad
- Unifying™ receiver
- 2 AAA batteries (pre-installed)
- User documentation

SYSTEM REQUIREMENTS

- Smart TVs: Compatible with Samsung SUHD /UHD (Tizen –2016 models and above), LG OLED /SUHD /UHD (WebOS –2016 models and above), Sony Bravia UHD (Android TV –2016 models and above)
- Other Devices: Compatible with your Windows® or Mac PC connected to the TV plus iOS® and Android™ devices
- Unifying receiver — requires device USB port, Windows 7 or later, macOS 10.11 or later, Android 5.0 or later, or Chrome OS™
- Bluetooth® wireless — requires Windows 8 or later, macOS 10.12 or later, iOS 9 or later, Android 5.0 or later, or Chrome OS

1. Wireless range may vary with environmental and computing conditions

2. See logitech.com/k600tv for more detail. Works with your Windows or Mac PC connected to the TV, and mobile devices.



PACKAGE SPECIFICATIONS

	Single	Case Pack
Part #	920-008822	N/A
UPC	097855139849	097855139849
Weight	22.93 oz.	98.77 oz.
Width	4.92 in.	5.20 in.
Depth	15.08 in.	15.39 in.
Height	1.22 in.	5.83 in.
Case Pack Count	N/A	4 single units
Pallet Count	672 units	168 case packs

PRODUCT DESCRIPTION

100-word description

The Logitech K600 TV is the smarter way to control your Smart TV. Sit back and navigate grid layouts with the D-Pad and control the cursor with the precision touchpad from up to 15-meters away. Familiar typing allows you to quickly search for content, enter your complicated mix-cased password, and browse the internet with ease. The dedicated media and navigation keys allow you to play and pause movies, control the volume, and immediately launch Home and Search screens. Connect the K600 TV to your Smart TV, PC, and mobile devices – and switch between them with the touch of a button.

50-word description

The Logitech K600 TV is the smarter way to control your Smart TV – with an integrated touchpad and D-Pad. Sit back and simply search for your favorite content thanks to familiar and fast typing, and the integrated D-pad. Enjoy the full capabilities of your Smart TV's web browser with a precision touchpad optimized for larger TV screens.

25-word description

The Logitech K600 TV is the smarter way to control your Smart TV – with an integrated touchpad and D-Pad so you can search, type, find, and unwind.