

# SAMSUNG Galaxy Tab S5e

## Quick Reference Manual

Unlocked<sup>1</sup>



## Samsung Care



Get more than just protection for your device. Pick the time and place, and a team member will meet you to setup, troubleshoot, repair or replace your product.

Enroll, at [samsung.com/us/support/premium-care](https://samsung.com/us/support/premium-care)

### Get to know your product:

- Access user manuals, tips and more at [samsung.com/us/support](https://samsung.com/us/support)

### Ask the community:

- Ask questions and get solutions from Samsung customers, at [us.community.samsung.com](https://us.community.samsung.com)

### Contact us for support:

- For hardware or software support, visit [samsung.com/us/support/contact](https://samsung.com/us/support/contact) or call us at 1.800.SAMSUNG
- Find a service location near you, at [samsung.com/us/support/service/locations](https://samsung.com/us/support/service/locations)

## About your device



<sup>1</sup>Data and messaging services are compatible with most U.S. carriers. Visit [www.samsung.com](https://www.samsung.com) for more information on your device. See your provider for compatibility details.

©2019 Samsung Electronics America, Inc. Samsung and Galaxy Tab are both trademarks of Samsung Electronics Co., Ltd. Android, Google, Google Play, and other marks are trademarks of Google LLC. Other company and product names mentioned herein may be trademarks of their respective owners. Screen images simulated. Appearance of tablet may vary.

Printed in Vietnam  
GH68-51046A




## Customize your device

Tap **Settings** to customize, connect or turn on options to personalize your device.

**Wallpaper** Change the look of the Home and Lock screens.

**Accounts and backup** Tap Users to add additional users for the device.

**Biometrics and security** Set biometric security options.



**Connections** Connect to Wi-Fi network, Bluetooth device and other connection options.

**Lockscreen** Select a screen lock type and set security options.

**Display** Customize the Home screen and display brightness.

**Sounds and vibrations** Set device volume and sounds.

## Device features

**Expandable storage** Expand storage with a microSD™ card.

**Flexible security** Biometric security feature.

**Family share** Connect with your loved ones by sharing photos, events, reminders and notes.

**Bixby home** See upcoming appointments, photos, tomorrow's weather and more.

**Multuser** Allows multiple users for one device.

## Call and message continuity

Never miss calls or messages even if your phone is out of reach.

Note:


- You must be signed in to your Samsung account
- You can only make emergency calls using your phone
- Call quality may decrease

1. From **Settings** , tap **Connections**  > **Call and message continuity** and follow the prompts to complete setup.

Follow the same step to setup **Call and message continuity** on your phone.

2. Once both devices are connected, the device will appear on the connected device list.

## Set up your device



### Install the SIM/microSD card

- Use the tray removal tool to open the microSD™ card tray.
- Slide the SIM card and the optional microSD card (microSD card sold separately) into the tray with the gold contacts facing down.

### Charge the battery


Before turning on your device, charge it fully with the provided charger.

Use only Samsung approved charging devices and batteries. Samsung accessories are designed for your device to maximize battery life. Using other accessories may void your warranty and may cause damage.

## Bixby

Set reminders, see upcoming appointments, photos, tomorrow's weather and more.

To launch Bixby, from the home screen swipe right and follow the prompts to set up.



Visit [samsung.com/us/support/owners/app/Bixby](https://samsung.com/us/support/owners/app/Bixby) for more information.

## Learn more

Use the Help feature to access the user manual and other information on how to use your device, including:



Downloading apps



Managing contacts





Downloading apps created for Galaxy devices.



Configuring accessibility settings



Connecting and controlling smart devices

To open the Help feature, from the Home screen, swipe up and tap **Settings**  > **Help** .

