







ASSEMBLY GUIDE


ARENA




01061802-003

 **Arozzi**






x8



x16










x8






x14




x6









1




2








5





6









9




10









service@arozzi.com



support@arozzi.se

