

Let's get started



AT&T

SAMSUNG Galaxy A10e



 **AT&T 5-Star
Eco-Rating 2.0**
att.com/ecospace

**WIRELESS
EMERGENCY
ALERTS
CAPABLE** 


AT&T Eco Rating 2.0 only applies to Galaxy A10e. For limited factors evaluated visit att.com/EcoSpace. Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

Portions © 2019 Samsung Electronics America, Inc. Samsung and Galaxy A10e are both trademarks of Samsung Electronics Co., Ltd. Portion of memory occupied by existing content. LTE is a trademark of ETSI. 4G LTE is not available everywhere. Wi-Fi is a trademark of the Wi-Fi Alliance. Contains Lithium ion battery - recycle or dispose of properly. Portions © 2019 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.



Optimize the battery

From the home screen, swipe up for **Apps**, and then tap **Settings**  > **Device care** .



Useful apps*



AT&T Call Protect

Tired of nuisance calls? Take more control with automatic fraud blocking and suspected spam warnings.



AT&T DriveMode

Help avoid distractions while driving. Silence incoming text alerts.



AT&T ProTech

Have a question, call or chat with a live AT&T ProTech support expert.



AT&T Smart Wi-Fi

Find and auto-connect to available hotspots.



AT&T Mobile Security

Helps protect against threats that can compromise your personal information.

What's in the box

- Samsung Galaxy A10e
- Pre-installed SIM
- Travel Adapter
- USB Cable
- Inbox Guide
- Terms and Conditions

Find more information

Manage your account with myAT&T

- On your phone: Swipe up for **Apps**, and then tap the **AT&T** folder > **myATT**
- On the web: att.com/myATT



Compatible device and online account required. Data and messaging rates may apply for download and app usage.

Need more help?

- On your phone: Swipe up for **Apps**, and then tap **AT&T** folder > **Device Help**
- On the web: att.com/DeviceHowTo



Give us a call

- 611 from any AT&T wireless phone
- 800.331.0500

Device Protection

Remember to protect your device against loss, theft and damage. Learn more at att.com/protectyourdevice

Samsung Care

- To access user manuals, tips, videos, and more, visit samsung.com/us/support.
- For hardware or software support, call 800.726.7864 or visit samsung.com/us/support/contact.
- To find a repair center near you, visit support-us.samsung.com/cyber/locator/asc_locator.jsp.

*Compatible device and subscription may be required. Data and messaging rates may apply. Restrictions and limitations may apply. For more app information, go to <https://att.com/shop/apps>.

Your new phone



Need more help?


Swipe up for **Apps** > **AT&T** folder > **Device Help**

Rear cover and battery are not removable.
Do not attempt to remove.

Easily adjust settings

Settings menu


From the home screen, swipe up for **Apps**, and then tap **Settings**.



Quick settings

Drag the Status bar down to display the Notification panel.

In addition to notifications, the Notification panel also provides quick access to device functions such as Wi-Fi, allowing you to quickly turn them on or off.



Capture life's moments

Take a picture

From the home screen, tap **Camera** > **Photo**.

- Swipe left or right to zoom in or out.
- Tap to take a photo.
- Tap to take selfies.
- Swipe right or left to select a shooting mode.

Record a video

From the home screen, tap **Camera** > **Video**.

- Tap to start recording.
- Tap to capture a picture while recording.
- Tap to pause recording.
- Tap to end recording.

Share a picture or video

1. After taking the picture, tap the image viewer at the bottom left of the screen,
2. Select the photo you want to share and then tap **Share**.
3. Select the desired option to share your photo and follow the prompts.

How to replace the SIM

Remove SIM/microSD tray

- Use the tool to open the SIM/microSD card tray.

Insert SIM/microSD card

- Place the SIM card and optional microSD card (sold separately) into the tray with the gold contacts facing down.

Turn on your new phone

- Press and hold the **Power/Lock** key until the device turns on.



Call family & friends

Make a call

1. From the home screen, tap **Phone**.
2. Place a call using one of the following:
 - **Keypad**: Displays the keypad, and enter a phone number.
 - **RECENTS**: Select from call history.
 - **CONTACTS**: Select from address book.



Check Voicemail

1. From the home screen, tap **Phone**.
2. Tap **Voicemail**.


Visual Voicemail

1. From the home screen, swipe up for **Apps**, and then tap **Visual Voicemail**.
2. Select a message to play.

Surf & stream in no time

Connect to Wi-Fi

1. From the home screen, swipe up for **Apps**, and then tap **Settings** > **Connections** > **Wi-Fi**.
2. Tap the Wi-Fi slider to turn it on.
3. Tap a network, enter a password if required, then tap **Connect**.



Use Bluetooth

1. From the home screen, swipe up for **Apps**, and then tap **Settings** > **Connections** > **Bluetooth**.
2. Tap the Bluetooth slider to turn it on.
3. Tap the field next to your device name to make it visible for pairing.
4. Tap a device from the list to initiate pairing.

