



10.2
Megapixels

3X
Optical Zoom

2.7"
LCD

Kodak EasyShare M1073 IS

Digital Camera

Sharp pictures meet sharp style.

Take amazingly sharp pictures with the camera you can take anywhere. The stylish KODAK EASYSHARE M1073 IS Digital Camera gives you the power to capture any moment. And with features like image stabilization, blur reduction technology and HD picture capture, this compact and affordable camera was designed to make everyone look good.

- Reduce blur caused by camera shake, subject movement or fast-action situations with image stabilization and blur reduction technology
- Take stunning HD pictures and view them on your HDTV with the optional KODAK EASYSHARE HDTV Dock
- Don't miss a shot, with the security of in-camera charging and the power of the Li-Ion rechargeable battery
- For great shots of friends and family, face detection technology locates faces and automatically adjusts the camera settings
- Capture the details in low-light conditions and fast-action situations with high ISO (up to 1000)

Image stabilization
and blur reduction
technology



View and share your
pictures in stunning
HD quality

Face detection—locates
faces and adjusts camera
settings



Steady it. **Kodak**

Kodak EasyShare M1073 IS

Digital Camera

Standard features

Sensor type	1/2.33 inch CCD
CCD total pixels	10.6 MP (3766 x 2804)
Effective pixels	10.2 MP (3680 x 2760)
Lens	32-96 mm (35 mm film camera equivalent) f/2.9-f/5.2 Includes mechanical shutter and 2 step aperture
Zoom	3X optical zoom lens, 5X continuous advanced digital zoom, 0.2X increments starting at 3X optical zoom (LCD preview mode)
Image stabilizer	Yes
Shutter speed	4-1/2000 sec.
Viewfinder	None
LCD	2.7" (230K pixels) indoor/outdoor color display
Storage	32 MB* internal flash memory, SD/SDHC Card expansion slot

Auto focus

Type	TTL-AF, selectable: multi-zone (5 zones) AF, center zone AF
Focus modes	Normal, landscape, macro-selectable
Focus range	0.6 m - Inf. (auto), 0.10 m - 0.70 m (macro, wide) 0.35 m - 0.70 m (macro, tele), 10 m - Inf. (landscape)
Auto focus	Yes
Auto focus zones	Multizone (5 point) and center zone
AF assist light	No

Exposure control

ISO sensitivity	Auto: ISO 80-160, Manual: 80, 100, 200, 400, 800, 1000 selectable
Metering	TTL-AE, center-weighted, multipattern, center spot
Compensation	± 2.0 EV with 0.3 EV steps
Bracketing	No
AE lock	Exposure is locked when S1 is locked
Histogram	No
White balance	Auto, semi-auto (daylight, tungsten, fluorescent, open shade)

Flash

Range	0.6-2.4 m (@ wide, ISO 160) 0.6-1.4 m (@ tele, ISO 160)
Modes	Auto, Red-Eye Reduction, Fill, Off

Compensation

No

Shooting specification

Burst modes	Single shot, self timer (2 sec. or 10 sec.), two shots, self timer, burst three shot
Face detection	Yes
Shooting modes	Auto, SCN, video, landscape, close-up, high ISO
Scene modes	Portrait, sport, landscape, close-up, children, night portrait, beach, snow, fireworks, self-portrait, back light, night landscape, text/document, manner/museum, flower, sunset, panorama, candlelight, high ISO <0.4 sec. (wide, flash off) <1.3 sec. (wide, preview on, buffer not full)
Click to capture	
Shot to shot	

Still capture

Still format	JPEG/EXIF v2.21
Picture size (recorded pixels)	10.2 MP (4:3): 3680 x 2760 9.0 MP (3:2): 3680 x 2452 7.6 MP (16:9): 3680 x 2070 5.0 MP (4:3): 2592 x 1944 3.1 MP (4:3): 2048 x 1536 2.2 MP (3:2): 1800 x 1200 2.1 MP (16:9): 1920 x 1080 1.2 MP (4:3): 1280 x 960
Color modes	Color (high, natural, low), sepia, black and white
Sharpness	High/normal/low
Long time exposure	0.5-4 sec. (max)
Review menu	Select all, search, tag, favorite, protect, copy, slide show, multimedia slide show, multi-up
Editing	KODAK PERFECT TOUCH Technology, on-camera crop, undo-delete, sound tagging

Video capture

Format	QUICKTIME MOV (motion JPEG) with audio recording during capture and playback
Quality	VGA (640 x 480) @ 15 fps., QVGA (320 x 240) @ 30 fps.

Length	Recording time continuous based on memory capacity (up to 80 minutes max.)
Review menu	Select all, search, tag, favorite, protect, copy, slide show, multimedia slide show, multi-up
Editing	Make picture, action print, trim

Customization

Custom settings	LCD brightness, image storage, image stabilizer, set tag, orientation sensor, camera sounds, sound volume, date & time, auto power off, video out, language
-----------------	---

Share

Share	Select all, print, e-mail, cancel prints
-------	--

Physical specifications

I/O interface	A/V output (NTSC or PAL selectable), digital USB 2.0 full speed, PIMA15740 picture transfer protocol via cable or exclusive KODAK Camera Dock Optional KODAK EASYSHARE Docks with KODAK KLIC-7001 Li-Ion Battery (supplied), 5V AC adapter inlet on camera, USB AC Adapter (supplied) Top: shutter button, flash button, power button Back: mode dial (landscape, auto, close-up, SCN, high ISO, video), zoom button, review button, 4-way and OK button, share button, menu button, delete button 1/4" standard
Tripod mount	92 mm (W) x 56.5 mm (H) x 22.7 mm (D)
Dimensions	117 g (excluding battery and memory card)
Weight	

Compatibility

Dock compatibility	Works with optional KODAK HDTV Dock, KODAK EASYSHARE G610 Printer Dock, KODAK EASYSHARE Camera Dock Series 3 KODAK EASYSHARE Photo Printer 500, IMAGELINK Print System compatible, PICTBRIDGE enabled
Direct print	Works with KODAK EASYSHARE Software

Software

Service and support

Warranty	One year
----------	----------

Minimum system requirements

WINDOWS	WINDOWS XP or higher, 600 MHz processor or greater, INTERNET EXPLORER 6.0 or higher
MACINTOSH	MAC OS X 10.3 and higher

Minimum hardware requirements

	128 MB RAM; 200 MB hard drive disk space available; CD-ROM drive, available USB port; color monitor, 800x600 display resolution, 16-bit minimum
--	---

Package contents

	KODAK EASYSHARE M1073 IS Digital Camera; KODAK Li-Ion Rechargeable Digital Camera Battery KLIC-7001; KODAK USB AC Adapter; USB cable; wrist strap; KODAK EASYSHARE Software; getting started guide; custom camera insert for optional KODAK EASYSHARE Camera and Printer Docks
--	--

Ordering information 111 2697

Recommended accessories

KODAK EASYSHARE Camera Dock Series 3	188 6597
KODAK EASYSHARE HDTV Dock	895 1956
KODAK SD Memory Card, 1 GB	188 5862
KODAK SD Memory Card, 512 MB	833 1613
KODAK Li-Ion Rechargeable Digital Camera Battery KLIC-7001	197 9657
KODAK USB AC Adapter	869 5611
KODAK Li-Ion Universal Battery Charger Kit K7600-C	155 0755
KODAK 5-Volt AC Adapter	154 3669
KODAK Fashion Jewelry Neck and Wrist Straps:	
Black	137 3737
Multicolored	888 9529
KODAK Chic Patent Camera Bags	
Black	190 5975
Red	132 8020

*32 MB internal memory/17 available for picture storage (1 MB equals one million bytes)

For more information on the KODAK EASYSHARE M1073 IS Digital Camera, visit www.kodak.com/go/easyshare.



Product specifications subject to change without prior notice. Simulated screen images.

© Kodak, 2008. KODAK, EASYSHARE, PERFECT TOUCH, and IMAGELINK and the IMAGELINK Print System logo are trademarks of Kodak. QUICKTIME and the QUICKTIME logo are trademarks of Apple, Inc., registered in the U.S. and other countries. USB-IF logos are trademarks of Universal Serial Bus Implementers Forum, Inc. IC-1448 CAT No. 143 9298