

# **Tool-Less Server Rack Blanking Panel**

RKPNLTL1U RKPNLTL2U

**DE:** Bedienungsanleitung - de.startech.com

FR: Guide de l'utilisateur - fr.startech.com

ES: Guía del usuario - es.startech.com

IT: Guida per l'uso - it.startech.com

**NL:** Gebruiksaanwijzing - nl.startech.com

PT: Guia do usuário - pt.startech.com

# **Packaging Contents**

- 1 x 1U Tool-Less Rack Blanking Panel (RKPNLTL1U)
- 1 x 2U Tool-Less Rack Blanking Panel (RKPNLTL2U)

## **System Requirements**

- 1U of Rack Space (RKPNLTL1U)
- 2U of Rack Space (RKPNLTL2U)

## **Product Overview**

#### **RKPNLTL1U**



### **RKPNLTL2U**




## Installation


- 1. Insert the Blanking Panel into the desired 1U or 2U space in the rack.
- 2. Rotate the Latching Pins a quarter-turn clockwise to lock the panel in place.

**Note:** The notch in the Latching Pins will be horizontal when locked





Locked



# **Specifications**

### **RKPNLTL1U**

U Height	1U
Frame Type	Steel
Mounting Options	Front Mount
<b>External Dimensions</b>	18.98 x 1.72 x 0.79 in
(WxDxH)	(482 x 43.7 x 20 mm)
Product Weight	0.71 lb (320 g)

# **Specifications**

## **RKPNLTL2U**

U Height	2U
Frame Type	Steel
<b>Mounting Options</b>	Front Mount
<b>External Dimensions</b>	18.98 x 3.47 x 0.79 in
(WxDxH)	(482 x 88.1 x 20 mm)
Product Weight	1.15 lb (520 g)



## Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

### **Technical Support**

StarTech.com's lifetime technical support is an integral part of our commitment to provide industry-leading solutions. If you ever need help with your product, visit www.startech.com/support and access our comprehensive selection of online tools, documentation, and downloads.

For the latest drivers/software, please visit www.startech.com/downloads

#### **Warranty Information**

This product is backed by a two-year warranty.

In addition, StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

#### **Limitation of Liability**

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.