

SAMSUNG Galaxy Buds+

Quick Start Guide

What's in the box

- Earbuds (L/R)
- Charging case
- Wingtips (S/M/L)
- Ear tips (S/M/L)
- USB cable
- Quick Start Guide

Charge your device



- 2. Connect to power**
Close the charging case and connect the USB cable



- 3. Charging**
The earbuds and the charging case are charged simultaneously



You can also charge the earbuds and charging case simultaneously using a wireless charger.

Use only Samsung-approved charging devices and accessories. Using other accessories may void your warranty and may cause damage.

Samsung Electronics America, Inc.
85 Challenger Road
Ridgefield Park, New Jersey 07660
Phone: 1-800-SAMSUNG (726-7864)
Internet: www.samsung.com

©2020 Samsung Electronics America, Inc.
Samsung, Samsung Galaxy, Samsung Health, and Galaxy Wearable are all trademarks of Samsung Electronics Co., Ltd.
Other marks are the property of their respective owners.


Screen images are simulated. Appearance of device may vary.

Printed in Korea
GH68-51960A



Charger case Indicators

- Green Fully charged or above 60% battery
- Yellow Between 30% and 60% battery
- Red Charging or below 30% battery
- Flashing Red Charging disabled or error due to abnormal temperatures or low battery



Explore

