793mm

146mm

# USER GUIDE

Skullcandy

### Pairing Mode
**"Off Mode**




Pair New Device "Off mode
Coupler Nouvel Appareil "mode Off
Vincular Nuevo Dispositivo "modo Apagado
Accoppia Nuovo Dispositivo "modalità Spento
Emparelhar Novo Dispositivo "modo Desligado
Mit Neuem Gerät Koppeln "ausgeschaltetes"Zustand
Nieuw Apparaat Paren "uitmodus
Pardan Ny Enhet "dvärlet"tillstand
Muodosta Uusi Laitepari "off-tila
Sammenkoble Ny Enhet "av-modus
Para Ny Enhet "av-läge
Сопряжение Нового Устройства "выключенном Режиме
配对新设备 "关机模式
新しいデバイスをペアリング "オフモード
'새 기기 짝맺추기'"끄기 모드
وضع الاقتران

### Pair New Device
**"Jib+ Active/Jib XT Active"**



Pairing Mode
Mode Couplage
Modo De Vinculación
Modalità Di Accoppiamento
Modo Emparelhamento
Koppelmodus
Paarmodus
Parsbevarelsetillstand
Lataparin Muodostustila
Sammenkoblingsmodus
Parningsläge
Режим Сопряжения
配对模式
ペアリングモード
페어링 모드
وضع الاقتران

### Power - On/Off




Power = On/Off
On/Off
Encendido/apagado
Accensione/spegnimento
Ligar/desligar
Een/aus
Aan=Uitzetting
Tænd/sluk For Strøm
Virta Päälle/pois
Strøm Av/på
Strőm Av/på
Включить/выключить Питание
开机/关机
電源 =On/off
전원 켜기/끄기
التشغيل/إيقاف التشغيل

### Volume Up




Volume Up
Volume +
Subir Volumen
Aumento Volume
Aumentar O Volume
Lautstärke Erhöhen
Volume Omhoog
Skru Op For Lydstyrken
Äänenvoimakkuuden Lisäys
Volum Opp
Öka Volymen
Увеличение Громкости
音量增大
音量を上げる
볼륨 높이기
رفع مستوى الصوت

### Volume Down




Volume Down
Volume +
Bajar Volumen
Riduzione Volume
Diminuir O Volume
Lautstärke Senken
Volume Omlaag
Skru Ned For Lydstyrken
Äänenvoimakkuuden Vähennys
Volum Ned
Sänka Volymen
Уменьшение Громкости
音量减小
音量を下げる
볼륨 낮추기
خفض مستوى الصوت

### Play/Pause




Play/pause
Lecture/pause
Reproducir/pausar
Riproduci/pausa
Reproduzir/colocar Em Pausa
Wiedergabe/pause
Afspelen/pauzeren
Afspil/pause
Toisto/tauko
Spill/pause
Spela Upp/pausa
Воспроизведение/пауза
播放/暂停
再生 / 一時停止
재생/일시 정지
تشغيل/إيقاف مؤقت

### Track Forward




Track Forward
Piste Suivante
Adelantar
Brano Successivo
Faixa Seguinte
Nächster Titel
Volgend Nummer
Skift Til Næste Musiknummer
Kelkaa Eteenpäin
Neste Spor
Nästa Ljudspår
Переключение На 1 Трек Вперед
下一曲目
次のトラックを再生する
다음 트랙으로 건너뛰기
مسار إلى الأمام

### Track Back




Track Back
Piste Précédente
Retroceder
Brano Precedente
Faixa Anterior
Vorangehender Titel
Vorig Nummer
Musiknummer Tilbage
Kelaus Taaksepäin
Forrige Spor
Byta Till Föregående Spår
Переключение На 1 Трек Назад
上一曲目
前のトラックを再生する
이전 트랙으로 건너뛰기
مسار إلى الخلف

### Answer/End




Answer/end
Répondre/fin
Responder/colgar
Risposta/fine
Atender/desligar
Annehmen/beenden
Beantwoorden/beëindigen
Besvar/afslut
Vastaus/lopetus
Svar/avslutt
Svara/Ägg På
Ответить/закончить
接听/结束
応答 / 終了
전화 받기/끊기
الرد/النهاية

### Charge



Charge
Charge
Cargar
Carica
Carregar
Aufladen
Opladen
Opkost
Lataus
Lading
Ladda
Зарядка
充电
充電
충전
الشحن

Questions Visit: www.skullcandy.com
Si vous avez des questionsallez surwww.skullcandy.com
Si tienes dudas, visita: www.skullcandy.com
Domande Visitare il sito: www.skullcandy.com
Fazer perguntas: www.skullcandy.com
Fragen Besuch: www.skullcandy.com
Voor vragen bezoek: www.skullcandy.com
For spørgsmål se: www.skullcandy.com
Vastauksia löytyy: www.skullcandy.com
For spørsmål, besøk: www.skullcandy.com
Vid frågor, besök: www.skullcandy.com
Если у вас возникнут вопросы, посетите: www.skullcandy.com
如有问题请访问： www.skullcandy.com
質問がある場合はこちらをご覧ください：www.skullcandy.com
질문 방문: www.skullcandy.com
www.skullcandy.com: إذا كانت لديك أسئلات تفضل بزيارة

For best quality avoid storing product in conditions above 100 degrees.
Pour assurer la meilleure qualité, évitez de garder aux températures qui dépassent 37,7 °C degrés.
Evite guardar el producto en temperaturas por encima de los 37,7 grados para asegurar su máxima calidad.
Per avere la migliore qualità evitare di conservare il prodotto in condizioni che superano i 37,7 gradi.
Para obter a melhor qualidade, evita guardar o produto em condições superiores a 37,7 graus.
Um die bestmögliche Qualität zu gewährleisten, Produkt nicht über 37,7 °C lagern.
Om de kwaliteit van dit product optimaal te houden, mag het niet bij temperaturen boven 37,7 °C worden opgeslagen.
For at opnå den bedste kvalitet, undgå at opbevare produktet under forhold over 37,7°C.
Parhaan laadun takaamiseksi välttä tuotteen säilyttämistä yli 37,7 asteen lämpötilassa.
For optimal kvalitet bør du unngå å oppbevare produktet i temperaturer over 37,7 grader.
För bästa kvalitet, undvik förvaring över 37,7 grader.
Для наилучшего качества избегайте хранения продукта в условиях выше 37,7 градусов.
为了确保最佳音质，避免将产品置于高于37.7摄氏度的环境之中。
最高の品質を保持するため、37.7 °C 以上の条件で製品を保管しないでください。
최상의 품질을 위해 제품을 37.7도 이상에 보관하지 마세요.
لضمان أفضل جودة، يجب تجنب تخزين المنتج في درجات حرارة تزيد عن 37.7 درجة مئوية.

**FCC Compliance Statement**
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

**ISED Compliance Statement**
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1 )This device may not cause interference.(2)This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :(1)L'appareil ne doit pas produire de brouillage;(2)L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé. Cet émetteur ne doit pas être situé au même endroit ou fonctionner avec une autre antenne ou un autre émetteur.

BACK