⊗Prestigio

Open your package

- Prestigio MultiPhone
- Battery
- Carrying case
- Quick start guide
- Headset
- USB cable
- Travel charger

EN

Your phone at a glance

Front camera
Earpiece
Touch screen
Home key
Menu key
Back key
Microphone

Headset jack
Micro USB port
Rear camera
Power button
Volume button
Speaker

Buttons

EN

Button	Definition	Function
▌	Power	• Press and hold to power on or off your phone. • Press to lock or unlock the screen display.
▌	Volume	• Press to adjust the volume.
▭	Menu	• Tap to open a list of options available on the current screen.
▭	Home	• Tap to return to home screen. • Tap and hold to open the list of recent apps.
↩	Back	• Tap to return to the previous screen. • Tap to hide the onscreen keyboard when it is opened.

Getting started

1. Remove the back cover.

2. Take out the battery.

3. Insert your SIM card.

4. Insert a memory card.

5. Replace the back cover.

6. Press and hold the power key to power on your phone.

EN

Charge your phone

Connect your phone to a power outlet by using the included USB cable and travel charger.

## Finger tips

• Tap

• Hold

• Swipe

• Slide

• Zoom in

• Zoom out

EN

• Scroll • Flick

Make a call

1. Use one of the following methods:

  » Tap 📞 to open the dial pad, enter the number directly.

  » Tap 📇 to open contact list, select a contact.

2. Tap Call.

Home screen

Your Home screen is the starting point to access all of the phone's features. The Home screen can have multiple panels. To view other panels, swipe left or right.

Add an app icon to home screen

On the Home screen, tap ⦂⦂⦂ to open list menu, tap and hold

an application icon, and then drag it into a panel preview.

Set wallpaper

1. On the Home screen, tap ▭ > **Wallpaper**.
2. Select one of the following: **Gallery**, **Live wallpapers**, **Video wallpaper** or **Wallpapers**.
3. Select an image and tap **Set wallpaper**. Or, select an image, resize it by dragging the frame, and then tap **OK**.

Use your apps

Open an app

• On the Home screen or the main menu, select an app icon to open it.

Technical Specifications

Item	Specification
Processor	High Performance Dual Core 1.2GHz Cortex A7
Memory	ROM 4GB+RAM Flash 512MB, Micro SD slot supports up to 32GB
OS	Android 4.2
Display	5.0-inch, Capacitive multi-touch
Resolution	480*854 pixels
Band	UMTS:900/2100MHz; GSM:850/900/1800/1900MHz
Interfaces	Micro USB 2.0, Micro SD (micro SDHC compatible)
Communications	WiFi (802.11 b/g/n), 3G, Bluetooth 3.0
Battery	2000 mAh Li-Poly battery
Dimension	149.6*75*9.5mm (H*W*D)

Weight	135g(without battery)

EN

Specific Absorption Rate Information
The highest SAR value for this PAP5501 model when tested for compliance against the standard was 1.587 W/kg (10g)for ICNIRP recommendation.

$C\,\epsilon$ As the Prestigio products are constantly updated and improved, your device's software and hardware may have a slightly different appearance or modified functionality than presented in this Quick Start Guide.

Prestigio hereby states that this Smartphone complies to basic requirements and another relevant regulations given by the EU directive 1999/5/EC. Full version of the declaration of conformity is available on:
http://www.prestigio.com/compliance.