


7. Gently thread, then cut, the cable tie.

# **NOTE**


Do not use too much force; it might deform the cable.



8. Terminate the rest of the cables. Then follow steps 9–11 to secure the cable to the patch panel.



9. Insert the front side of the cover into the panel hood.



10. Push down the cover and snap it into the knob on each side.



11. If you want to install more cables, reverse Steps 9 and 10 to open the cover.

#### TRADEMARKS USED IN THIS MANUAL

BLACK BOX and the Double Diamond logo are registered trademarks of BB Technologies, Inc.


UL is a registered trademark of Underwriters Laboratories Inc.

Any other trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.

© Copyright 2008. Black Box Corporation. All rights reserved.



# CAT6 Shielded Patch Panel, 24-Port



## **CAT6 SHIELDED PATCH PANEL, 24-PORT**

## **Specifications**

Frame: Nickel-plated

Connector: RJ-45 jack (8-wire)

**Compliance:** IEC 60603-7-5 (shielded), TIA/EIA-568B.2-1 (link) Category 6

Connector Shield: 0.098" (0.25) mm thick copper

alloy plated with tin

Contact Resistance: 20 milli ohms maximum

Contacts: 0.018" (0.46 mm) diameter phosphor

bronze,  $50 \ \mu m$  gold over nickel plating

Cover Shield: Nickel-plated

DC Resistance: 0.1 ohms maximum

Housing: Glass-filled polyester UL® 94V-0, black

IDC: 110-type IDC, accepts 22–26 AWG solid wire

Insulation Resistance: 500 Mega ohms minimum

Rated Current: 1.5 amps

Wiring: Supports T568A/T568B

**Size:** 1.75"H (1U) x 19"W x 4.3"D (4.5 x 48.3 x 10.9 cm)

Weight: 4 lb. (1.8 kg)

## **Overview**

### WHAT THE PACKAGE INCLUDES

- CAT6 patch panel base unit
- Patch panel cover
- (48) transparent IDC covers
- (24) cable ties
- Ground wire
- (3) plastic ID cover holders
- (3) paper ID labels
- (4) 12-24 cuphead screws


- (4) 10-32 cuphead screws
- This user's manual

#### TOOLS YOU NEED TO SUPPLY


- Punchdown tool
- Cable stripping tool
- Cable cutters

## Installation

Follow Steps 1–11 to install the CAT6 Shielded Patch Panel, 24-Port.




1. Strip the outer plastic jacket to about 3" (76 mm).



2. Cut 2½" (55 mm) off the copper braid.


# **CAT6 SHIELDED PATCH PANEL, 24-PORT**



3a. If the STP cable has an outer diameter of less than 0.2" (6 mm), place the cable braid under the bracket and cable jacket on the mesh strip. Then attach the cable to equipment ground.



3b. If the STP cable has an outer diameter of more than 0.2" (6 mm), bend back the copper braid and place the braid under the bracket. (Place the bracket exactly where the braid bends.)



4. Cut each single wire's aluminum foil to expose individual pairs.



5. Arrange the wires according to the color. Use a punchdown tool to terminate each pair.



6. After terminating each pair, make sure the aluminum foil fully covers the wires.