

104 KEY FULL-SIZE USB KEYBOARD FOR MAC AND PC User's Guide



www.macally.com

Keyboard Shortcuts for MacOS X

Previous section has described 15 default shortcuts and function keys. They are supported in MacOS X from 10.3 to 10.11, macOS Sierra and above, no driver installation is needed. Please note, these shortcuts are not universal, certain shortcuts such as Zoom in and Zoom out do not work as defined in some application such as Microsoft Word and Excel because these applications have their own way of zooming. On the other hand, some shortcuts may act completely different way in different applications. You should try them out first.

In MacOS X, if shortcuts Brightness adjust and Zoom do not work, please configure Keyboard Shortcuts to enable them:

1. Open System Preferences, double click to open Keyboard icon, then select Keyboard Shortcuts tab.



Introduction

Thank you for purchasing the Macally MKEYE. It is designed with lots of shortcut features and flexibility and will greatly improve your productivity.

Before you begin using this product, be sure to read this user's guide in its entirety.

Package Contents

- USB Keyboard
- User's guide

Macally Product Information

Registration

Please register this product at www.macally.com/register.html.

Technical Support

Please E-mail us at techsupport@macally.com, In U.S.A. please call 1-909-230-6888 Mon-Fri 8:30 AM - 5:30 PM, Pacific Standard Time

Macally Product Information

Warranty

Macally peripherals warrants that this product will be free from defects in title, materials and manufacturing workmanship for one year from the date of purchase. If the product is found to be defective then, as your sole remedy and as the manufacturer's only obligation, Macally will repair or replace the product. This warranty shall not apply to products that have been subject to abuse, misuse, abnormal electrical or environmental conditions, or any condition other than what can be considered as normal use.

Limitation of Liability


The liability of Macally Peripherals arising from this warranty and sale shall be limited to a refund of the purchase price. In no event shall Macally Peripherals be liable for costs of procurement of substitute products or services, or for any lost profit, or for any consequential, incidental, direct or indirect damages, however caused and on any theory of liability, arising from this warranty and sale. These limitations shall apply not with standing any failure of essential purpose of any limited remedy.

Copyright© 2016 by Macally Peripherals

System Requirement

- Mac OS X 10.3 to 10.11, macOS Sierra and above
- Windows 7/8/10 and above
- Any desktop and notebook computer with a USB port available

Hardware Basics



Function keys F1 to F15 mode -

Press "Fn" key with "▼" Down Arrow key simultaneously to switch to function key mode as default.

Additional shortcuts:

- ☼ F14 - Decrease Brightness
- ☼ F15 - increase Brightness

Shortcut Keys

Shortcut mode - Press "Fn" key with "▲" Up Arrow key simultaneously to switch to shortcut mode as default.

- ⌘ Quit Application (Cmd-Q)
- ⌘ Cut (Cmd-X)
- ⌘ Copy (Cmd-C)
- ⌘ Paste (Cmd-V)
- ⏪ Previous Track (Cmd-Left Arrow)
- ⏩ Play/Pause (Spacebar)
- ⏩ Next Track (Cmd-Right Arrow)
- ⏏ Mute
- ⏏ Volume Down
- ⏏ Volume Up
- ⏏ Eject
- ⌘ Rectangular screen area capture (Cmd-Shift-4)
- ⌘ Print (Cmd-P)
- ⌘ Zoom Out (Cmd - (minus))
- ⌘ Zoom in (Cmd = (equal))
- ⌘ File save (Cmd-S)

⌘ Screen capture for Windows PC


More about mode

1. Shortcut mode is restored to default mode after MKEYE loses power, e.g. when unplugged from a computer or a computer is shut down or restarted.
2. In either Shortcut mode or Function key mode, one can also press "Fn" key with one of top row key simultaneously to perform the secondary function without switching mode.


Keyboard Setup Assistant

In Mac, the first time you plug in this new keyboard to use, desktop will pop out a "Keyboard Setup Assistant" window, Please follow the on-screen instruction to identify the keyboard before you can use the keyboard correctly.


After initial setup, if you experience any issue with keyboard or couldn't type correctly, please unplug and replug the keyboard, open keyboard icon in System Preferences, click on "Change Keyboard Type" icon to run Keyboard Setup Assistant to re-identify the keyboard.



2. If your computer has a built-in display, you can enable shortcuts F14 and F15 under Display to adjust brightness.



3. You can enable shortcut Zoom in and Zoom out under Universal Access.



www.macally.com