

Network Management Card 2 for InfraStruxure 40 and 60 kVA PDU

Supported Products: PD40G6FK1-M, PD40F6FK1-M, PD40L6FK1-M, PDRPPNX10-M, PD60G6FK1, PD60F6FK1, PD60L6FK1, PDRPPNX10, PD40E5EK20-M, PD40H5EK20-M

What's in This Document

Schneider Electric Network Management Device IP Configuration Wizard	1
Affected Revision Levels	2
AOS & TCP/IP Stack Modifications (apc_hw05_aos_694.bin).....	2
Application for InfraStruxure 40 and 60 kVA PDU (apc_hw05_xpdu_694.bin)	4
Miscellaneous	5

Schneider Electric Network Management Device IP Configuration Wizard

The Network Management Device IP Configuration Wizard is a Windows application designed specifically to remotely configure the basic TCP/IP settings of Network Management Cards. The Wizard runs on Windows® 2000, Windows 2003, Windows Vista, Windows XP, Windows 7, Windows Server 2008, Windows Server 2016, Windows 8, Windows 10 and Windows 2012. This utility supports cards that have firmware version 3.X.X or higher and is for IPv4 only.

Note: In firmware version AOSv6.8.2 and higher:

The Network Management Device IP Configuration Wizard only supports the discovery of unassigned devices.

You cannot search for assigned devices already on the network using an IP range unless you enable SNMPv1 and set the Community Name to "public". For more information on SNMPv1, see the UserGuide.

When the NMC IP address settings are configured, to access the NMC Web UI in a browser, you must update the URL from http to https.

The Wizard is available as a free download from the APC website at www.apc.com:

1. Go to www.apc.com/shop/tools/software-firmware and select **Wizards and Configurators** from the **Filter by Software/Firmware** drop-down list.
2. Click on the **Download** button to download the **Network Management Device IP Configuration Wizard**.

Affected Revision Levels

File	Detail
apc_hw05_aos_694.bin	Network Management Card Operating System & TCP/IP Stack
apc_hw05_xpdu_694.bin	Application for InfraStruxure 40 and 60 kVA PDU
powernet433.mib	PowerNet(R) SNMP Management Information Base (MIB)

For details on upgrading the network management card firmware, see the user's guide on the SE website (www.se.com).

AOS & TCP/IP Stack Modifications (apc_hw05_aos_694.bin)

Compatibility

apc_hw05_xpdu_694.bin	Application for InfraStruxure 40 and 60 kVA PDU
powernet433.mib	PowerNet(R) SNMP Management Information Base (MIB)

Security Notifications/Disclosure

Ripple20 Vulnerability Fixes:

- This release addresses the Ripple20 vulnerabilities which are defined in the following CVEs: CVE-2020-11896, CVE-2020-11898, CVE-2020-11899, CVE-2020-11902, CVE-2020-11904, CVE-2020-11905, CVE-2020-11906, CVE-2020-11907, CVE-2020-11909, CVE-2020-11910, CVE-2020-11911, CVE-2020-11912, CVE-2020-11913, CVE-2020-11914.

Schneider Electric/APC Bulletin:

<https://www.se.com/ww/en/download/document/SEVD-2020-174-01/>

Known Issues in This Version

- SNMPv3 communication and monitoring on some third-party SNMP management tools such as ManageEngine OpManager does not work properly.
- Modifying large groups of event actions by severity may cause an unexpected network interface restart.
- Device and Read-only users were getting disable after upgrade from 5.x.x to 6.x.x f/w. This is due to the fact that the 5.x.x user database is completely different from the 6.x.x user database.
- It is no longer possible to launch to a device through StruxureWare Data Center Expert if the device contains the 6.9.4 release of the AOS. This issue will be addressed in the upcoming release of Data Center Expert (7.8.1).

New Features and Enhancements

1. Security Updates:
 - a. The removal of SSLv3 and TLS 1.0 from the Web UI, including the Minimum Protocol field.
 - b. The removal of Triple DES (3DES).
 - c. AES128-CTR and AES256-CTR cipher suites have been added to SSH.
 - d. Elliptic-curve Diffie-Hellman (ECDHE) has been added to SSH.
 - e. The "Host" field in the HTTP header now only allows an IPv4/IPv6 address, host name, or fully qualified domain name (FQDN) known to the NMC and not from an external site.
2. EAPoL text is now localized.
3. Modbus TCP now supports a keep-alive time period where the connection will stay active when there is no activity.

Bugs Fixed in This Version

1. Treck Vulnerabilities (Ripple20) - April 2020.
2. IPv6 connectivity outside of local subnet now works in all environments.

Application for InfraStruxure 40 and 60 kVA PDU (apc_hw05_xpdu_694.bin)

Compatibility

apc_hw05_aos_694.bin

Network management card OS & TCP/IP Stack

powernet433.mib

PowerNet(R) SNMP Management Information Base (MIB)

See AOS & TCP/IP Stack Modifications (apc_hw05_aos_694.bin), page 2 for a list of modifications and enhancements that affect this application version.

Known Issues in This Version

No new known issues in this release.

New Features and Enhancements

No new application features for InfraStruxure 40 and 60 kVA PDU in this release.

Bugs Fixed in This Version

None.

Miscellaneous

Recovering From a Lost Password

See the User's Guide on the SE website (www.se.com) for instructions on how to recover from a lost password.

Event Support List

For the event names and event codes for all events supported for a currently connected APC device, first retrieve the Config.ini file from a configured network management card.

To use FTP to retrieve the Config.ini file from a configured network management card:

1. Open a connection to the network management card, using its IP Address:
ftp> open <ip_address>
2. Log on using the Super User/Administrator user name and password.
3. Retrieve the Config.ini file containing the settings of the network management card of the UPS.
ftp> get config.ini.

The file is written to the folder from which you launched FTP.

In the Config.ini file, find the section heading [EventActionConfig]. In the list of events under that section heading, substitute 0x for the initial E in the code for any event to obtain the hexadecimal event code shown in the user interface and in the documentation.

For example, the hexadecimal code for the code E0033 in the Config.ini file (for the event "System: Configuration change") is 0x0033.

Powernet MIB Reference Guide

NOTE: The MIB Reference Guide, available on the SE website (www.se.com), explains the structure of the MIB, types of OIDs, and the procedure for defining trap receivers. For information on specific OIDs, use a MIB browser to view their definitions and available values directly from the MIB itself. You can view the definitions of traps at the end of the MIB itself (the file powernet433.mib is available for download from the SE website, www.se.com).

HASH Signatures

The following are hash signatures for the upgrade utility web download:

MD5 Hash: ca4042b42ba360d326e4b4ebd295088c

SHA-1 Hash: 2f0f9ae4052df54d44d30d1d3f9e0f25f8c4869c

SHA-256 Hash:

6cda41c1ecbc27c811d956a32da1a0f3ffa78ba3a1dcda07a9cadb7fdd7a6896