


# Meet your tablet.

## SAMSUNG Galaxy Tab A

Para la versión en español, visite  
[verizonwireless.com/Support](http://verizonwireless.com/Support)

**verizon**✓

# Setting up your tablet



Your tablet already has a SIM card installed.

## **Optional: Insert the microSD card**

1. Use the tray removal tool to open the tray.
2. Insert the microSD™ card into the tray with the gold contacts facing down, as shown.

NOTE: microSD card is sold separately.

## **Charge your tablet**

Before turning on your tablet charge it fully with the provided charger.

**WARNING:** Only use Samsung approved chargers with your device. Incompatible chargers or tampering with the charging port could damage your device and void the warranty.

# About your tablet



# Using your tablet

## Turning your tablet on/off

To turn your tablet on, press and hold the **Power/Lock** button.

Press the **Power/Lock** button again to turn it off.

## Locking/unlocking the screen

To turn on your screen, press the **Power/Lock** button. Then swipe the screen up to unlock it.

To turn off your screen and prevent accidental key presses, press the **Power/Lock** button.

## Activating your tablet

Activate your tablet to use the internet on Verizon's 4G LTE network.


Turn on your tablet. Then follow the onscreen instructions in the Setup Wizard.

NOTE: Subject to specific terms of use. For coverage details, visit [verizonwireless.com/certifieddevice](http://verizonwireless.com/certifieddevice).

## **Bixby**


Set reminders, see upcoming appointments, tomorrow's weather and more.

From the Home screen, swipe right to launch **Bixby** and follow the prompts to complete setup.



For more information, visit [samsung.com/us/support/owners/app/Bixby](https://samsung.com/us/support/owners/app/Bixby).

# Learning more

 The Help app gives you tips, videos and other information on how to use your tablet, including:



Getting apps




Taking photos



Accessibility settings



>  To open **Help**, from the Home screen swipe up and tap

**Settings > Help.**



Visit **[verizonwireless.com/Support](https://www.verizonwireless.com/Support)**.



Download a User Guide from **[verizonwireless.com/Support](https://www.verizonwireless.com/Support)** or call **888.987.HELP (4357)** to order a copy.

# Managing your account



## **My Verizon Mobile app**

Manage your account, track your usage, edit account information, pay your bill and more.



## **International travel**

For features and rates when traveling outside the US, visit **[verizonwireless.com/international](http://verizonwireless.com/international)**.



## **Customer service**

Call **1.800.922.0204**

Twitter **@VZWSupport**

# Additional information

## **Your wireless device and third-party services**

Verizon Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this are provided by or in conjunction with third parties. Verizon Wireless is not responsible for your use of this device or any non-Verizon Wireless applications, services and products, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use and privacy policies apply. Please review carefully all applicable terms, conditions and policies prior to using this wireless device and any associated application, product or service.



© 2018 Verizon Wireless. All Rights Reserved. Samsung and Galaxy Tab are both trademarks of Samsung Electronics Co., Ltd. Android, Google, Google Play, and other marks are trademarks of Google LLC. Other company and product names mentioned herein may be trademarks of their respective owners. Screen images simulated. Appearance of device may vary.

Not all features, apps or services may be available with your plan, device operating system and software version. Please contact your wireless service provider for more information.

