


OPTI SIT UP BENCH

Assembly & User Instructions- Please Keep for future reference

610/9864

opti



Important – Please read these instructions fully before assembly or use

These instructions contain important information which will help you get the best from your equipment and ensure safe and correct assembly, use and maintenance.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0345 6001714** or visit **www.argos-support.co.uk**

Contents

Safety Information	2
Components - Parts	3
Components - Fixings	4
Assembly Instructions	5--7
Workout Area	8
Exercise Information	9--13
Before starting	9
Muscle Chart	10
Warming up and Cooling down	11--12
Using the bench	13
Care and Maintenance	14
Exploded Parts Diagram	15
Parts List	16



Safety Information

Important – Please read fully before assembly or use

This exercise equipment is built for optimum safety. However, certain precautions apply whenever you operate a piece of exercise equipment. Be sure to read the entire manual before you assemble, operate or use this equipment.


Assembly

- The product must be installed on a stable and level surface.
- Assemble the item as close to its final position (in the same room) as possible.
- Make sure you have enough space to layout the parts before starting.
- Keep children and animals away from the exercise area, small parts could pose a choking hazard if swallowed.
- Dispose of all packaging carefully and responsibly.
- Check you have all the components and tools listed in the parts list, bearing in mind that, for ease of assembly, some components are pre-assembled.

Using

- It is the responsibility of the owner to ensure that all users of this product are properly informed as to how to use this product safely.
- This product is intended for domestic use only. **Do not** use in any commercial, rental, or institutional setting.
- Use the equipment only for intended use, as described in this manual. Do not use attachments not recommended by the manufacturer.
- Keep this equipment indoors, away from moisture and dust. Do not put the equipment in a garage, outbuilding, covered patio, or near water.

- Your product is intended for use in clean dry conditions. You should avoid storage in excessively cold or damp places as this may lead to corrosion and other related problems that are outside our control.
- Keep unsupervised children away from the equipment.
- Disabled persons should not use the equipment without a qualified person or doctor in attendance.
- Always wear appropriate workout clothing when exercising. **Do not** wear loose or baggy clothing, as it may get caught in the equipment. Wear trainers to protect your feet while exercising.
- **Do not** place any sharp objects around the equipment.
- Keep hands away from all moving parts.
- If any of the adjustment devices are left projecting, they could interfere with the user's movement.
- Before using the equipment to exercise, always perform stretching exercises to properly warm up.
- Only one person at a time should use the equipment.
- A spotter is recommended during exercise.
- If the user experiences dizziness, nausea, chest pain, or other abnormal symptoms **stop the workout and seek immediate medical attention.**
- Injuries to health may result from incorrect or excessive training.
- This product is suitable for a maximum user weight of: **110kgs.**
- This product conforms to: BS EN ISO 20957-1, and -4 Class (H) - Home Use .


 **Warning:** Before beginning any exercise program, consult your Doctor. This is especially important for persons over the age of 35 or persons with pre-existing health problems. You **MUST** read all instructions before using any fitness equipment. Argos and its associates assumes no responsibility for personal injury or property damage sustained by or through the use of this product.

Components - Parts


If you have damaged or missing parts, please call the
Customer Helpline: 0345 600 1714

Please check you have all parts listed below


Note: Some of the smaller components may be pre-fitted to larger components. Please check carefully before contacting Argos regarding any missing components.
Total mass of the product is 6.5 kg. Total size of the equipment is (D) 128 cm × (W) 32 cm × (H) 52 cm.




1 Main frame × 1




3 Incline adjust tube × 1




7 Front T shape stabilizer × 1




4 Foam roll × 4




6 Foam roll tube × 1




5 Lower protection holder tube × 1



2 Backrest rad × 1



17 Knob nut × 1










8 Lock pin × 1

Components - Fixings

Please check you have all fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more hardware may be supplied than are required. Some of the fixings are pre-fitted to the larger components. Please check carefully before contacting Argos regarding any missing fixings.


<p>9 </p> <p>M10×60mm Allen bolt × 1</p>	<p>13 </p> <p>M8×18mm Allen bolt × 4</p>	<p>10 </p> <p>M10 Aircraft Nut × 1</p>
<p>11 </p> <p>Ø10 mm Washer × 2</p>	<p>12 </p> <p>Ø8mm Washer × 4</p>	<p>18 </p> <p>5# Allen Wrench × 1</p>
<p>19 </p> <p>6# Allen Wrench × 1</p>		

Tools prepared by user



Adjustable
spanner x 1


Assembly instructions



Step 1

- A). Attach the Main Frame(#1) to the bracket on Incline Adjust Tube(#3), Align the hole and secure front hole with one M10×60MM Allen Bolt(#9), two Φ 10mm Washers (#11) and one M10 Aircraft Nut (#10), insert the Lock Pin(#8) into the rear hole.
- B). Insert the Incline Adjust Tube(#3) into the front opening of the Front T shape Stabilizer(#7), Select desired height and secure with Lower Protection Holder Tube(#5) and Knob Nut(#17).


Assembly instructions



Step 2

A). Attach the Backrest Pad (#2) to the Main Frame (#1), align the hole and secure with four M8×18MM Allen Bolts (#13) and four Φ 8mm Washers (#12).

Assembly instructions




Step 3

- A). Insert the Foam Roll Tube(#6) into the hole on the top of the Incline Adjust Tube(#3) with half way, attach two Foam Rolls (#4) from each side of the Foam Roll Tube(#6). Attach two Foam Rolls (#4) from each side of the Lower Protection Holder Tube(#5).
- B) When finish workout, pull out the Lock Pin(#8), then fold up the Front T shape Stabilizer(#7) and locked with Lock Pin(#8), the unit can be folded for storage to save space.

Workout area

The free area must be at least 0.6m greater than the training area. This is a space where you can safely dismount, without obstruction, in case of an emergency. Where two pieces of equipment are positioned adjacent to each other the free area may be shared



Only one person should be within the training area when the equipment is in use.

Exercise Information

Before starting

Tailor your exercise program according to your physical condition. If you have been inactive for several years, or are overweight, you must start slowly and increase your time on the equipment, a few minutes per workout increase is advisable.


Initially, you may be able to exercise only for a few minutes in your target zone; however, your aerobic fitness will improve over the next six to eight weeks. Don't be discouraged if it takes longer. It's important to work at your own pace.

Please remember these essentials:

- Have your doctor review your training and diet programme to advise you of a workout routine you should adopt.
- Begin your training programme slowly with realistic goals
- Monitor your pulse frequently. Establish your target heart rate based on your age and condition.
- Set up your equipment on a flat even surface with adequate training area, as prescribed in this manual.


Exercise intensity

To maximize the benefits of exercising, it is important to exercise at an appropriate intensity. The intensity level can be found by using your heart rate as a guide. For effective aerobic exercise, your heart rate should be maintained at a level between 65% and 85% of your maximum heart rate as you exercise. This is known as your target zone. You can find your target zone in the table below.



During the first few months of your exercise programme, keep your heart rate near the low end of your target zone as you exercise. After a few months, your heart rate can be increased gradually until it is near the middle of your target zone as you exercises.

To measure your heart rate, stop exercising but continue moving your legs or walking around and place two fingers on your wrist. Take a six-second heartbeat count and multiply the results by 10 to find your heart rate. For example, if your six - second heartbeat count is 14, your heart rate is 140 beats per minute. (A six-second count is used because your heart rate will drop rapidly when you stop exercising.) Adjust the intensity of your exercise until your heart rate is at the required level.



Exercise Information

Muscle chart

Aerobic Exercise


Aerobic exercise improves the fitness of your lungs and heart - your body's most important muscle. Aerobic exercise fitness is promoted by any activity that uses your large muscles (arms, legs or buttocks, for example).

Weight Training

Along with aerobic exercising which helps get rid of and keep off the excess fat that our bodies can store, weight training is an essential part of the routine process. Weight training helps tone, build and strengthen muscle. If you are working above your target zone, you may want to do a lesser amount of reps.


Targeted Muscle Groups

The exercise routine that is performed on the Workout Bench will develop the upper and lower body muscle groups.



Front

- | | |
|-----------------------------|-----------------------------|
| A: Trapezius | F: Abdominal |
| B: Anterior Deltoid | G: Sartorius |
| C: Pectoralis Major | H: Quadriceps |
| D: Serratus Anterior | I: Tibialis Anterior |
| E: Biceps | |



Back

- | | |
|-----------------------------|-------------------------|
| J: Trapezius | N: Gluteals |
| K: Posterior Deltoid | O: Hamstrings |
| L: Triceps | P: Gastrocnemius |
| M: Latissimus Dorsi | |

Exercise Information

Warming up and Cooling down

Each workout should include the following three parts:

1. A warm up, consisting of 5 to 10 minutes of stretching and light exercise. A proper warm up increases your body temperature, heart rate and circulation in preparation for exercise.
2. Training zone exercise consisting of 20 to 30 minutes of exercising with your heart rate in your training zone. (**Note:** During the first few weeks of your exercise programme, do not keep your heart rate in your training zone for longer than 20 minutes.)
3. A cool down, with 5 to 10 minutes of stretching. This will increase the flexibility of your muscles and will help to reduce post-exercise muscle soreness.

Exercise Frequency


To maintain or improve your fitness, plan three workouts each week with at least one day of rest between workouts. After a few months of regular exercise, you may complete up to five workouts each week, if desired. Remember, the key to success is to make exercise a regular and enjoyable part of your everyday life.

Toe touch stretch

Stand with your knees bent slightly and slowly bend forward from your hips. Allow your back and shoulders to relax as you reach down toward your toes as far as possible.

Hold 15 counts, and then relax. Repeat 3 times.

Stretches: Hamstrings, back of knees and back.



Hamstring stretch

Sit with one leg extended. Bring the sole of the opposite foot toward you and rest it against the inner thigh of your extended leg. Reach toward your toes as far as possible.

Hold for 15 counts, and then relax.

Repeat 3 times for each leg.

Stretches: Hamstrings, lower back and groin.



Exercise Information


Calf / Achilles stretch

With one leg in front of the other, reach forward and place your hands against a wall. Keep your back leg straight and your back foot flat on the floor. Bend your front leg, lean forward and move your hips toward the wall.

Hold for 15 counts, and then relax.

Repeat 3 times for each leg. To cause further stretching of the Achilles tendons, bend your back leg as well.

Stretches: Calves, Achilles Tendons and Ankles.



Quadriceps stretch

With one hand against the wall for balance, reach back and grasp one foot with your other hand. Keeping your bent knee pointing directly downward towards the floor, gently pull your heel towards your buttock until you feel a gentle stretch in the target area.

Hold for 15 counts, and then relax. Repeat 3 times for each leg.

Stretches: Quadriceps and Hip muscles.



Inner thigh stretch

Sit with the soles of your feet together and your knees outward. Pull your feet toward your groin area as far as possible.

Hold for 15 counts, and then relax. Repeat 3 times.

Stretches: Quadriceps and Hip muscles.



Exercise Information

Using the bench

Important

When working out, do the following for each exercise: exhale while exerting/lifting and inhale while returning to starting position in a slow and controlled manner

- Read all caution and warning stickers before using this equipment.
- Before using, inspect the equipment for loose, frayed, or worn parts, if in doubt do not use the equipment until the parts have been replaced.
- Before beginning any exercise programme it is suggested to have a complete medical examination and to obtain your doctor's approval of your exercise/conditioning programme.
- Any clips must be closed completely before using this equipment.
- We recommend that you always exercise with a partner or someone who can assist you in case the weights become too heavy for you to lift on your own.


Always warm up your muscles before exercising. Prepare your body with easy stretching (without bouncing) and light callisthenic, for several minutes.

Thigh Exercise

Lay in the board as shown in the figure, raise the leg until it's horizontal and decent it without touching with the other leg, repeat with both legs.

Field of application:

Outer thigh, waist




Back Knees Raise

Lean on the board looking upwards as shown in the figure. Make a set of repetitions raising the legs until they form a 90° angle with the body.

Field of application

Abdomen




Sit Up

Lock the legs and lean the board as shown in the figure, Raise the trunk until it forms a 90° angle with the body and starting from this point make a set of repetition.

Field of Application


Abdomen



Care and Maintenance

1. The safety level of the equipment can only be maintained if it is examined regularly for damage and wear e.g. ropes, pulleys and connection points.
 2. Inspect and tighten all parts before using the equipment. Replace defective components immediately, and /or keep the equipment out of use until repair. Pay special attention to components most susceptible to wear.
 3. The equipment can be cleaned using a damp cloth and mild non-abrasive detergent. **Do not** use solvents.
 4. **Do not** attempt to repair this equipment yourself. Should you have any difficulty with assembly, operation or use of your exercise product or if you think that you may have parts missing, contact the **Customer Helpline: 0345 6001714** www.argos-support.co.uk
- Guarantee:**
For guarantee purposes, please retain your purchase receipt

Exploded Parts Diagram



Parts List

Part	Description	Qty
1	Main Frame	1
2	Backrest Pad	1
3	Incline Adjust Tube	1
4	Foam Roll	4
5	Lower Protection Holder Tube	1
6	Foam Roll Tube	1
7	Front T shape Stabilizer	1
8	Lock Pin	1
9	M10×60MM Allen Bolt	1
10	M10 Aircraft Nut	1
11	Φ10mm Washer	2
12	Φ8mm Washer	4
13	M8×18MM Allen Bolt	4
14	Φ38mm Foot	4
15	Φ19mm End Cap	4
16	□ 38mm End Cap	1
17	Knob Nut	1
18	5# Allen Bolt	1
19	6# Allen Bolt	1

Guarantee



Product Guarantee

This product is guaranteed against manufacturing defects from a period of



Year

This product is guaranteed for one year from the date of original purchase.

Any defect that arises due to faulty materials or workmanship will either be replaced refunded or repaired free of charge where possible during this period by the dealer from whom you purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual
- It must be used solely for domestic purpose
- The guarantee will rendered invalided if the products is re-sold or has been damaged by inexpert repair
- Specifications are subject to change without notice
- The manufacturer disclaims any liability for the incidental or consequential damages.
- The guarantee is in addition to, and does not diminish your statutory or legal right
- In the event of problem with the product with in the guarantee period call the

Customer Helpline: 0345 6001714 www.argos-support.co.uk

Guarantor: Argos Ltd
489 – 499 Avebury Boulevard
Central Milton Keynes
MK9 2NW